Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DURACELL CT AA x24 - PB

Duracell Coppertop AA Batteries with Power Boost Ingredients

Instruction Manual

1. Introduction

This manual provides essential information for the safe and effective use of Duracell Coppertop AA Alkaline Batteries with Power Boost Ingredients. These batteries are designed to deliver reliable and long-lasting power for a wide range of household and office devices.



Image 1.1: Duracell Coppertop AA Batteries, 24-count pack. This image displays the front packaging of the Duracell Coppertop AA batteries, highlighting the brand, battery type, and count.

Duracell Coppertop AA batteries incorporate Power Boost Ingredients, a patented formulation engineered to provide enhanced performance for your devices. They are suitable for use in items such as remote controls, flashlights, toys, calculators, clocks, radios, wireless mice, and keyboards.

2. Safety Information

Please read and adhere to the following safety guidelines to prevent injury or damage to devices.

- May explode or leak, and cause burn injury, if recharged, disposed of in fire, mixed with a different battery type, inserted backwards or disassembled.
- Replace all used batteries at the same time.
- Do not carry batteries loose in your pocket or purse.
- Do not remove the battery label.
- Keep batteries away from children. If swallowed, consult a physician at once. For information on treatment, call (202) 625-3333 collect.



Image 2.1: Back of Duracell Coppertop AA Battery packaging. This image shows the reverse side of the battery packaging, detailing important safety warnings and usage instructions in multiple languages.

For additional safety details, refer to the official Safety Information PDF:Duracell Safety Information (PDF).

3. Installation and Usage

To install Duracell Coppertop AA batteries:

1. Identify the battery compartment in your device.
2. Observe the polarity markings (+ and -) inside the compartment.
3. Insert the batteries, ensuring that the positive (+) end of the battery aligns with the positive (+) terminal in the device, and the negative (-) end aligns with the negative (-) terminal.
4. Close the battery compartment securely.

Always replace all batteries in a device at the same time with new batteries of the same type and brand to ensure optimal performance and prevent leakage.



Image 3.1: Diagram of Duracell Power Boost Ingredients. This graphic illustrates the internal composition of a Duracell battery, highlighting the unique blend of Nickel & Lithium that contributes to its Power Boost technology, compared to other standard batteries.

4. Storage and Maintenance

Duracell Coppertop AA batteries are guaranteed to last for **12 years in storage**. To maintain their performance and extend their shelf life:

- Store batteries in a cool, dry place at room temperature.
- Avoid extreme temperatures, both hot and cold, as these can reduce battery life.
- Keep batteries in their original packaging until ready for use to prevent accidental short-circuiting.
- Do not store batteries with metal objects like coins or keys.



Image 4.1: Duracell 12-Year Storage Guarantee. This image emphasizes the long shelf life of Duracell batteries, stating they are guaranteed for 12 years in storage.

5. Troubleshooting

If your device is not functioning after installing new batteries:

- **Check Polarity:** Ensure batteries are inserted correctly according to the device's positive (+) and negative (-) markings.
- **Replace All Batteries:** If using multiple batteries, replace all of them simultaneously with fresh ones. Mixing old and new batteries, or different types, can impair performance.
- **Inspect Contacts:** Verify that the battery contacts in the device are clean and free from corrosion. Gently clean them if necessary.
- **Device Functionality:** Test the device with another set of known good batteries to rule out a device malfunction.

6. Product Specifications

Specification	Detail
Brand	DURACELL
Model Number	CT AA x24 - PB
Battery Cell Composition	Alkaline
Battery Size	AA
Product Dimensions	1.19 x 7.75 x 4.5 inches
Item Weight	1.23 Pounds
Recommended Uses	TV Remote, Gaming Controller, Camera, Flashlights, Toys
Storage Life	12 Years

7. Warranty and Support

Duracell guarantees these batteries against defects in material and workmanship. If you experience any issues, please refer to the contact information provided on the product packaging or the official Duracell website for support.
For further assistance or to report a concern, please consult the official Duracell resources.

8. Additional Resources

For more detailed information regarding battery safety and disposal, please visit the official Duracell website or consult local regulations.
Note: No official product videos were available with the required metadata for embedding in this manual.

© 2025 DURACELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0035LCFNQ

More documents and user manuals: **https://manuals.plus/**