Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mystim MS46575

Mystim Charming Chuck E-Stim Penis Strapset

Model: MS46575 | Brand: Mystim

Introduction

The Mystim Charming Chuck E-Stim Penis Strapset is an accessory designed for use with a compatible E-Stim power unit (sold separately). This set includes two elastic conductive bands made from textile fiber, intended for electrical stimulation of male genitalia. This manual provides essential information for the safe and effective setup, operation, and maintenance of your Charming Chuck strapset.

Safety Information

Please read all safety warnings before using this product.

- Consult a physician before use if you have any medical conditions, especially heart conditions, pacemakers, epilepsy, or are pregnant.
- Do not use on broken, irritated, or sensitive skin.
- This product is an accessory and requires a separate E-Stim power unit for operation. Ensure your E-Stim unit is compatible and used according to its own safety guidelines.
- Always start with the lowest intensity setting on your E-Stim power unit and gradually increase to a comfortable level.
- Discontinue use immediately if discomfort, pain, burning, or skin irritation occurs.
- Do not use this product while sleeping or in situations where you cannot safely control the E-Stim unit.
- Keep out of reach of children.
- Use only water-based conductive gel to ensure proper conductivity and prevent skin irritation. Do not use oil-based lubricants.

Package Contents

- 2 x Mystim Charming Chuck E-Stim Bands
- 2 x Connection Cables (for E-Stim unit)



Image showing the two elastic conductive bands connected to their electrode cables, as typically found in the package.

Setup Instructions

1. **Prepare the Bands:** Ensure the Charming Chuck bands are clean and dry before use.
2. **Connect Cables:** Attach the provided connection cables to the buckles on each Charming Chuck band. Ensure a secure connection.
3. **Apply Conductive Gel:** Apply a generous amount of water-based conductive gel to the inner, conductive surface of both bands where they will make contact with the skin. This is crucial for effective and comfortable stimulation.
4. **Position the Bands:** Carefully place the bands around the desired area of the male genitalia. Adjust the bands for a snug, but not overly tight, fit. Ensure the conductive surface is in full contact with the skin.
5. **Connect to E-Stim Unit:** Plug the other end of the connection cables into your compatible Mystim E-Stim power unit. Refer to your E-Stim unit's manual for specific connection ports.



Image showing the two elastic conductive bands with their buckles, ready for cable connection and application.

Operating Instructions

1. **Power On:** Turn on your Mystim E-Stim power unit. Ensure the intensity setting is at its lowest level before starting.
2. **Adjust Intensity:** Slowly increase the intensity on your E-Stim unit until you feel a comfortable and pleasant sensation. Do not increase the intensity to a painful or uncomfortable level.
3. **Session Duration:** Follow the recommended session durations provided in your E-Stim power unit's manual. Typically, sessions last between 15 to 60 minutes.
4. **Discontinue Use:** If you experience any discomfort, pain, or irritation, immediately reduce the intensity or turn off the E-Stim unit.
5. **Power Off:** After your session, turn off the E-Stim power unit before disconnecting the cables or removing the bands.

Maintenance and Care

- **Cleaning:** After each use, gently hand wash the bands with mild soap and lukewarm water. Rinse thoroughly to remove all soap residue and conductive gel.
- **Drying:** Allow the bands to air dry completely before storing. Do not wring or twist the bands.
- **Storage:** Store the Charming Chuck bands and cables in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not use abrasive cleaners or harsh chemicals on the bands. Avoid bending or kinking the cables excessively.

Troubleshooting

- **No Sensation or Weak Sensation:**
  - Ensure the E-Stim power unit is turned on and has sufficient battery power.
  - Check that all cables are securely connected to both the bands and the E-Stim unit.
  - Verify that enough conductive gel has been applied to the bands and that they are making good contact with the skin.
  - Increase the intensity setting on your E-Stim unit gradually.
- **Stinging or Burning Sensation:**
  - Immediately reduce the intensity setting on your E-Stim unit.
  - Reapply more conductive gel to ensure even distribution and good conductivity.
  - Adjust the position of the bands to ensure full and even contact with the skin, avoiding any pinching or uneven pressure points.
  - Inspect the bands for any damage or wear that might cause uneven conductivity.

Specifications

Product Name	Mystim Charming Chuck
Model Number	MS46575
Brand	Mystim
Material	Conductive Textile Fiber, Silicone
Color	Black
Dimensions (L x W x H)	Approximately 25 x 1 x 25.4 cm (9.84 x 0.39 x 10 inches)
Net Product Weight	Approximately 54.43 grams (0.12 lbs)
Water Resistance Level	Waterproof (Hand wash only)
Care Instructions	Hand wash
Country of Origin	China

Warranty Information

Specific warranty information for the Mystim Charming Chuck E-Stim Penis Strapset is not provided in this manual. Please refer to the product packaging or contact Mystim customer support for details regarding warranty coverage.

Customer Support

For further assistance, technical support, or inquiries regarding your Mystim Charming Chuck E-Stim Penis Strapset, please visit the official Mystim website or contact their customer service department. Contact details may also be found on the product packaging.

© 2023 Mystim. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0037NZ8GI

More documents and user manuals: **https://manuals.plus/**