Manuals+
Q & A | Deep Search | Upload

Optimus 50003

Optimus 50003 Personal Grooming System Instruction Manual

Model: 50003

Introduction

This manual provides detailed instructions for the safe and effective use of your Optimus 50003 Personal Grooming System. This system is designed for comfortable removal of nose, ear, and eyebrow hairs, and includes a high-performance trimmer head attachment for larger areas. Please read this manual thoroughly before initial use and retain it for future reference.

Safety Information

- **Water Exposure:** Keep the trimmer away from direct water sources. While water-resistant, it is not designed for submersion.
- **Battery Safety:** Keep batteries out of reach of children. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.
- **Intended Use:** Use this product only for its intended purpose as described in this manual.
- **Blade Care:** The blades are self-sharpening and maintenance-free. Do not attempt to sharpen or modify the blades.
- **Cleaning:** Ensure the device is turned off before cleaning.

Package Contents

Verify that all items are present in the package:

- Optimus 50003 Personal Grooming System (Main Unit)
- Rotary Blade Head (pre-installed)
- High-Performance Trimmer Head Attachment
- Fast Trimming Comb
- Convenient Storage Stand
- Instruction Manual
- *Note: One AA battery is required and not included.*

OPTIMUS
PERSONAL GROOMING SYSTEM
SISTEMA DE CUIDADO PERSONAL
PET
INCLUDES:
• High-performance Trimmer Head.
• Cleaning Brush.
• Convenient Store Stand.
• Fast Trimming Comb.
• Instructions (in English And Spanish) & Warranty.
INCLUYE:
• Cabeza de cortadora de alto rendimiento.
• Cepillo de Limpieza.
• Conveniente pedestal de tienda.
• cepillo de cortado rápido.
• Instrucciones (y Garantía en inglés y español).
OPTIMUS
MODEL:50003S
• Operates on one AA battery (not included)
• Opera con una batería AA (no incluida)
UN AÑO
1
GARANTÍA LIMITADA
6 30326 50003 0
OPTIMUS ENTERPRISE, INC
ANAHEIM, CA 92806
MADE IN CHINA

Image: Back of product packaging illustrating the included components.

Product Overview

The Optimus 50003 features a durable design with an easy-grip rubber-coated body. It is equipped with self-sharpening stainless steel blades for consistent performance.

- **Rotary Blade System:** Designed for comfortable and precise removal of nose, ear, and eyebrow hairs.
- **High-Performance Trimmer Head:** An interchangeable attachment for trimming hair in larger areas.
- **Fast Trimming Comb:** Used with the trimmer head for uniform hair length.
- **Water Resistant:** Allows for easy cleaning under running water.

Image: The Optimus 50003 grooming system with its main unit, interchangeable trimmer head, and storage stand.

Image: Visual representation of the key features of the Optimus 50003 grooming system.

Setup

Battery Installation

1. Ensure the grooming system is turned off.
2. Gently twist the bottom part of the main unit counter-clockwise to open the battery compartment.
3. Insert one (1) AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the bottom cover by twisting it clockwise until securely closed.

Operating Instructions

Using the Rotary Blade Head (Nose, Ear, Eyebrows)

1. Ensure the rotary blade head is securely attached to the main unit.
2. Turn on the device by sliding the power switch.
3. **For Nose/Ear Hair:** Gently insert the rotary blade tip into the nostril or ear canal. Move the trimmer in a circular motion to trim unwanted hair. Do not insert too deeply.
4. **For Eyebrow Hair:** Carefully guide the rotary blade along the desired eyebrow line to trim stray hairs. Use caution to avoid over-trimming.
5. After use, turn off the device.

Image: Detailed view of the rotary blade head, designed for precise trimming.

Using the High-Performance Trimmer Head and Comb

1. To attach the trimmer head, twist the rotary blade head counter-clockwise and remove it. Align the trimmer head with the main unit and twist clockwise until it locks into place.
2. For uniform trimming, slide the fast trimming comb onto the trimmer head.
3. Turn on the device.
4. Gently guide the trimmer head with the comb against the direction of hair growth to trim hair in larger areas.
5. After use, turn off the device.

Maintenance

Cleaning

- Ensure the grooming system is turned off and remove the battery if storing for extended periods.
- Remove the trimming head (rotary or trimmer head) from the main unit.
- Rinse the trimming head under running water to remove hair clippings. The blades are water-resistant.
- Use the included cleaning brush to remove any stubborn hair from the blades or inside the head.
- Allow the trimming head to air dry completely before reattaching it to the main unit or storing.

- Wipe the main unit with a damp cloth if necessary. Do not immerse the main unit in water.

Storage

Store the grooming system and its attachments in the convenient storage stand in a cool, dry place, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is dead or incorrectly inserted.	Check battery orientation. Replace with a new AA battery.
Trimmer pulls hair or cuts poorly.	Blades are clogged with hair. Battery power is low.	Clean the trimming head thoroughly. Replace the battery.
Trimming head is difficult to attach/detach.	Incorrect alignment or debris.	Ensure proper alignment and twist firmly. Check for any obstructions.

Specifications

- **Model:** Optimus 50003
- **Power Source:** 1 x AA Battery (not included)
- **Blade Material:** Stainless Steel
- **Features:** Rotary Blade System, High-Performance Trimmer Head, Fast Trimming Comb, Water Resistant, Self-Sharpening Blades, Easy-Grip Rubber Coated Body
- **Dimensions:** Approximately 3 x 2 x 7 inches
- **Weight:** Approximately 3.2 ounces
- **Color:** Black/Silver
- **UPC:** 630326500030
- **Manufacturer:** Optimus Enterprises, Inc.

Warranty and Support

The Optimus 50003 Personal Grooming System is backed by a **one-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair.
For warranty claims or technical support, please contact Optimus Enterprises, Inc. customer service. Refer to the product packaging or the manufacturer's website for current contact information.