Manuals+
Q & A | Deep Search | Upload

simplehuman CW1355

simplehuman 50 Liter / 13 Gallon Semi-Round Kitchen Step Trash Can

MODEL: CW1355

Product Overview

The simplehuman 50 Liter / 13 Gallon Semi-Round Kitchen Step Trash Can is designed for efficiency and durability in your home. It features simplehuman's proprietary lid shox technology for a smooth, quiet close and a secure slide lock to keep the lid shut from curious pets and children. Its semi-round shape allows for space-efficient placement against walls, making it ideal for high-traffic kitchen areas.

- **Silent Close Lid:** Patented lid shox technology ensures a slow, silent close.
- **Lock the Lid Shut:** A slide lock securely fastens the lid, preventing access by pets and children.
- **Stay-Open Lid:** The lid remains open for extended periods, convenient for longer tasks.
- **Semi-Round Shape:** Space-efficient design fits perfectly against walls.
- **Large Capacity:** Ideal for large families or busy households.
- **Custom Fit Liners:** Designed to fit perfectly, preventing slippage and remaining hidden.

Front view of the simplehuman 50 Liter Semi-Round Kitchen Step Trash Can in black plastic.

Setup Instructions

1. **Unpack the Trash Can:** Carefully remove all packaging materials from the trash can and its components.
2. **Choose a Location:** Place the semi-round trash can against a wall or in a corner to maximize space

efficiency. Ensure there is enough clearance for the lid to open fully.

3. **Install Trash Liner:** Lift the lid. Place a simplehuman Code P custom fit liner (or a standard 13-gallon trash bag) around the rim of the inner bucket. Ensure the bag is fully extended and secured to prevent slippage.

The trash can with its lid open, showing a liner properly installed around the rim.

Operating Instructions

- **Using the Step Pedal:** To open the lid, simply step firmly on the steel pedal at the base of the can. The lid will open smoothly.
- **Silent Close Feature:** When you release the pedal, the lid will close slowly and silently due to the integrated lid shox technology, preventing slamming.
- **Stay-Open Lid:** For longer tasks, such as scraping plates or extended cleaning, manually lift the lid until it locks into the fully open position. To close, gently push the lid down.
- **Secure Slide Lock:** To engage the lock, slide the silver latch located on the front of the lid towards the closed position. This will securely lock the lid, preventing accidental opening by pets or small children. To unlock, slide the latch back to the open position.

The simplehuman trash can showing its durable steel foot pedal for hands-free operation.



Detail of the slide lock on the simplehuman trash can, designed to secure the lid.

The lid of the simplehuman trash can shown in its convenient stay-open position.

Maintenance

- **Cleaning:** Wipe the exterior of the trash can with a soft, damp cloth and mild detergent as needed. Avoid abrasive cleaners or scouring pads, which can damage the finish.
- **Liner Replacement:** When the trash bag is full, lift the lid, remove the full bag, and replace it with a new simplehuman Code P liner or equivalent.
- **OdorSorb System (if applicable):** If your model includes an OdorSorb pod, replace it every 45 days for optimal odor control. The microporous membrane continuously releases a natural plant oil-based formula to neutralize trash odors.

Close-up of the OdorSorb system, which helps neutralize trash odors.

Troubleshooting

Problem	Possible Cause	Solution
Lid does not close silently.	Mechanism obstruction or wear.	Check for debris around the lid hinge. Ensure the can is on a level surface. If issues persist, contact customer support.
Slide lock is difficult to engage/disengage.	Debris or misalignment.	Clean the slide lock area. Ensure the lid is properly seated.
Unpleasant odors persist.	Liner not properly sealed, can needs cleaning, or OdorSorb pod needs replacement.	Ensure trash bag is fully sealed. Clean the interior and exterior of the can thoroughly. Replace OdorSorb pod if applicable.

Specifications

Brand: simplehuman

Model Number: CW1355

Capacity: 50 Liters / 13 Gallons

Color: Black

Material: Plastic

Opening Mechanism: Step-On

Shape: Semi-Circular

Special Features: Dent Resistant, Lockable

Product Dimensions (L x W x H):18.7" x 14.4" x 26.2"

Item Weight: 7 Pounds

UPC: 838810019543

Detailed dimensions of the simplehuman 50 Liter Semi-Round Kitchen Step Trash Can.

Warranty & Support

The simplehuman 50 Liter / 13 Gallon Semi-Round Kitchen Step Trash Can comes with a **5-year warranty**, covering defects in material and workmanship under normal household use.

For detailed warranty information, troubleshooting assistance, or to contact customer support, please refer to the official user manual or visit the simplehuman website.

You can also download the User Manual (PDF) for more information.

© 2024 simplehuman. All rights reserved.