Manuals+
Q & A | Deep Search | Upload

Casio WV-59

Casio Replacement Band WV-59 Series Instruction Manual

Introduction

This manual provides instructions for the installation and care of your Casio Replacement Band, compatible with models WV-59E-1AVW, WV-59J-1AW, WV-59U-1AVW, and WV-59A-1AVW. This band is designed to restore the original fit and function of your Casio watch.

Installation Guide

Proper installation ensures the longevity and secure fit of your new watch band. Please follow these steps carefully.

Tools Required:

- Small spring bar tool or a thin, flat-bladed screwdriver.
- Soft cloth to protect your watch.

Step 1: Removing the Old Band

1. Place your watch face down on a soft cloth to prevent scratches.
2. Locate the spring bars that secure the old band to the watch lugs. These are small, spring-loaded pins at each end of the band.
3. Using the spring bar tool or screwdriver, gently push in one end of the spring bar.
4. While holding the spring bar compressed, carefully pull the band away from the watch lug until the spring bar detaches.
5. Repeat this process for the other end of the band and for the second half of the watch band.
6. Retain the old spring bars if they are in good condition, as some replacement bands may not include new ones.

Step 2: Installing the New Band

Ensure you have the correct orientation for the new band. Typically, the buckle side attaches to the 12

o'clock position of the watch, and the longer strap with holes attaches to the 6 o'clock position.

Image 1: Top view of the Casio WV-59 replacement band, showing the buckle and the strap with adjustment holes.

1. Insert one end of a spring bar into the hole on one of the watch lugs.
2. Compress the other end of the spring bar with your tool.
3. Carefully guide the spring bar into the corresponding hole on the opposite lug. You should hear a small click when it's securely in place.
4. Gently tug on the band to ensure it is firmly attached and does not come loose.
5. Repeat this process for the second half of the watch band.



Image 2: Bottom view of the Casio WV-59 replacement band, highlighting the textured surface and attachment points.

Wearing and Adjustment

Once installed, the band can be adjusted to fit your wrist comfortably using the tang buckle. Select a hole that allows the watch to sit securely without being too tight or too loose, ensuring proper blood circulation and comfort.

Care and Maintenance

To maintain the appearance and extend the life of your resin watch band, follow these simple care instructions:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth to remove dirt, sweat, and oils. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely.
- **Avoid Harsh Chemicals:** Do not expose the band to strong solvents, detergents, or abrasive cleaners, as these can damage the resin material.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight when not in use to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Band does not fit the watch lugs.	Incorrect band size or model compatibility.	Verify the band is compatible with your specific Casio WV-59 series model. Ensure the spring bars are correctly aligned.
Spring bar is difficult to install.	Misalignment or spring bar not fully compressed.	Ensure the spring bar is fully compressed and aligned with both lug holes. Apply gentle, even pressure.
Band feels loose after installation.	Spring bar not fully seated in lug holes.	Gently tug on the band to confirm both ends of the spring bar are securely in place. Reinstall if necessary.

Specifications

Brand: Casio

Model Compatibility: WV-59E-1AVW, WV-59J-1AW, WV-59U-1AVW, WV-59A-1AVW (Model WV-59 series)

Material: Resin

Band Color: Black

Band Width: 24mm

Clasp Type: Tang Buckle (Stainless Steel)

Item Shape: Rectangular (referring to the watch case shape this band is designed for)

Manufacturer: CASIO

Warranty Information

This Casio replacement band is covered by the manufacturer's standard warranty against defects in materials and workmanship. Please refer to your original watch warranty documentation or contact Casio customer support for specific warranty terms and conditions.

Customer Support

For further assistance, technical support, or inquiries regarding your Casio product, please visit the official Casio website or contact their customer service department. Contact information can typically be found on the Casio website or in your original watch manual.