Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCHLEICH 42079

Schleich 42079 Elephant Equipment Figure Instruction Manual

Model: 42079 | Brand: SCHLEICH

1. Introduction

This manual provides essential instructions for the assembly, use, and care of your Schleich 42079 Elephant Equipment Figure. Please read this manual thoroughly before assembly and use to ensure proper handling and to maximize the product's lifespan. This product is designed for children aged 3 years and older.

2. Safety Information

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years due to potential choking hazards.
- **Adult Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Intended Use:** This product is a toy figure and is intended for imaginative play. Do not use for purposes other than its intended design.
- **Material Safety:** Made from plastic. Ensure children do not ingest any parts.

3. Package Contents

The Schleich 42079 Elephant Equipment Figure package includes the following components:

- Elephant equipment structure (main platform)
- Two warrior figures (one with spear, one with bow)
- Various decorative and protective elements (e.g., shields, banners)
- Assembly instructions (this manual)

Total number of pieces: 18

4. Setup and Assembly

Assembly is required for this product. Follow these steps to assemble the Elephant Equipment Figure:

1. Carefully unpack all components from the packaging.

2. Identify the main platform structure and the individual warrior figures.
3. Attach the protective and decorative elements (shields, banners) to the main platform as indicated by the molded slots or connection points. Ensure they are securely fastened.
4. Position the two warrior figures onto the designated areas of the platform. The figures are designed to fit securely.
5. Once assembled, the equipment can be placed onto a compatible Schleich elephant figure (sold separately).



Figure 1: The fully assembled Schleich 42079 Elephant Equipment, showing the main platform and the two warrior figures positioned on it. The equipment is designed to be mounted on a separate elephant figure.

5. Operating Instructions

The Schleich 42079 Elephant Equipment Figure is designed for imaginative play. Once assembled and placed on a compatible elephant figure, it provides a dynamic setup for storytelling and role-playing.

- The two warrior figures are positioned on the equipment, allowing for various play scenarios.
- The elevated position of the warriors on the elephant's back provides a clear view for strategic play.
- The equipment and figures are robust for active play, but gentle handling is recommended to preserve details.

6. Care and Maintenance

To ensure the longevity and appearance of your Schleich Elephant Equipment Figure, follow these simple care instructions:

- **Cleaning:** Wipe the figures and equipment with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the paint and plastic.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation or fading.

- **Handling:** While durable, avoid excessive force or bending of small parts to prevent breakage.

7. Troubleshooting

If you encounter any issues with your Schleich Elephant Equipment Figure, consider the following:

- **Parts not fitting:** Ensure you are attempting to connect the correct parts. Refer to the assembly steps. Do not force parts together.
- **Figures unstable on platform:** Verify that the figures are correctly seated in their designated positions on the equipment.
- **Damage:** If any part is damaged, discontinue use to prevent further injury or damage. Information on spare parts is not available.

8. Product Specifications

Feature	Detail
Model Number	42079
Brand	SCHLEICH
Material	Plastic
Color	Grey (equipment)
Dimensions (L x W x H)	29 x 16.5 x 23 cm
Weight	800 Grams
Number of Pieces	18
Assembly Required	Yes
Recommended Age	3 years and up (36 months minimum)
Batteries Required	No
UPC	792491251244

9. Warranty and Support

For information regarding warranty, product support, or to inquire about replacement parts, please contact Schleich customer service directly. Contact details can typically be found on the official Schleich website or product packaging.
Note: Information regarding the availability of spare parts for this specific model is not provided.

© 2023 SCHLEICH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004GXFQQK

More documents and user manuals: **https://manuals.plus/**