Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Merkury Innovations MEYMW250

Merkury Innovations MEYMW250 3.5mm Vertical Flat Speakers User Manual

Model: MEYMW250

Introduction

Thank you for purchasing the Merkury Innovations MEYMW250 3.5mm Vertical Flat Speakers. These compact and lightweight speakers are designed to provide clear audio from your portable devices without the need for external power.

Product Overview



Figure 1: Merkury Innovations MEYMW250 Vertical Flat Speakers. These speakers feature a minimalist white design with a circular speaker grille on the front. They are designed to stand vertically on a flat surface.

The MEYMW250 speakers are designed for portability and ease of use. Key features include:

- **3.5mm Jack Connectivity:** Compatible with iPod, iPhone, MP3 players, and other devices with a standard 3.5mm audio output.
- **Compact and Lightweight Design:** Easy to carry and set up anywhere.
- **No Batteries Required:** Powered directly by the audio source, eliminating the need for external power or batteries.
- **Frequency Response:** 200 Hz - 12 kHz for clear audio reproduction.
- **Speaker Size:** Equipped with 50mm, 8Ω speakers.

Setup

1. **Unpack the Speakers:** Carefully remove the speakers from their packaging.
2. **Position the Speakers:** Place the speakers on a flat, stable surface. For optimal sound, position them equidistant from your listening position.
3. **Connect to Audio Source:** Locate the 3.5mm audio cable attached to the speakers. Insert the 3.5mm jack into the headphone or audio output port of your device (e.g., smartphone, tablet, MP3 player).

Note: Ensure your audio device's volume is set to a low level before connecting to avoid sudden loud sounds.

Operating Instructions

1. **Power On Your Device:** Turn on your audio source device.
2. **Play Audio:** Start playing music or any audio content on your connected device.
3. **Adjust Volume:** Control the volume directly from your connected audio device. The MEYMW250 speakers do not have independent volume controls.

Since these speakers are passively powered by the audio source, there is no separate power button or indicator light on the speakers themselves.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speakers. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the speakers or subjecting them to strong impacts, as this may damage internal components.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No sound from speakers.	3.5mm jack not fully inserted. Audio device volume too low or muted. Audio device not playing content. Faulty audio cable or speakers.	Ensure the 3.5mm jack is securely plugged into both the speakers and the audio device. Increase the volume on your audio device. Check if the device is muted. Verify that audio content is actively playing on your device. Test the speakers with another audio device or try another 3.5mm cable if possible (though the cable is integrated). If the issue persists, the speakers may be faulty.
Distorted or poor sound quality.	Audio device volume too high. Poor audio source quality. Interference.	Reduce the volume on your audio device. Try playing a different audio file or source to determine if the issue is with the content. Move speakers away from other electronic devices that might cause interference.

Specifications

- **Model:** MEYMW250
- **Brand:** Merkury Innovations
- **Connectivity:** 3.5mm Auxiliary Jack
- **Speaker Size:** 50mm
- **Speaker Impedance:** 8 Ohms (8Ω)
- **Frequency Response:** 200 Hz - 12 kHz
- **Power Source:** Passive (No batteries required, powered by audio source)
- **Color:** White
- **Dimensions (each speaker):** Approximately 2"D x 4"W x 4"H (5.08 cm D x 10.16 cm W x 10.16 cm H)
- **Weight (total):** Approximately 0.5 Pounds (8 ounces / 226.8 grams)
- **UPC:** 844702012004

Warranty and Support

For warranty information or technical support, please contact Merkury Innovations customer service. Details are typically provided on the product packaging or on the official Merkury Innovations website.
Please retain your proof of purchase for any warranty claims.

© 2024 Merkury Innovations. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B005Q09TCE

More documents and user manuals: **https://manuals.plus/**