Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mystim MS46460

Mystim Twisting Tom Electrosex Toy User Manual

Model: MS46460

1. Introduction

The Mystim Twisting Tom is the first ever quattro-polar prostate stimulator made of 100% medical grade platinum silicone. Its innovative design features 4 poles that create two separated stimulation areas: the prostate and the perineum. Thanks to its unique Flex Stay technology, the Twisting Tom can be bent into any desired form, and it will retain this shape during use, allowing for personalized comfort and optimal contact.

Important Safety Warnings:

- Current must never flow through the heart.
- Do not use if you have a pacemaker.
- Do not use if you are pregnant.
- Do not use if you suffer from epilepsy.
- Do not use on any broken or inflamed skin.

Note: The Mystim Twisting Tom is an attachment designed to be used with a compatible electro-stimulation power source, such as the Mystim Tension Lover Kit or Pure Vibes Kit. This product does not include a power source, which must be purchased separately.

2. Product Features

- **Quattro-polar Design:** Features four poles for targeted stimulation of the prostate and perineum.
- **Medical Grade Silicone:** Constructed from 100% medical grade platinum silicone for safety and comfort.
- **Flex Stay Technology:** Allows the user to bend and shape the toy to their preference, maintaining its form during use.
- **Phthalate Free:** Ensures a safe and body-friendly material composition.
- **Latex Free:** Suitable for individuals with latex sensitivities.
- **Waterproof:** Designed for safe use and easy cleaning.
- **Connector Points:** Equipped with two standard 2mm pin connector points on the base for attachment to an electro-stimulation unit.

3. Package Contents

Upon opening your Mystim Twisting Tom package, you should find the following items:

- 1 x Mystim Twisting Tom Electrosex Toy
- 1 x User Manual (this document)

Please note: An electro-stimulation power source (e.g., Mystim Tension Lover Kit or Pure Vibes Kit) and connecting cables are required for operation and are sold separately.



Image: Mystim Twisting Tom product packaging, showing the black silicone toy visible through a clear window.

4. Setup

1. **Initial Cleaning:** Before first use, thoroughly clean the Twisting Tom as described in the Maintenance section.
2. **Connect to Power Source:** Connect the Twisting Tom to a compatible electro-stimulation power source (such as the Mystim Tension Lover Kit or Pure Vibes Kit) using appropriate 2mm pin cables. The Twisting Tom has two connector points located on its base. Ensure the pins are fully inserted and connections are secure.



Image: Angled view of the Mystim Twisting Tom's base, highlighting the two small circular connector points for electro-stimulation cables.

5. Operating Instructions

1. **Apply Conductive Gel:** Apply a generous amount of water-based conductive gel to the entire surface of the Twisting Tom that will be in contact with the body. This is crucial for effective and comfortable electro-stimulation.
2. **Insertion and Positioning:** Carefully insert the Twisting Tom. Utilize the Flex Stay feature to adjust its shape for optimal comfort and to ensure good contact with the prostate and perineum areas.
3. **Start Low:** Ensure your electro-stimulation power source is set to the lowest intensity level before turning it on.
4. **Gradual Intensity Increase:** Slowly and gradually increase the intensity to a comfortable and desired level. Pay close attention to the sensations and adjust as needed. Do not exceed comfortable limits. If any discomfort or pain occurs, immediately reduce the intensity or discontinue use.
5. **Experimentation:** Experiment with different settings and programs on your power source to explore various sensations and find what is most pleasurable for you.



Image: The Mystim Twisting Tom, a black, curved silicone toy designed for electro-stimulation.



Image: A close-up view of the smooth, curved silicone body of the Mystim Twisting Tom.



Image: A top-down perspective of the Mystim Twisting Tom, clearly showing its T-bar shaped base.




Image: The Mystim Twisting Tom positioned next to a ruler, indicating its length and maximum diameter for size reference.

6. Maintenance

Cleaning:

- Clean the Twisting Tom thoroughly after each use.
- Wash with warm water and a mild, toy-safe soap.
- Rinse thoroughly to remove all soap residue.

Drying:

- Allow the toy to air dry completely before storage, or gently pat dry with a lint-free cloth.

Storage:

- Store in a clean, dry, and dust-free environment.
- Keep away from direct sunlight and extreme temperatures.
- Store separately from other toys made of different materials to prevent potential material degradation or reactions.

Material Care:

- The Twisting Tom is made of medical grade platinum silicone. Avoid using silicone-based lubricants or cleaning agents, as these can damage the material.
- Only use water-based lubricants with this product.

7. Troubleshooting

Problem	Possible Cause	Solution
No sensation or weak sensation	• Improper connection to power source. • Power source off or low battery. • Insufficient conductive gel. • Intensity setting too low. • Damaged cables.	• Check that the Twisting Tom is properly connected to the power source. • Ensure the power source is turned on and has sufficient battery life. • Verify that enough water-based conductive gel has been applied. • Increase the intensity setting on the power source gradually. • Inspect connecting cables for any visible damage or loose connections.
Discomfort or pain during use	• Intensity setting too high. • Insufficient lubrication. • Improper positioning or insertion.	• Immediately reduce the intensity setting on your power source. • Ensure proper and ample lubrication with water-based gel. • Re-evaluate insertion depth and angle. Adjust the Flex Stay shape if necessary for better comfort. • Discontinue use if discomfort persists.

Problem	Possible Cause	Solution
Connecting leads do not stay in the toy	• Pins not fully inserted. • Incompatible cable pins. • Wear on connector points.	• Ensure the 2mm pins are fully inserted into the connector points on the Twisting Tom's base. • Verify that your cables have standard 2mm pins compatible with the toy. • If the issue persists, contact Mystim customer support or your retailer.

8. Specifications

- **Model Number:** MS46460
- **Material:** 100% Medical Grade Platinum Silicone
- **Dimensions:**
  - Length: Approximately 130mm (5.11 inches)
  - Diameter: Minimum 25mm (0.98 inch), Maximum 37mm (1.46 inches)
- **Product Dimensions (Packaged):** 5 x 1.46 x 5.1 inches; 4.23 ounces
- **Water Resistance:** Waterproof
- **Power Source:** Requires external electro-stimulation power source (not included)
- **Connectors:** 2 x 2mm pin connectors

9. Warranty and Support

For detailed warranty information, product support, or any inquiries regarding your Mystim Twisting Tom, please refer to the official Mystim website or contact the retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2024 Mystim. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0064P1A1S

More documents and user manuals: **https://manuals.plus/**