Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BNC006WHWH

Braun BNC006WHWH Classic Analog Quartz Wall Clock User Manual

Model: BNC006WHWH

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Braun BNC006WHWH Classic Analog Quartz Wall Clock. Please read this manual thoroughly before using the product to ensure correct usage and to prolong its lifespan.



Image 1: Front view of the Braun BNC006WHWH Classic Analog Quartz Wall Clock. The clock features a white dial with black hour and minute hands, and black hour markers. The Braun logo is visible at the 12 o'clock position.

2. Safety Information

- Ensure the clock is securely mounted on a wall to prevent accidental falls and potential damage or injury.
- Use only the specified battery type (1 AA battery). Incorrect battery types may cause leakage or damage.
- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.

3. Package Contents

Verify that all items are present in the package:

- 1 x Braun BNC006WHWH Classic Analog Quartz Wall Clock
- 1 x AA Battery

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert one (1) AA battery, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

4.2 Mounting the Clock

The Braun BNC006WHWH wall clock is designed for simple wall mounting.

1. Choose a suitable location on a wall where the clock will be visible and securely supported.
2. Install a screw or hook into the wall at the desired height. Ensure the screw/hook is strong enough to hold the clock's weight (approximately 0.18 kg).
3. Align the hanging slot on the back of the clock with the installed screw or hook.
4. Carefully hang the clock, ensuring it is stable and level.

5. Operating Instructions

5.1 Setting the Time

After installing the battery, the clock hands will begin to move. To set the correct time:

1. Locate the time adjustment knob on the back of the clock, usually near the battery compartment.
2. Gently turn the knob in either direction to move the hour and minute hands until the desired time is displayed.
3. Once the time is set, the clock will operate automatically.

6. Maintenance

6.1 Cleaning

To maintain the appearance of your clock:

- Wipe the clock's surface with a soft, dry cloth.
- Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.

6.2 Battery Replacement

When the clock hands stop moving or the time becomes inaccurate, it is time to replace the battery.

- Follow the steps outlined in Section 4.1 "Battery Installation" to replace the AA battery.
- Ensure proper disposal of the old battery.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Clock is not running.	Battery is dead or incorrectly installed.	Check battery polarity or replace with a new AA battery.
Clock shows incorrect time.	Time was not set correctly or battery is low.	Reset the time using the adjustment knob. If issue persists, replace the battery.
Clock makes unusual noise.	Internal mechanism issue.	Contact customer support if the noise is persistent and affects operation.

8. Specifications

Feature	Detail
Brand	Braun
Model Number	BNC006WHWH
Display Type	Analog
Movement Type	Quartz (Quiet German precision)
Power Source	Battery Powered (1 x AA battery)
Material	Plastic (Frame)
Color	White
Item Weight	0.18 Kilograms (180 g)
Dimensions (LxWxH)	20 x 20 x 3.4 Centimeters
Mounting Type	Wall Mount

9. Warranty and Support

For warranty information or technical support regarding your Braun BNC006WHWH Classic Analog Quartz Wall Clock, please refer to the "Contact Seller of Record" as indicated at the point of purchase.
For general inquiries or further assistance, you may visit the official Braun website or contact their customer service department.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B006J14L72

More documents and user manuals: **https://manuals.plus/**