Frigidaire FFAD5033R1

Frigidaire 50-Pint Dehumidifier User Manual

Model: FFAD5033R1 | Brand: Frigidaire

1. Introduction

This manual provides essential information for the safe and efficient operation of your Frigidaire 50-Pint Dehumidifier. Designed to maintain optimal humidity levels in medium-sized rooms, this Energy Star certified appliance features automatic humidity control, continuous draining capability, a full tank alert system, automatic shutoff, and auto defrost. Please read all instructions carefully before use to ensure proper function and to prevent injury or damage.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not operate the dehumidifier with a damaged cord or plug.
- Ensure the unit is placed on a stable, level surface to prevent tipping and water spillage.
- Maintain adequate clearance around the unit (at least 8 inches) for proper airflow.
- Do not use extension cords. Plug the unit directly into a grounded electrical outlet.
- Unplug the dehumidifier before cleaning, servicing, or moving it.
- Do not block air inlets or outlets.
- This appliance contains refrigerant. Servicing should only be performed by qualified personnel.

3. Product Overview and Components

Familiarize yourself with the main parts of your Frigidaire Dehumidifier.



Figure 3.1: Front view of the Frigidaire 50-Pint Dehumidifier. This image displays the overall design of the unit, including the top control panel, the main body, and the lower water bucket section with its visible water level indicator.



Figure 3.2: Close-up of the top control panel. This panel features the digital humidity display, fan speed settings, timer, filter reset button, and power controls, allowing for easy adjustment of the dehumidifier's functions.




Figure 3.3: Detail of the water level indicator on the front of the unit. This transparent window allows users to visually monitor the water accumulation in the collection bucket without needing to remove it.



Figure 3.4: The water collection bucket partially pulled out from the unit. This image demonstrates how the bucket can be easily accessed and removed for manual emptying.



Figure 3.5: The integrated handle on the top of the dehumidifier. This handle provides a convenient way to lift and

move the unit when needed.



Figure 3.6: Close-up of the caster wheels located at the base of the dehumidifier. These wheels enable easy portability and movement of the unit across different surfaces.



Figure 3.7: The power cord neatly wrapped and secured on the back of the dehumidifier. This feature provides convenient storage for the cord when the unit is not in use or being moved.

4. Setup Instructions

Follow these steps for initial setup of your dehumidifier.

1. **Unpacking:** Carefully remove the dehumidifier from its packaging. Retain packaging materials for future storage or transport.
2. **Placement:** Place the unit on a firm, level surface capable of supporting its weight when the water bucket is full. Ensure there is at least 8 inches (20 cm) of space on all sides for proper air circulation. Avoid placing near heat sources or in direct sunlight.
3. **Power Connection:** Plug the power cord directly into a grounded 115V AC, 60Hz electrical outlet. Do not use an extension cord.
4. **Initial Operation:** For the first 3-4 days of operation, it is recommended to run the unit on its factory setting, which typically displays as "CO" (Continuous Operation) on the LED screen. This allows the unit to stabilize and efficiently reduce initial high humidity levels.
5. **Continuous Drain Setup (Optional):** For continuous operation without emptying the bucket, attach a standard garden hose (not included) to the continuous drain outlet located on the side of the unit. Ensure the hose is sloped downwards to allow gravity drainage into a floor drain or suitable receptacle.



Figure 4.1: Connection point for the continuous drain hose. This image shows a standard garden hose attached to the designated outlet on the side of the dehumidifier, enabling continuous water drainage.

5. Operating Instructions

Understand how to use the control panel and various functions of your dehumidifier.

Control Panel Functions

- **On/Off Button:** Press to turn the unit on or off.
- **Humidity Control (∧ / ∨):** Use the up and down arrows to set your desired humidity level between 35% and 85% relative humidity (RH) in 5% increments. The display will show the set humidity for 5 seconds, then revert to showing the current room humidity.
- **Fan Speed Button:** Cycles through fan speeds: High, Medium, and Low. Higher fan speed results in faster moisture removal.
- **Timer Button:** Activates the timer function to set a delayed start or stop time (1-24 hours).
- **Filter Reset Button:** Illuminates after 250 hours of operation to remind you to clean the air filter. Press to reset the indicator after cleaning.

Indicators

- **Humidity % Display:** Shows the current room humidity or the set humidity level.
- **Lock Indicator:** Illuminates when control panel is locked (press and hold Timer for 3 seconds).
- **Fan Speed Indicators (Hi, Med, Low):** Show the currently selected fan speed.
- **Bucket Full Indicator:** Illuminates and the unit beeps when the water collection bucket is full or incorrectly installed. The unit will automatically shut off.
- **Clean Filter Indicator:** Illuminates after 250 hours of operation.
- **Power Indicator:** Illuminates when the unit is powered on.

Special Features

- **Auto Shutoff:** The unit automatically turns off when the desired humidity level is reached or the water bucket is full. It will restart when humidity rises or the bucket is emptied.
- **Auto Defrost:** If frost builds up on the evaporator coils, the compressor will cycle off and the fan will continue to run until the frost disappears. This is normal operation.

- **Continuous Operation (CO):** To run the unit continuously regardless of humidity level, set the humidity to the lowest possible setting (e.g., 35%) or use the continuous drain option.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your dehumidifier.

Emptying the Water Bucket

When the bucket is full, the unit will beep, the "Bucket Full" indicator will light up, and the unit will stop operating. Carefully remove the bucket by pulling it straight out. Empty the water and slide the bucket back into the unit until it clicks into place. Ensure the bucket is properly seated to resume operation.

Cleaning the Air Filter

The air filter should be cleaned approximately every 250 hours of operation, or more frequently depending on air quality. A dirty filter reduces efficiency and can cause the unit to malfunction.

1. Turn off the dehumidifier and unplug it.
2. Locate the air filter behind the front grille (refer to product diagram if needed).
3. Gently slide out the filter.
4. Wash the filter with warm, soapy water. Rinse thoroughly.
5. Allow the filter to air dry completely before reinserting. Do not use a dishwasher.
6. Slide the dry filter back into its slot.
7. Plug in the unit and press the "Filter Reset" button on the control panel.

Cleaning the Unit Exterior

Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals, abrasives, or solvents.

Storage

If storing the unit for an extended period, ensure the water bucket is empty and clean. Clean the air filter. Wrap the power cord neatly using the integrated cord storage on the back of the unit. Store in a cool, dry place, preferably in its original packaging.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Dehumidifier does not operate.	Unit unplugged; power outage; bucket full or not properly seated; desired humidity level reached.	Ensure unit is plugged in; check circuit breaker; empty and re-seat bucket; lower desired humidity setting.
Unit runs but does not dehumidify.	Air filter clogged; temperature too low (below 41°F/5°C); air inlet/outlet blocked; room size too large.	Clean air filter; ensure room temperature is within operating range; clear obstructions; consider a larger capacity unit for the space.
"F0" error code displayed.	This code often indicates a sensor error or a need for a system reset.	Unplug the unit for 10-15 minutes, then plug it back in. If the error persists, contact customer support.

Problem	Possible Cause	Solution
Water leaks from the unit.	Water bucket not properly seated; continuous drain hose not connected correctly or sloped.	Ensure bucket is fully pushed in; check continuous drain hose connection and ensure proper downward slope.
Unit is noisy.	Normal fan operation; unit not on a level surface; internal component issue.	Ensure unit is on a level surface. Some fan noise is normal. If noise is excessive or new, contact customer support.

8. Specifications

Technical details for the Frigidaire 50-Pint Dehumidifier.

Feature	Detail
Brand	Frigidaire
Model Name	FFAD5033R1
Dehumidification Capacity	50 Pints per Day
Recommended Floor Area	Up to 500 Square Feet
Product Dimensions (WxDxH)	11.6 x 15 x 24.4 inches
Item Weight	46 Pounds
Material	Plastic
Operation Mode	Continuous
Special Features	Automatic Defrost, Automatic Shutoff, Full Tank Alert, Continuous Drain Option
Energy Star Certified	Yes

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Frigidaire website. You may also visit the Frigidaire Store on Amazon for additional resources and contact details.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question