Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

2wire 2701HG-B

2wire 2701HG-B Router User Manual

Model: 2701HG-B

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your 2wire 2701HG-B Router. Please read this guide thoroughly before setting up your device to ensure proper functionality and optimal performance. The 2701HG-B is designed to provide reliable internet connectivity and network services for your home or small office environment.

Setup

1. Unpacking the Router

Carefully remove all components from the packaging. Ensure the following items are present:

- 2wire 2701HG-B Router
- Power Adapter
- Ethernet Cable
- DSL/Phone Cable (if applicable)

2. Connecting the Router

1. **Power Connection:** Connect the power adapter to the router's power port and then plug it into an electrical outlet. The power indicator light should illuminate.
2. **Internet Connection:**
    - For DSL connections: Connect one end of the DSL/phone cable to the DSL port on the router and the other end to your wall DSL jack.
    - For Ethernet WAN connections: Connect one end of an Ethernet cable to the WAN/Internet port on the router and the other end to your modem or network jack.
3. **Local Network Connection (Optional):**
    - **Wired:** Connect one end of an Ethernet cable to any of the LAN ports (usually labeled 1-4) on the router and the other end to your computer's Ethernet port.
    - **Wireless:** You can connect wirelessly after the initial setup.

3. Initial Configuration

After connecting the hardware, allow a few minutes for the router to boot up. The indicator lights will show its status.

1. Open a web browser (e.g., Chrome, Firefox, Edge) on a computer connected to the router.
2. In the address bar, type the default IP address of the router (commonly192.168.1.254 or 192.168.1.1) and press Enter. Refer to the label on the bottom of your router for the exact IP address and default login credentials.
3. Follow the on-screen instructions of the setup wizard to configure your internet connection, Wi-Fi network name (SSID), and password.

Operating the Router

1. Understanding Indicator Lights

The front panel of the 2701HG-B router features several LED indicators that provide information about its operational status:

- **Power:** Solid green indicates the router is powered on.
- **DSL/WAN:** Solid green indicates a stable internet connection. Blinking indicates connection activity.
- **Ethernet (LAN 1-4):** Solid green indicates a device is connected to that port. Blinking indicates data transfer.
- **Wireless:** Solid green indicates the Wi-Fi network is active. Blinking indicates wireless data transfer.

2. Connecting Devices

- **Wired Devices:** Connect an Ethernet cable from your device (e.g., PC, game console) to any available LAN port on the router.
- **Wireless Devices:**
    1. On your wireless device (e.g., smartphone, laptop), search for available Wi-Fi networks.
    2. Select your router's SSID (network name) from the list.
    3. Enter the Wi-Fi password (security key) you configured during setup.

3. Using WPS (Wi-Fi Protected Setup)

The 2701HG-B supports WPS for easy connection of compatible wireless devices without entering the password manually.

1. Press the WPS button on your router (refer to the router's physical layout for exact location).
2. Within two minutes, activate WPS on your wireless device. The device should automatically connect to the network.

Maintenance

1. Firmware Updates

Periodically check the 2wire support website for available firmware updates. Firmware updates can improve performance, add new features, and enhance security. Follow the instructions provided on the website for updating your router's firmware.

2. Resetting the Router

If you encounter persistent issues or forget your login credentials, you may need to reset the router to its factory default settings. This will erase all custom configurations.

- With the router powered on, use a paperclip or a similar pointed object to press and hold the reset button (usually located in a small pinhole on the back or bottom) for about 10-15 seconds.
- Release the button. The router will restart with factory default settings. You will need to reconfigure your internet and Wi-Fi settings.

3. Cleaning

Keep the router in a clean, dust-free environment. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or

aerosols.

Troubleshooting

No Internet Connection

- Check all cable connections (power, DSL/WAN, Ethernet).
- Verify the DSL/WAN indicator light is solid green. If not, contact your Internet Service Provider (ISP).
- Restart the modem (if separate) and then the router by unplugging them from power for 30 seconds and plugging them back in.
- Ensure your ISP account is active and there are no service outages.

Slow Wi-Fi or Intermittent Connection

- Move the router to a central location, away from obstructions and interference sources (e.g., cordless phones, microwaves).
- Ensure your router's firmware is up to date.
- Try changing the Wi-Fi channel in the router's settings to avoid interference from neighboring networks.
- Reduce the number of devices connected to the network or limit bandwidth-intensive activities.

Cannot Access Router Interface

- Ensure your computer is connected to the router via Ethernet or Wi-Fi.
- Verify you are using the correct IP address (e.g., 192.168.1.254).
- Clear your browser's cache and cookies, or try a different browser.
- If you forgot the login password, perform a factory reset as described in the Maintenance section.

Specifications

Feature	Detail
Brand	2wire
Model Name	2701HG-B
Special Feature	WPS
Frequency Band Class	Dual-Band
Wireless Communication Standard	802.11bgn
Compatible Devices	Personal Computer
Recommended Uses For Product	Home
Connectivity Technology	Ethernet, Wi-Fi
Security Protocol	WPA2-PSK, WPA2-Enterprise
Voltage	100 volts
Antenna Location	Internal
Controller Type	Switch

Warranty and Support

For detailed warranty information and technical support, please refer to the official 2wire website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.
Official 2wire support resources can typically be found by searching for "2wire support" or visiting the manufacturer's main website.

© 2023 2wire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007CD8T4M

More documents and user manuals: **https://manuals.plus/**