Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Parlux 3800

Parlux Eco Friendly 3800 Professional Hair Dryer Instruction Manual

Introduction

This manual provides essential information for the safe and effective use of your Parlux Eco Friendly 3800 Professional Hair Dryer. The Parlux 3800 Hair Dryer is designed for professional use, featuring a sophisticated built-in silencer to reduce noise during operation. It incorporates an IONIC & CERAMIC system, which contributes to hair shine and softness. This product is manufactured with recyclable materials and is designed to be ozone-friendly.



Image: The Parlux Eco Friendly 3800 Professional Hair Dryer, showcasing its design and 'Ionic & Ceramic Eco Friendly' branding.

Safety Information

Always unplug the hair dryer when not in use. Do not use the hair dryer while bathing or near water. Keep the hair dryer away from heated surfaces. Allow the hair dryer to cool down before storing. Do not use the hair dryer if the cord is damaged or if it emits an unusual smell or sound. Keep the hair dryer out of reach of children and pets.

Setup

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Inspect the unit for any signs of damage.
2. **Power Connection:** Ensure your power outlet matches the voltage requirements of the hair dryer (240 Volts). Plug the power cord into a suitable electrical outlet.
3. **Attaching Concentrator Nozzles:** The hair dryer comes with two concentrator nozzles. Select the desired nozzle

and firmly attach it to the front of the dryer.



Image: The Parlux Eco Friendly 3800 Hair Dryer with a concentrator nozzle attached, ready for use.

Operating Instructions

The Parlux 3800 Hair Dryer is equipped with controls for speed and temperature, along with a cold shot button for versatile styling.

Controls:

- **Speed Settings:** The dryer features 2 speed settings. Use the switch on the handle to select between low and high airflow.
- **Temperature Settings:** There are 4 temperature settings available. Adjust the temperature switch to achieve the desired heat level.
- **Cold Shot Button:** Press and hold the cold shot button to deliver a burst of cool air, ideal for setting hairstyles.

Usage:

After shampooing and conditioning, gently towel-dry your hair to remove excess water. Plug in the hair dryer and select your desired speed and temperature settings. Direct the airflow towards your hair, moving the dryer continuously to prevent heat concentration in one area. Use the cold shot button to finish your style and add shine.

▶ **Watch video online**
Efficient Hair Drying, No Damage, Smooth Styleea

Video: Demonstration of efficient hair drying techniques using a professional hair dryer, focusing on achieving smooth styles without damage.

Maintenance

- **Cleaning the Air Filter:** Regularly check and clean the rear air filter to ensure optimal performance and prevent overheating. Unplug the dryer, remove the filter cover, and gently brush away any accumulated dust or hair.
- **Cord Care:** Do not wrap the power cord tightly around the dryer, as this can damage the cord. Store the cord loosely.
- **Storage:** Allow the hair dryer to cool completely before storing it in a dry, safe place.

Troubleshooting

- **No Power:** Ensure the hair dryer is securely plugged into a functional electrical outlet. Check your circuit breaker.
- **Low Airflow:** Clean the air filter at the back of the dryer. A clogged filter can restrict airflow.
- **Overheating:** If the dryer shuts off unexpectedly, it may be due to overheating. Unplug it, clean the air filter, and allow it to cool down for at least 10-15 minutes before resuming use.
- **Unusual Noise or Smell:** Discontinue use immediately and unplug the dryer. Contact customer support for assistance.

Specifications

Feature	Detail
Brand	Parlux
Model Name	Parlux 3800
Wattage	2100 watts
Power Source	Corded Electric
Voltage	240 Volts
Number of Speeds	2
Number of Temperature Settings	4
Special Features	Eco Friendly, Recyclable, Ionic & Ceramic System, Low Noise Built-in Silencer
Material Type	Ceramic
Dimensions (L x W x H)	3.75 x 7.75 x 9.75 inches

Feature	Detail
Item Weight	2 Pounds



Image: A diagram illustrating the dimensions of the Parlux Eco Friendly 3800 Hair Dryer, showing a length of approximately 11 inches (27 cm).



Image: Product packaging for the Parlux 3800 Eco Friendly hair dryer, displaying key specifications and features in English.

Warranty and Support

For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Parlux website. For technical support, replacement parts, or service inquiries, please contact Parlux customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007VCFVWC

More documents and user manuals: **https://manuals.plus/**