Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome IMAC-K121S

iHome Full Size Mac Keyboard (Wired 2019 Version) Instruction Manual

Model: IMAC-K121S

1. Overview

The iHome Full Size Mac Keyboard is designed for seamless integration with various computer systems, including Apple Mac (macOS, iOS) and Windows Desktop/Laptop PCs. This wired keyboard offers a plug-and-play experience, eliminating the need for complex syncing procedures. Its full-size layout, including a dedicated numeric keypad, enhances productivity for tasks such as spreadsheets and financial applications. The keyboard features an ultra-slim design with an anodized aluminum finish and low-profile keys, providing a comfortable and efficient typing experience.



Figure 1: iHome Full Size Mac Keyboard, top-down view.

2. Setup

2.1 Connecting the Keyboard

1. Locate an available USB port on your computer (Mac or PC).
2. Plug the USB cable of the iHome Full Size Mac Keyboard into the USB port.
3. The keyboard is a plug-and-play device and should be recognized automatically by your operating system without requiring additional drivers or syncing.



Figure 2: Keyboard in use, connected to a computer.

3. Operating Instructions

3.1 Basic Usage

- **Typing:** Use the standard QWERTY layout for text input.
- **Numeric Keypad:** The integrated full numeric keypad is ideal for data entry, calculations, and navigating spreadsheets.
- **Function Keys:** The top row of keys (F1-F12) provides various functions, which may vary slightly depending on your operating system and specific application.

3.2 Compatibility

This keyboard is compatible with computers running Apple macOS (including iMac) and Microsoft Windows operating systems. Standard keyboard functions will operate across both platforms. Specific multimedia or system control keys may behave differently or require operating system configuration depending on the platform.




Figure 3: Detail of the integrated numeric keypad.

4. Maintenance

4.1 Cleaning

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keys and surface.
- Avoid excessive moisture and do not spray cleaners directly onto the keyboard.

- For debris between keys, use compressed air to dislodge particles.

5. Troubleshooting

5.1 Keyboard Not Responding

- Ensure the USB cable is securely plugged into a working USB port on your computer.
- Try plugging the keyboard into a different USB port.
- Restart your computer.
- If using a USB hub, try connecting the keyboard directly to the computer.

5.2 Incorrect Key Functions

- Verify that your operating system settings for keyboard layout are correct (e.g., US English).
- Some function keys may require specific software or operating system support. Consult your computer's documentation for details.

6. Specifications

Feature	Detail
Brand	iHome
Model Number	IMAC-K121S
Connectivity Technology	USB (Wired)
Operating System Compatibility	iOS, Mac, Windows
Keyboard Description	Full Size, 110-key with Numeric Keypad
Material	Aluminum (Anodized Finish)
Item Weight	1.9 pounds
Product Dimensions (LxWxH)	19.2 x 6.5 x 1.8 inches
Included Components	Keyboard



Figure 4: Ultra-slim design of the keyboard.

7. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product at the time of purchase or visit the official iHome support website. Keep your proof of purchase for warranty claims.

© 2023 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007X3VEBG

More documents and user manuals: **https://manuals.plus/**