Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome IMAC-K111S

iHome Bluetooth Keyboard User Manual

Model: IMAC-K111S

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your iHome Bluetooth Keyboard (IMAC-K111S). Designed for wireless connectivity, this keyboard utilizes Bluetooth 3.0 technology and features a built-in rechargeable lithium-ion battery for extended use. Please read this manual thoroughly before using your keyboard to ensure optimal performance and longevity.



Image: The iHome Bluetooth Keyboard, featuring a sleek silver base and white keys, viewed from an angle.

Setup

1. Charging the Keyboard

Your iHome Bluetooth Keyboard comes with a built-in rechargeable lithium-ion battery. Before first use, fully charge the keyboard. Connect the provided charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off or change color when fully charged.

2. Pairing with Your Device

1. Ensure the keyboard is sufficiently charged.
2. Turn on the keyboard by sliding the power switch, usually located on the side or back of the keyboard. An indicator light may flash to show it's in pairing mode or ready to pair.
3. On your device (PC, Tablet, Smartphone), navigate to the Bluetooth settings.
4. Enable Bluetooth on your device if it's not already enabled.
5. Search for available Bluetooth devices. The keyboard should appear in the list, typically named "iHome Keyboard" or similar.
6. Select the keyboard from the list. Your device may prompt you to enter a pairing code displayed on your screen using the iHome keyboard, then press Enter.
7. Once successfully paired, the keyboard's indicator light will typically stop flashing and remain solid, or turn off, indicating a successful connection.

Note: The pairing process may vary slightly depending on your device's operating system (e.g., macOS, Windows, Android, iOS).

Operating Instructions

Basic Usage

Once paired, the iHome Bluetooth Keyboard functions like a standard keyboard. Simply begin typing. The keyboard is designed for comfortable and efficient input.

Power Saving Mode

To conserve battery life, the keyboard may enter a sleep mode after a period of inactivity. To wake it up, simply press any key. It will automatically reconnect to your paired device.

Function Keys

The keyboard includes function keys (F1-F12) which may have secondary functions accessible by pressing the**Fn** key simultaneously. These functions typically control media playback, volume, screen brightness, and other system features. Refer to your device's operating system documentation for specific function key behavior.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the keyboard. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid getting moisture into any openings.
- **Storage:** When not in use for extended periods, turn off the keyboard to preserve battery life. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maximize the lifespan of the built-in rechargeable battery, avoid fully discharging it frequently. Recharge the keyboard when the battery low indicator (if present) illuminates.

Troubleshooting

Problem	Possible Solution
Keyboard does not turn on.	Ensure the power switch is in the "ON" position. Charge the keyboard fully.

Problem	Possible Solution
Keyboard does not pair with device.	• Ensure Bluetooth is enabled on your device. • Make sure the keyboard is in pairing mode (refer to Setup section). • Move the keyboard closer to your device. • Forget the keyboard from your device's Bluetooth list and try pairing again. • Restart both the keyboard and your device.
Keyboard disconnects frequently.	• Ensure the keyboard is within the effective Bluetooth range (typically up to 10 meters/33 feet). • Check for interference from other wireless devices. • Ensure the keyboard is sufficiently charged. • Update your device's Bluetooth drivers if applicable.
Keys are not responding.	• Ensure the keyboard is connected and not in sleep mode. Press any key to wake it. • Re-pair the keyboard with your device. • Check for physical obstructions under the keys.

Specifications

- **Model:** IMAC-K111S
- **Connectivity:** Bluetooth 3.0
- **Power Source:** Built-in Rechargeable Lithium-ion Battery
- **Dimensions (LxWxH):** Approximately 14 x 4.5 x 0.5 inches
- **Weight:** Approximately 2.4 ounces
- **Color:** Silver
- **Compatible Devices:** PC, Tablet, Smartphone (including devices running macOS)

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official iHome website. Keep your proof of purchase for warranty claims.
Online Support: www.ihome.com/support

© 2024 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007X3VEC0

More documents and user manuals: **https://manuals.plus/**