DURACELL MN1500 (LR6)

Duracell AA Alkaline Batteries (2-Pack) MN1500 (LR6) User Manual

Brand: DURACELL | Model: MN1500 (LR6)

Introduction

This manual provides essential information for the safe and effective use of your Duracell AA Alkaline Batteries. These all-purpose batteries are designed for general use in a wide range of electronic devices.



Image: Duracell AA Alkaline Batteries, shown in a 2-pack blister card packaging.

Product Features

- Conveniently packaged in a card of 2 batteries.
- Genuine Duracell alkaline chemistry for reliable power.
- Fresh dated with a long shelf life for extended storage.

Setup and Installation

To install your Duracell AA Alkaline Batteries:

1. Locate the battery compartment on your electronic device.

2. Open the battery compartment cover.
3. Insert the Duracell AA batteries, ensuring correct polarity (+ and - ends) as indicated inside the device's battery compartment. Incorrect insertion can prevent the device from functioning or cause damage.
4. Close the battery compartment cover securely.

Operating Instructions

Once installed, your Duracell AA Alkaline Batteries will power your compatible electronic devices. Refer to your device's instruction manual for specific operating procedures. The batteries are designed to provide consistent power for devices such as cameras, clocks, and TV remotes.

Maintenance and Storage

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at room temperature. Avoid extreme temperatures.
- **Replacement:** Replace all batteries in a device at the same time. Do not mix old and new batteries, or different types of batteries.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in fire, as they may explode or leak.
- **Cleaning:** If battery terminals become dirty, clean them with a dry cloth before insertion.

Troubleshooting

If your device is not powering on after installing new batteries:

- Verify that the batteries are inserted with the correct polarity (+ and -).
- Ensure the battery compartment cover is fully closed.
- Check if the device itself is functioning correctly with other known good batteries.
- If the batteries are old or have been stored for a long time, they may have lost charge. Replace them with fresh batteries.

Specifications

Specification	Detail
Battery Type	AA Alkaline
Model Number	MN1500 (LR6)
Voltage	1.5 Volts
Cell Composition	Alkaline
Item Weight	1.06 ounces (per battery)
Date First Available	August 6, 2012
Recommended Uses	Camera, Clock, TV Remote

Warranty and Support

Duracell AA Alkaline Batteries are guaranteed for 10 years in storage. For specific warranty claims or product support, please refer to the contact information provided on the product packaging or visit the official Duracell website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question