Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic BF-AF10B-P/A

Panasonic BF-AF10B-P/A Hand Free LED Neck Light User Manual

Model: BF-AF10B-P/A

Introduction

The Panasonic Hand Free LED Neck Light is designed to provide convenient illumination, allowing you to keep your hands free for various activities. Its lightweight and flexible design makes it suitable for use in diverse situations, from outdoor activities to emergency lighting.
This manual provides essential information on the proper use, setup, and maintenance of your LED neck light to ensure optimal performance and longevity.

Safety Information

Please read all safety instructions before using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Battery Safety:** Do not mix different battery types or dispose of old batteries with new ones. Do not expose batteries to heat or fire. Keep batteries out of reach of children. If swallowed, contact a physician immediately.
- **Choking Hazard:** The silicone closure is designed to pop apart if grabbed, acting as a safety feature. However, small parts may still pose a choking hazard for young children.
- **Water Resistance:** The device is water-resistant, not waterproof. Avoid submerging it in water.
- **Light Source:** Do not stare directly into the LED light, as it may cause eye discomfort.
- **Disposal:** Dispose of the product and batteries according to local regulations. Do not dispose of with household waste.

Package Contents

Verify that all items are present in the package:

- Panasonic Hand Free LED Neck Light (Pink)
- 2 x Lithium Polymer CR2032 Batteries (pre-installed or included separately)

Product Overview

The Panasonic Hand Free LED Neck Light is a compact and flexible lighting solution designed for convenience. It features a soft, flexible neckband that rests comfortably around your neck, directing light forward to illuminate your path or workspace.



Image: The Panasonic BF-AF10B-P/A Hand Free LED Neck Light, showcasing its flexible pink neckband and integrated LED light unit.

Key features include:

- Hands-free design for convenience.
- Up to 13 lumens of LED light output.

- Approximately 15 hours of continuous light from Panasonic battery technology.
- Water-resistant construction for use in various weather conditions.
- 45-degree wide-angle beam for broad illumination.
- Lightweight and flexible silicone neckband.

Setup: Battery Installation

The device uses two CR2032 lithium coin batteries. Follow these steps to install or replace batteries:

1. **Remove the Light Unit:** Gently pull the light unit out of the silicone neckband. It is designed to be removable for battery access.



Image: Step 1 of battery replacement, illustrating the removal of the front LED cover and the light unit from the neckband.

2. **Open Battery Compartment:** Once the light unit is removed, locate the battery cover. Push to open the battery compartment.



Image: Step 2 of battery replacement, showing how to push to open the battery cover on the light unit.

3. **Insert Batteries:** Insert two CR2032 lithium coin batteries with the positive (+) side facing up, following the polarity markings inside the compartment.



Image: Step 3 of battery replacement, detailing the correct orientation for inserting two CR2032 batteries.

4. **Close and Reassemble:** Close the battery compartment cover securely. Then, slide the light unit back into the silicone neckband until it is firmly seated.

Operating Instructions

To use your Panasonic Hand Free LED Neck Light:

1. **Wear the Light:** Place the flexible neckband around your neck. The light unit should rest comfortably on your chest, directing light forward.



Image: Illustration of the neck light being worn, demonstrating its hands-free application.

2. **Turn On/Off:** Locate the power switch on the light unit. Press the switch to turn the LED light ON. Press it again to turn the light OFF. The device features 2-way switching.



Image: Close-up of the light unit indicating the position of the ON/OFF switch.

Maintenance

Proper maintenance ensures the longevity of your neck light.

- **Cleaning:** Wipe the neck light with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the light unit is dry before storage.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

- **Battery Replacement:** Replace batteries when the light appears dim or stops functioning. Refer to the "Setup: Battery Installation" section for instructions.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Dead or incorrectly installed batteries.	Replace batteries, ensuring correct polarity. Refer to "Setup: Battery Installation".
Light is dim.	Low battery power.	Replace batteries.
Light unit falls out of neckband.	Not fully seated or excessive force applied.	Ensure the light unit is pushed firmly into the neckband. Avoid pulling on the light unit while wearing.

Specifications

Feature	Detail
Model Number	BF-AF10B-P/A
Brand	Panasonic
Light Source Type	LED
White Brightness	13 Lumens
Power Source	Battery Powered
Battery Type	2 x CR2032 Lithium Coin Batteries
Battery Life	Up to 15 hours (continuous)
Material	Plastic, Silicone
Color	Pink
Water Resistance Level	Water Resistant
Product Dimensions	15"D x 1"W x 1"H (approximate)
Item Weight	0.17 Pounds (approx. 2.72 ounces)
Special Feature	2-way switching

Warranty and Support

This product is guaranteed to be free from defects in materials and workmanship. For warranty claims or technical support, please contact Panasonic directly.
Manufacturer: Panasonic Energy Corporation
Website: www.panasonic.com
Please retain your purchase receipt as proof of purchase for warranty purposes.

© 2024 Panasonic Energy Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009KY5PGG

More documents and user manuals: **https://manuals.plus/**