Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic T44288

Panasonic CR-P2 Photo Lithium Battery Instruction Manual

Model: T44288

Introduction

This manual provides essential instructions for the safe and effective use of your Panasonic CR-P2 Photo Lithium Battery. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

Observe the following safety precautions to prevent injury or damage to the battery and connected devices:

- Do not recharge, disassemble, heat, or dispose of in fire.
- Do not short-circuit the battery terminals.
- Keep out of reach of children.
- Insert the battery with correct polarity (+ and -).
- If battery fluid leaks and gets into eyes, rinse immediately with water and seek medical attention.
- Store in a cool, dry place away from direct sunlight.

Setup

The Panasonic CR-P2 battery is designed for use in compatible cameras and other electronic devices requiring a CR-P2 type lithium battery.

1. **Unpack the Battery:** Carefully remove the battery from its retail packaging.
2. **Identify Polarity:** Locate the positive (+) and negative (-) terminals on the battery and within your device's battery compartment.
3. **Insert Battery:** Align the battery according to the polarity markings and insert it firmly into the device's battery compartment. Ensure a secure fit.
4. **Close Compartment:** Close the battery compartment door securely.



Image: Panasonic CR-P2 Photo Lithium Battery in its retail packaging. This shows the battery as it would appear when first purchased, ready for installation.

Operating

Once installed, the Panasonic CR-P2 battery will power your compatible device. No specific operational steps are required for the battery itself beyond proper installation.

- Ensure your device is turned off before installing or removing the battery.
- Refer to your device's instruction manual for specific operating procedures related to battery usage and power management.
- Replace the battery when your device indicates low power or ceases to function.

Maintenance

Proper maintenance ensures optimal performance and longevity of your battery.

- **Storage:** Store unused batteries in their original packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cleaning:** If battery terminals become dirty, gently wipe them with a clean, dry cloth. Do not use liquids or abrasive materials.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of with household waste.

Troubleshooting

If your device is not powering on or functioning correctly after battery installation, consider the following:

- **Incorrect Installation:** Remove the battery and re-insert it, ensuring correct polarity (+ and -).
- **Depleted Battery:** If the battery has been stored for a long time or previously used, it might be depleted. Replace with a new battery.
- **Device Issue:** If the problem persists with a new, correctly installed battery, the issue may lie with the device itself. Refer

to your device's manual or contact its manufacturer.

- **Terminal Contact:** Ensure the battery terminals and device contacts are clean and free from obstruction.

Specifications

Feature	Detail
Battery Type	CR-P2 Photo Lithium Battery
Brand	Panasonic
Model Number	T44288
Battery Cell Composition	Lithium
Voltage	6 Volts
Item Weight	0.7 ounces
Recommended Uses	Camera
Number of Batteries	1 CR2 battery required (included)

Warranty and Support

Information regarding product warranty and customer support is not provided within this document. Please refer to the product packaging or the manufacturer's official website for details on warranty coverage and support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00B4YGATG

More documents and user manuals: **https://manuals.plus/**