Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SHIMANO FD-A073

Shimano FD-A073 Front Derailleur User Manual

Model: FD-A073 | Brand: SHIMANO

1. Introduction

This manual provides essential information for the installation, operation, and maintenance of your Shimano FD-A073 Front Derailleur. Designed for triple chainring setups, this derailleur offers reliable shifting performance for 7-speed drivetrains.
Key features include:

- Triple Front Derailleur (3 x 7, For 21-speed bikes)
- Light operation and smooth shifting
- Multi clamp band for quick assembly
- Bottom Pull Only, Down Swing design
- Compatible with up to 50T chainring

2. Setup and Installation

Proper installation is crucial for optimal performance. It is recommended that installation be performed by a qualified bicycle mechanic.

2.1. Pre-Installation Check

- Ensure your bicycle frame is compatible with band-type front derailleurs.
- Verify the correct clamp size for your seat tube: 34.9mm (with included adapters for 31.8mm and 28.6mm).
- Confirm your bike uses a bottom-pull cable routing system.
- This derailleur is designed for triple chainrings with a maximum large chainring size of 50 teeth.

2.2. Installation Steps

1. **Chain Removal:** The design of this derailleur requires the bicycle chain to be broken and removed for installation. Use a chain tool to carefully remove the chain.
2. **Mounting the Derailleur:** Open the derailleur clamp and position it on the seat tube, ensuring the outer cage plate is parallel to the large chainring. The bottom of the outer cage should be approximately 1-3mm above the teeth of the largest chainring. Use the appropriate adapter for your seat tube diameter (28.6mm, 31.8mm, or 34.9mm).
3. **Tightening the Clamp:** Securely tighten the clamp bolt. Do not overtighten.

4. **Cable Routing:** Route the derailleur cable from the bottom bracket area to the cable fixing bolt on the derailleur. Ensure the cable is free of kinks and excessive friction.
5. **Cable Tensioning:** Pull the cable taut and secure it with the cable fixing bolt. Note that this derailleur does not feature an integrated barrel adjuster for fine-tuning cable tension. An inline barrel adjuster may be necessary for precise adjustments.
6. **Chain Re-installation:** Reinstall the chain using a master link or by re-pinning it with a chain tool.
7. **Limit Screw Adjustment:** Adjust the High (H) and Low (L) limit screws to prevent the chain from overshifting off the chainrings. The H-screw controls the outward movement (large chainring), and the L-screw controls the inward movement (small chainring).



Figure 1: Front view of the Shimano FD-A073 Front Derailleur. This image shows the overall design, including the cage and mounting clamp area.



Figure 2: Angled view of the Shimano FD-A073 Front Derailleur. This perspective highlights the "Tourney" branding and the "7 SPEED" indicator on the cage.

3. Operating Instructions

The Shimano FD-A073 Front Derailleur is designed for smooth and reliable shifting across your triple chainring setup. It works in conjunction with compatible 7-speed front shifters.

3.1. Shifting Gears

- To shift to a larger chainring (e.g., from small to middle, or middle to large), push the shifter lever to increase cable tension.
- To shift to a smaller chainring (e.g., from large to middle, or middle to small), release the shifter lever to decrease cable tension, allowing the derailleur spring to move the cage inward.
- Always shift while pedaling forward with moderate pressure. Avoid shifting under heavy load or while stationary.

3.2. Gear Combinations

While the derailleur allows for a wide range of gear combinations, avoid extreme cross-chaining (e.g., large front chainring with largest rear cog, or small front chainring with smallest rear cog) as this can lead to increased wear, noise, and reduced shifting efficiency.

4. Maintenance

Regular maintenance will prolong the life and ensure the smooth operation of your front derailleur.

- **Cleaning:** Periodically clean the derailleur cage and pivot points to remove dirt and grime. Use a degreaser specifically designed for bicycle components.
- **Lubrication:** After cleaning, apply a small amount of bicycle-specific lubricant to the pivot points of the derailleur. Avoid over-lubricating, as this can attract more dirt.
- **Cable Inspection:** Check the derailleur cable for fraying, rust, or excessive friction. Replace the cable if any damage is observed.
- **Limit Screw Check:** Occasionally verify that the limit screws are still correctly set to prevent overshifting.
- **General Inspection:** Inspect the derailleur for any signs of damage, bends, or loose bolts. Address any issues promptly.

5. Troubleshooting

This section addresses common issues you might encounter with your front derailleur.

Problem	Possible Cause	Solution
Derailleur does not shift to the largest chainring.	H-limit screw is too tight; insufficient cable tension; bent derailleur cage.	Loosen the H-limit screw slightly. Increase cable tension (may require an inline barrel adjuster). Inspect and straighten or replace bent cage.
Derailleur does not shift to the smallest chainring.	L-limit screw is too tight; excessive cable tension.	Loosen the L-limit screw slightly. Decrease cable tension.
Chain rubs against the derailleur cage.	Incorrect limit screw adjustment; improper derailleur height or angle; cross-chaining.	Fine-tune H and L limit screws. Re-adjust derailleur height and angle. Avoid extreme cross-chaining.
Shifting feels stiff or difficult.	Friction in cable housing; dirty/unlubricated pivot points; stiff derailleur spring.	Lubricate cable and housing. Clean and lubricate derailleur pivot points. If spring is excessively stiff, professional inspection is recommended.

6. Specifications

Specification	Detail
Model Number	FD-A073 (Part No. EFDA073X3)
Mounting Type	Clamp-On Mount
Clamp Sizes	34.9mm (with adapters for 31.8mm & 28.6mm)
Cable Pull	Bottom Pull
Derailleur Style	Down Swing, Traditional

Specification	Detail
Drivetrain Speeds	7-speed (Triple)
Max Chainring Size	50T
Derailleur Capacity	20T
Dimensions (LxWxH)	5.5" x 4" x 3.25" (approx.)
Weight	0.05 Kilograms (approx.)
Material	Alloy Steel
Color	Black

7. Warranty Information

SHIMANO products are manufactured to high standards and are covered by a limited warranty against defects in materials and workmanship. For specific warranty terms, conditions, and duration, please refer to the official SHIMANO website or contact SHIMANO customer support directly. Keep your proof of purchase for warranty claims.

8. Customer Support

If you require further assistance with your Shimano FD-A073 Front Derailleur, please visit the official SHIMANO website for FAQs, technical documents, and contact information. You may also consult with a certified bicycle mechanic for professional installation, adjustment, or repair services.
Official SHIMANO Website: bike.shimano.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00C45HXBS

More documents and user manuals: **https://manuals.plus/**