Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 1687472YP

Briggs & Stratton Mower Oil Filter 1687472YP Instruction Manual

Model: 1687472YP | Brand: Briggs & Stratton

Official Briggs & Stratton Logo

1. Introduction

This manual provides essential instructions for the proper installation, function, and maintenance of the Briggs & Stratton Mower Oil Filter, model 1687472YP. This genuine OEM replacement part is designed to ensure proper fit and performance, contributing to the longevity and efficiency of your lawn mower equipment. Adhering to these guidelines will help maintain your engine's health and performance.

2. Safety Information

Always prioritize safety when performing maintenance on your equipment. Failure to follow safety precautions can result in injury or damage to the equipment.

- **Consult Equipment Manual:** Always refer to your specific lawn mower's owner's manual for detailed safety precautions and procedures before beginning any maintenance.
- **Engine Cool Down:** Ensure the engine is completely cool before attempting to remove or install the oil filter. Hot oil and engine components can cause severe burns.
- **Disconnect Spark Plug:** To prevent accidental engine startup, disconnect the spark plug wire from the spark plug before performing any service.
- **Personal Protective Equipment (PPE):** Wear appropriate PPE, including safety glasses and gloves, to protect against oil splashes and sharp edges.
- **Proper Disposal:** Dispose of used oil and oil filters responsibly according to local environmental regulations. Do not pour used oil down drains or onto the ground.

3. Product Identification

The Briggs & Stratton Mower Oil Filter 1687472YP is supplied in official Briggs & Stratton packaging. Verify the part number on the packaging matches the required replacement part for your equipment.



Image: Briggs & Stratton Oil Filter 1687472YP in its original packaging. The packaging features the 'GENUINE BRIGGS & STRATTON PARTS' logo and multilingual text for 'ORIGINAL SERVICE PARTS'.

4. Installation (Setup)

Follow these steps to properly install the Briggs & Stratton Mower Oil Filter 1687472YP. Always refer to your engine's service manual for specific torque specifications and procedures.

1. **Prepare the Engine:** Ensure the engine is cool and the spark plug wire is disconnected. Place a suitable drain pan beneath the oil filter location to catch any spilled oil.
2. **Remove Old Filter:** Unscrew the old oil filter counter-clockwise. Be prepared for oil to drain out. Allow all oil to drain from the filter and dispose of it properly.
3. **Prepare New Filter:** Apply a thin film of clean engine oil to the rubber gasket of the new Briggs & Stratton oil filter. This helps ensure a proper seal.
4. **Install New Filter:** Screw the new filter onto the engine by hand until the gasket makes contact with the engine block.
5. **Tighten Filter:** Once the gasket contacts the engine block, tighten the filter an additional 1/4 to 1/2 turn by hand. Do not overtighten, as this can damage the filter or engine block. Refer to your engine manual for precise torque specifications if available.
6. **Refill Oil:** Refill the engine with the recommended type and amount of engine oil as specified in your lawn mower's owner's manual.
7. **Check for Leaks:** Reconnect the spark plug wire. Start the engine and let it run for a few minutes. Shut off the engine and check for any oil leaks around the new filter. If leaks are present, tighten slightly or re-evaluate the installation.



Image: The Briggs & Stratton Oil Filter 1687472YP, showing its pleated filter media and metal end caps with a spring. A ruler is visible for scale, indicating its approximate dimensions.

5. Operating Principle (Function)

The oil filter is a crucial component within your engine's lubrication system. Its primary function is to remove contaminants from the engine oil. As oil circulates through the engine, it picks up various particles such as dirt, metal shavings from wear, carbon deposits, and sludge. The filter's pleated media traps these harmful particles, preventing them from recirculating and causing abrasive wear to critical engine components like bearings, pistons, and cylinder walls. A clean oil filter ensures a steady supply of clean oil, which is vital for proper lubrication, cooling, and overall engine health.

6. Maintenance

Regular replacement of the oil filter is essential for maintaining engine performance and extending its lifespan.

- **Replacement Schedule:** Always refer to your lawn mower's owner's manual for the manufacturer's recommended oil and oil filter replacement intervals. Generally, oil filters should be replaced at least once per season or every 50 operating hours, whichever comes first.
- **Severe Conditions:** If operating your equipment in dusty, dirty, or extreme temperature conditions, more frequent oil and filter changes may be necessary.
- **Always Replace with Oil Change:** It is highly recommended to replace the oil filter every time you change the engine oil to ensure the new oil remains clean and effective.

7. Troubleshooting

If you encounter issues related to your oil filter, consider the following common troubleshooting steps:

- **Oil Leaks Around Filter:**
  - Ensure the filter is tightened correctly (hand-tight plus 1/4 to 1/2 turn).
  - Check if the old gasket was removed from the engine block before installing the new filter. A double gasket will cause leaks.
  - Inspect the new filter's gasket for any damage or deformities.
- **Low Oil Pressure:**

- A severely clogged oil filter can restrict oil flow, leading to low oil pressure. If you suspect this, replace the filter immediately.
- Ensure the engine oil level is correct.

- **Premature Engine Wear:**
  - Failure to replace the oil filter at recommended intervals can lead to contaminated oil circulating, causing accelerated engine wear. Adhere to the maintenance schedule.

If problems persist, consult your lawn mower's service manual or contact an authorized service technician.

8. Specifications

Brand	Briggs & Stratton
Model Number	1687472YP
Manufacturer Part Number	1687472YP
Material	Plastic
Item Dimensions (L x W x H)	4.75 x 1.38 x 7 inches
Item Weight	0.15 Pounds
Included Components	Oil Filter
Compatible Vehicle Type	Lawn Mower
GTIN / UPC	024847912562

9. Warranty and Support

As a genuine Briggs & Stratton part, this oil filter is manufactured to high-quality standards. For specific warranty information pertaining to this replacement part, please refer to the documentation that accompanied your original Briggs & Stratton equipment or contact Briggs & Stratton customer support directly. Warranty terms typically cover manufacturing defects.
For technical assistance, additional product information, or to locate an authorized service dealer, please visit the official Briggs & Stratton website or contact their customer service department. Ensure you have your product model and serial numbers available when seeking support.
Briggs & Stratton Official Website: www.briggsandstratton.com

© 2023 Briggs & Stratton. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00D6FK1QY

More documents and user manuals: **https://manuals.plus/**