Honeywell 5110

Honeywell Security Safe Model 5110 User Manual

Instructions for Setup, Operation, and Maintenance

1. INTRODUCTION

Thank you for choosing the Honeywell Security Safe Model 5110. This safe is designed to protect your valuables, documents, and records. Please read this manual carefully to ensure proper setup and operation of your safe.

The Honeywell Security Safe Model 5110 features a digital keypad for secure access, an override key for emergency entry, and a durable steel construction with a scratch-resistant powder coat finish. It includes a removable cash tray and predrilled mounting holes for secure installation.

2. SAFETY INFORMATION

- Do not store the override keys inside the safe. Keep them in a secure, separate location.

- Ensure the safe is placed on a stable, level surface.

- Keep the safe away from excessive moisture or extreme temperatures.

- This safe is for security purposes and is not fireproof or waterproof unless explicitly stated on the product packaging.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Honeywell Security Safe Model 5110

- Override Keys (2)

- Mounting Bolts (for securing the safe)

- Removable Cash Tray

- Instruction Manual (this document)

4. SETUP

4.1 Installing Batteries

The digital keypad requires 4 AA batteries (not included) for operation. Ensure the batteries are inserted with correct polarity.

1. Locate the battery compartment on the inside of the safe door.

2. Open the battery compartment cover.

3. Insert 4 new AA batteries, observing the correct (+) and (-) polarity markings.

4. Close the battery compartment cover securely.

4.2 Initial Opening and Setting Your Personal Code

The safe will arrive in a locked state. Use the override key for the first opening and to set your personal code.

1. Insert one of the override keys into the keyhole, usually located behind a small cover on the keypad panel.

2. Turn the key clockwise to unlock.

3. While the key is turned, rotate the handle clockwise to open the safe door.

4. With the door open, locate the red or green reset button on the inside of the door, near the hinge.

5. Press the reset button. You will hear a beep, and the yellow "PROCEED" light on the keypad will illuminate.

6. Within 5 seconds, enter your desired 3-8 digit personal code on the keypad.

7. Press the "A" or "B" button to confirm your new code. You will hear a confirmation beep.

8. Test your new code with the door open: Enter your code, then press "A" or "B". The green "READY" light should illuminate, allowing you to turn the handle.

9. Remove the override key and store it in a safe place, separate from the safe.

Image: Front view of the Honeywell Security Safe Model 5110, showcasing the digital keypad and handle.

4.3 Mounting the Safe

The safe features predrilled mounting holes for secure installation to a floor or wall. Mounting hardware

(bolts) is included.

1. Choose a suitable location for mounting.

2. Open the safe door and locate the predrilled holes on the bottom or back panel.

3. Position the safe and mark the drilling points on the surface.

4. Drill pilot holes into the surface according to the size of the mounting bolts.

5. Align the safe with the drilled holes and insert the mounting bolts.

6. Tighten the bolts securely to fasten the safe in place.

Image: The Honeywell Security Safe Model 5110 with its door open, revealing the interior storage space and a removable cash tray.

5. OPERATION

5.1 Opening the Safe with Your Personal Code

1. Enter your 3-8 digit personal code on the keypad.

2. Press the "A" or "B" button.

3. If the code is correct, the green "READY" light will illuminate, and you will hear a beep.

4. Within 5 seconds, turn the handle clockwise to open the safe door.

5. To close, simply shut the door and turn the handle counter-clockwise until it locks.

5.2 Using the Override Key (Emergency Access)

The override key provides emergency access in case you forget your code or the batteries are depleted.

1. Locate the keyhole cover on the keypad panel and remove it.

2. Insert an override key into the keyhole.

3. Turn the key clockwise to unlock.

4. While the key is turned, rotate the handle clockwise to open the safe door.

5. Remember to store override keys in a secure location away from the safe.

5.3 Low Battery Indicator

When the batteries are low, the red "LOW BATT" light on the keypad will illuminate when you attempt to open the safe. Replace the batteries promptly to ensure continued operation.

6. MAINTENANCE

6.1 Battery Replacement

Replace the 4 AA batteries when the "LOW BATT" indicator lights up or if the keypad becomes unresponsive. Refer to Section 4.1 for battery installation steps.

6.2 Cleaning

Clean the exterior of the safe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or keypad.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Safe does not open with code.	Incorrect code entered. Batteries are low or dead.	Re-enter the code carefully. Replace batteries (refer to Section 6.1). Use override key if necessary.
Keypad is unresponsive.	Dead batteries.	Replace batteries immediately (refer to Section 6.1). Use override key to open.
"LOW BATT" light is on.	Batteries are low.	Replace batteries (refer to Section 6.1).
Cannot set new code.	Reset button not pressed correctly. Code not entered within 5 seconds.	Ensure the reset button is pressed firmly until a beep is heard. Enter the new code quickly after pressing the reset button.

8. SPECIFICATIONS

Image: Visual representation of the external dimensions for the Honeywell Security Safe Model 5110.

Feature	Detail
Model Number	5110
Brand	Honeywell
Capacity	0.51 cu. ft.
Material	Steel
Finish	Powder Coated
Lock Style	Digital Keypad, Override Key
Number of Bolts	2
Outside Dimensions (H x W x D)	9.8 in x 13.8 in x 10.2 in (approx. 24.9 cm x 35.1 cm x 25.9 cm)
Inside Dimensions (H x W x D)	8.875 in x 13.625 in x 7.25 in (approx. 22.5 cm x 34.6 cm x 18.4 cm)
Item Weight	20.8 pounds (approx. 9.43 kg)
Batteries Required	4 AA (not included)
Mounting Type	Floor Mount

9. WARRANTY AND SUPPORT

Honeywell provides a **1-year limited warranty** for this product. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Honeywell website.

For additional information or to explore other Honeywell products, you may visit the Honeywell Store on Amazon.

Related Documents - 5110

	Honeywell Steel Security Box User Guide Comprehensive user guide for the Honeywell Steel Security Box (Models 5005 series), covering setup, operation, maintenance, and warranty information.
	Honeywell 5101 & 5102 Steel Security Safe Operation Manual User manual for Honeywell 5101 & 5102 Steel Security Safes. Includes setup, operation, passcode programming, override key usage, mounting instructions, and limited warranty information.
	Honeywell 2201 & 2203 Steel Fire & Security Safe: Operation and Warranty Guide Comprehensive guide for the Honeywell 2201 & 2203 Steel Fire & Security Safe, covering setup, operation, lost combinations, ordering new keys, and the lifetime after-fire replacement guarantee.
	Honeywell Steel Security Safe Operation & Installation Guide Comprehensive guide for operating and installing Honeywell Steel Security Safes, models 5805 and 5806, featuring programmable digital locks. Includes instructions on locking, unlocking, battery replacement, maintenance, anchoring, consumer assistance, and warranty information.
	Honeywell Executive / Long Gun Safe User Guide Comprehensive user guide for the Honeywell Executive and Long Gun Safes, detailing setup, operation, security features, maintenance, and warranty for models 3014DG, 3018DG, 3024DG, and 3032DG.

Honeywell

ENGLISH

User Guide

Digital Programmable Bluetooth Security Safe
with Motorized Digital Lock

Model 5403

Package Includes:

1 – Digital Bluetooth Steel Security Safe
1 – Operation Manual
2 – Override Access Keys
4 – Mounting Hardware
1 – Removable Shelf

Please read carefully the above list of contents at time have been received.
If any items are missing, please contact Consumer Assistance (see page 2 / for contact information.)

Read this manual carefully and never store it inside the safe!

[Honeywell Model 5403 Digital Programmable Bluetooth Security Safe User Guide](#)
User guide for the Honeywell Model 5403 Digital Programmable Bluetooth Security Safe with Motorized Digital Lock. This document details setup, operation, Bluetooth app integration, security features, and troubleshooting for secure storage of valuables.