Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 154843901

Frigidaire 154843901 Drive Motor User Manual

Model: 154843901

Product Overview

The Frigidaire 154843901 Drive Motor is a genuine replacement part designed for Frigidaire dishwashers. Engineered to exact specifications, this motor ensures optimal performance and reliability for your appliance. It is crucial to verify compatibility with your specific dishwasher model before proceeding with installation.



Image: The Frigidaire 154843901 Drive Motor, a genuine replacement component for dishwashers, shown from a front-side perspective.

Specifications

Attribute	Detail
Brand Name	Frigidaire
Model Info	154843901
Item Weight	2.55 pounds
Product Dimensions	1 x 1 x 1 inches
Part Number	154843901

Manufacturer	Frigidaire
Date First Available	July 17, 2013
UPC	012505474729, 840383151032

Installation Information

This section provides guidance for the proper installation of the Frigidaire 154843901 Drive Motor. Adherence to these guidelines is essential for correct function and safety.



Image: A graphic detailing installation requirements, including skill level (Trained Service Tech), estimated install time (40 minutes), and tools required.

Required Tools:

- 1/4" nut driver
- Cross-head screwdriver
- T15 & T20 drivers
- Gloves
- Safety glasses

Skill Level:

Installation of this part is recommended for a **Trained Service Technician**. For optimal results and to ensure safety, it is advised that a professional performs the installation.

Compatibility

The Frigidaire 154843901 Drive Motor is compatible with a wide range of Frigidaire dishwasher models. Please verify your specific model number against the list below before purchasing to ensure proper fit and function.



Image: A graphic displaying a comprehensive list of compatible Frigidaire dishwasher models for the 154843901 Drive Motor.

Compatible Models:

BD2434P, CDB350N, CDB400K, CDB500N, CDB600K, CDB900N, FDB520RH, FGBD2434, 970D1532, 970D1546, 970D1547, 970D1567, CDBEH600S, CDBEH950S, CDBEH960T, DGBD2432K, DGBD2438P, DGCD2444S, FDB1100RH, FDB1450CH, FDB1502RG, FFBD2403L, FFBD2404N, FFBD2405K, FFBD2406N, FFBD2407L, FFBD2408N, FFBD2409L, FFBD2411N, FFBD2412S, FFCD2413U, FFCD2418U, FFID2423R, FFID2426T, FGBD2431K, FGBD2431N, FGBD2432K, FGBD2434P, FGBD2435N, FGBD2438P, FGBD2445N, FGCD2436S, FGCD2444S, KABD2405M, KABD2406N, LFBD2409L, LFBD2412S, LFID2422R, LFID2426T, LGBD2431L, LGBD2431N, LGBD2432L, LGBD2435N, FGBD2434PB, FGBD2434PF, FGBD2434PW

Operating Instructions

As a replacement component, the Frigidaire 154843901 Drive Motor does not have independent operating instructions. Its function is integrated into the dishwasher's overall operation. Once correctly installed, the dishwasher will operate as designed by its manufacturer.

Maintenance

The Frigidaire 154843901 Drive Motor is a sealed unit and requires no routine maintenance or lubrication. To ensure longevity, avoid exposing the motor to excessive moisture or physical damage. If the motor exhibits signs of malfunction, it should be inspected by a qualified technician.

Troubleshooting

Troubleshooting issues related to the drive motor typically involve diagnosing symptoms such as unusual noises during operation, failure of the dishwasher to wash properly, or water leaks from the motor area. Due to the complexity of dishwasher repair and the electrical components involved, it is strongly recommended to consult a trained service technician for accurate diagnosis and repair.

Support and Assurance

Frigidaire provides assurance for its genuine parts. You can confidently repair your appliance when you choose genuine Frigidaire parts, as they are engineered to exact specifications for optimal performance and reliability.

For further assistance, technical support, or to locate a trained service technician, please refer to the official Frigidaire support channels or visit the Frigidaire Store on Amazon.

© 2023 Frigidaire. All rights reserved. This manual is for informational purposes only and is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00DZZL984

More documents and user manuals: **https://manuals.plus/**