Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

We R Memory Keepers 71337-1

We R Memory Keepers Trim & Score Board (71337-1) Instruction Manual

Model: 71337-1

1. Introduction

The We R Memory Keepers Trim & Score Board is a versatile tool designed for precision paper crafting. It allows users to accurately trim and score various paper materials, making it ideal for projects such as card making, scrapbooking, and other DIY paper crafts. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your tool.

Key Features:

- Integrated trimming and scoring functions.
- Clear measurement guides for accurate cuts and folds.
- Durable construction for consistent performance.
- Lightweight and portable design.
- Includes a scoring tool and two titanium blades.

2. Safety Information

Please read and understand all safety instructions before using the Trim & Score Board.

- **Sharp Blades:** The cutting blades are extremely sharp. Handle with care and keep fingers away from the blade path during operation and replacement.
- **Adult Supervision:** This product is not a toy. Keep out of reach of children. Adult supervision is recommended when children are present.
- **Stable Surface:** Always use the board on a flat, stable surface to prevent accidental movement and ensure precise results.
- **Proper Storage:** Store the board in a safe place when not in use, with the cutting arm secured, to prevent accidental injury.
- **Intended Use:** Use the board only for its intended purpose of trimming and scoring paper and similar craft materials. Do not attempt to cut other materials.

3. Setup

3.1 Unpacking

Carefully remove the Trim & Score Board from its packaging. Inspect all components to ensure they are present and undamaged. The package should include the main board, a scoring tool, and two titanium blades (one installed, one spare).





The Trim & Score Board as it appears in its original packaging, highlighting included components.

3.2 Familiarizing with Components

Before use, familiarize yourself with the different parts of the board:

- **Base Board:** The main surface with measurement grids and scoring grooves.
- **Cutting Arm:** The movable arm that holds the cutting blade.
- **Scoring Tool:** A separate tool used to create score lines.
- **Measurement Guides:** Printed rulers in inches and centimeters for precise placement.
- **Blade Storage:** A designated slot for storing the spare blade.



The We R Memory Keepers Trim & Score Board, showcasing its compact design and integrated tools.

4. Operating Instructions

4.1 Trimming Paper

1. Place the paper on the base board, aligning the edge you wish to cut with the desired measurement guide.
2. Ensure the paper is flat and securely positioned against the top and side guides.
3. Lower the cutting arm over the paper. The clear guide on the cutting arm helps visualize the cut line.
4. Gently slide the cutting blade carriage along the track, applying even pressure, to make a clean cut.
5. Lift the cutting arm and remove the trimmed paper.



Demonstration of using the integrated cutting blade to trim paper.

4.2 Scoring Paper


1. Place the paper on the base board, aligning the edge where you want the score line with the desired measurement guide.
2. Locate the scoring grooves on the base board.
3. Take the scoring tool and place its tip into the scoring groove at the desired measurement.
4. Apply gentle, even pressure and slide the scoring tool along the groove to create a crisp score line. For thicker materials, multiple passes with light pressure may be necessary.
5. Remove the paper and fold along the created score line.



Multilingual instructions inside
Instructions de multilingue à l'intérieur
Multilingual instrucciones incluido
Multilingual anweisungen im inneren

Blade storage
Rangement pour lames
Almacenamiento de corte
Klingenspeicher

Cut precisely with titanium blades
Coupe avec précision avec des lames de titane
Corta con precisión con cuchillas de titanio
Präzise schneiden mit Titanklingen



Folds out to a full 12 x 12in (30.5 x 30.5cm) surface
Se déplie pour découvrir une surface de 12 x 12in (30.5 x 30.5cm)
Se despliega hasta cubrir una superficie completa de 12 x 12in (30.5 x 30.5cm)
Zu einer Fläche von 12 x 12in (30.5 x 30.5cm) ausklappbar

Measurements in inches and centimeters
Mesures en pouces et en centimètres
Medidas en pulgadas y centímetros
Maße in zentimetern und zoll

Scoring tool storage
Rangement pour outils de découpage
Almacenamiento de herramienta de puntuación
Kratzer werkzeugspeicher



PERFECT FOR CREATING: Boxes, Cards, Envelopes, Gift Bags, Paper Rosettes & More

PARFAIT POUR CRÉER: Boîtes, Cartes, Enveloppes, Sacs Cadeaux, Rosettes De Papier Et Plus

PERFECTO PARA CREAR: Cajas, Tarjetas, Sobres, Bolsas De Regalos, Rosetas De Papel Y Más

PERFEKT ZUM ERSTELLEN VON: Schachteln, Karten, Umschlägen, Geschenktüten, Papierrosetten Und Natürlich Vielem Mehr

WARNING:
Not intended for children / Contains sharp blade

AVERTISSEMENT:
Nondestiné à l'usage des enfants / Contient la lame tranchante

ADVERTENCIA:
No está diseñado para los niños / Contiene hoja afilada

ACHTUNG:
Nicht für Kinder geeignet / Enthält scharfe Klinge

distributed by | distribué par | distribuido por
AMERICAN CRAFTS™
588 W. 400 S. STE 300
LINDON, UT 84042
made in china | fabriqué aux chine | hecho en china
www.americancrafts.com © 2016

71337-1



Demonstration of using the scoring tool to create a fold line on paper.

4.3 Using Measurement Guides

The board features clear measurement guides in both inches and centimeters. Always ensure your paper is aligned correctly with the desired measurement for accurate results. The scoring grooves are aligned with inch measurements.

5. Maintenance

5.1 Cleaning

To maintain optimal performance, keep your Trim & Score Board clean. Wipe the surface with a damp cloth. The manufacturer recommends hand washing only. Avoid abrasive cleaners or harsh chemicals that could damage the plastic or printed measurements.

5.2 Blade Replacement

Over time, cutting blades will become dull, leading to ragged cuts. Replace the blade when you notice a decrease in cutting performance. The board includes a spare titanium blade. Additional replacement blades (Model 71338-8) can be purchased separately.

1. Carefully slide the blade carriage to the center of the cutting track.
2. Gently pry open the blade housing on the carriage.
3. Remove the old blade, being extremely cautious of the sharp edge.
4. Insert a new blade into the housing, ensuring it is seated correctly.
5. Close the blade housing until it clicks securely.
6. Test the new blade on a scrap piece of paper.



Visual guide for identifying the correct replacement blade and its installation.

6. Troubleshooting

- **Ragged or Uneven Cuts:**
  Solution: The blade may be dull. Replace the cutting blade. Ensure the paper is held firmly against the guides and the cutting arm is pressed down evenly during the cut.
- **Blade Not Moving Smoothly:**
  Solution: The cutting track may have debris or paper dust. Clean the track thoroughly. A very thin coating of a silicone-based lubricant (like WD-40 applied to a cloth, then wiped on the track) can improve smoothness, but ensure no excess lubricant transfers to your paper.
- **Difficulty Seeing Measurement Guides:**
  Solution: Ensure adequate lighting in your workspace. Clean the board surface if it is obscured by dust or residue.
- **Paper Slipping During Scoring/Trimming:**
  Solution: Ensure the board is on a stable, non-slip surface. Apply firm, even pressure to the paper to hold it in place against the guides.

7. Specifications

Brand	We R Memory Keepers
Model Number	71337-1
Color	White
Product Dimensions	17.9"L x 10.05"W x 1.7"Th
Material	Plastic
Item Weight	1.5 Pounds
Recommended Uses	Paper
Special Feature	Lightweight, Non Slip
Included Components	Trim & Score Board, Scoring Tool, Two Replacement Blades
Care Instructions	Hand Wash Only

8. Warranty Information

This We R Memory Keepers Trim & Score Board comes with a limited warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or contact We R Memory Keepers customer support.

9. Support

For further assistance, product inquiries, or to purchase replacement parts, please visit the official We R Memory Keepers store or website.

We R Memory Keepers Store: Visit Store

Note on Videos: No official product videos were provided in the available data for embedding in this manual.

© 2025 We R Memory Keepers. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is my paper cutting crooked on the top part of the cutting track on the We R Memory Keepers Trim & Score Board (71337-1)?

If your We R Memory Keepers Trim & Score Board (71337-1) is cutting crookedly at the top of the track despite having a clean track and a fresh blade, please check the following troubleshooting...

Read full answer

Open the live page

https://manuals.plus/asin/B00EOC6T6E

More documents and user manuals: **https://manuals.plus/**