**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Chicco 06746/A**

# Chicco Electronic Baby Scale Model 06746/A Instruction Manual

## 1. Introduction

This manual provides detailed instructions for the safe and effective use of your Chicco Electronic Baby Scale, Model 06746/A. This device is designed to accurately monitor the weight of infants and children up to 20 kg, assisting parents and caregivers in tracking growth.
Please read this manual thoroughly before first use and keep it for future reference.

## 2. Safety Information

- Always place the scale on a stable, flat, and hard surface to ensure accurate readings. Avoid soft surfaces like carpets.
- Never leave a baby unattended on the scale. Always maintain physical contact with the baby during weighing.
- Keep the scale away from water and moisture. Do not immerse the device in water.
- Do not use abrasive cleaners or solvents on the scale. Clean with a soft, damp cloth.
- Ensure batteries are inserted correctly according to polarity markings. Remove batteries if the scale will not be used for an extended period.
- This scale is for domestic use only and is not intended for medical diagnosis. Consult a healthcare professional for any concerns regarding your child's growth.
- Do not exceed the maximum weight capacity of 20 kg.

## 3. Package Contents

Verify that all items are present in the package:

- 1 x Chicco Electronic Baby Scale Model 06746/A
- 2 x AA Batteries
- 1 x Instruction Manual (this document)

# 4. Setup

## 4.1 Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

## 4.2 Scale Placement

Place the scale on a firm, flat, and level surface. Ensure there is sufficient space around the scale for safe operation and to prevent accidental tipping.




Image 1: Top-down view of the Chicco Electronic Baby Scale, showing the weighing platform and the integrated LCD display with control buttons.

# 5. Operating Instructions

## 5.1 Power On/Off

- To turn on the scale, press the **ON/OFF** button (usually marked with a circle and a vertical line). The LCD display will show '0.000 kg' when ready.
- The scale features an automatic shut-off function after approximately 30 seconds of inactivity to conserve battery life.

## 5.2 Weighing Procedure

1. Turn on the scale. Wait for the display to show '0.000 kg'.
2. Carefully place the baby on the center of the weighing platform. Ensure the baby is calm and still for an accurate reading.
3. The display will stabilize and show the baby's weight.
4. Record the weight if necessary.
5. Remove the baby from the scale.




Image 2: A baby lying comfortably on the Chicco Electronic Baby Scale, demonstrating the typical use of the product for weighing.

## 5.3 Tare Function

The Tare function allows you to subtract the weight of an object (e.g., a towel or blanket) placed on the scale before weighing the baby, ensuring only the baby's weight is measured.

1. Turn on the scale.
2. Place the towel or blanket on the weighing platform.
3. Press the **TARE (T)** button. The display will reset to '0.000 kg'.
4. Carefully place the baby on the towel/blanket. The display will show the baby's net weight.

## 5.4 Last Weighing Memory

The scale automatically stores the last recorded weight. To recall the last measurement:

- After turning on the scale, if no weight is detected, the display may briefly show the last recorded weight before resetting to zero.
- Refer to the specific button (if any) for memory recall as indicated on the device or in the quick start guide.

## 5.5 Weighing Stabilization System

The Chicco Electronic Baby Scale is equipped with an advanced stabilization system. This feature helps to provide an accurate weight reading even if the baby moves slightly during the weighing process, ensuring precision down to 10 grams.




Image 3: Diagram illustrating the stabilization system of the Chicco Electronic Baby Scale, which helps maintain accuracy even when the baby moves.

## 5.6 Unit Selection

The scale supports multiple units of measurement (kilograms and pounds/ounces). To switch between units:

- With the scale turned on and displaying '0.000 kg', press the unit selection button (often integrated with the TARE button or a separate button).
- The display will toggle between 'kg' and 'lb/oz'.




Image 4: Close-up view of the Chicco Electronic Baby Scale's display and buttons, indicating the Tare function, last weighing memory, and dual measurement units (kg or lb/oz).

## 6. Maintenance and Care

- **Cleaning:** Wipe the scale surface with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the scale in water.
- **Storage:** Store the scale in a dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Always replace both batteries at the same time.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Display shows 'Lo' | Low battery power. | Replace both AA batteries. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Display shows 'Err' or 'O-Ld' | Overload. Weight exceeds 20 kg. | Remove the item from the scale. Do not exceed maximum capacity. |
| Inaccurate readings | Scale not on a flat surface; baby moving; external vibrations. | Ensure scale is on a stable, flat surface. Wait for baby to be calm. Minimize external disturbances. |
| Scale does not turn on | Batteries incorrectly installed or depleted. | Check battery polarity. Replace batteries if necessary. |

## 8. Specifications

- **Model Number:** 06746/A
- **Brand:** Chicco
- **Maximum Weight Capacity:** 20 kg
- **Measurement Precision:** 10 grams
- **Display Type:** LCD
- **Power Source:** 2 x AA Batteries (included)
- **Material:** Plastic
- **Dimensions (L x W x H):** 24.02 x 13.58 x 2.52 cm
- **Item Weight:** 1.5 kg (3.31 pounds)
- **Special Features:** Automatic shut-off, Low battery indicator, Overload clutch, Weighing stabilization system, Last weighing memory, Tare function.
- **Manufacturer:** Artsana SPA

## 9. Warranty and Support

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Chicco website. You may also contact Chicco customer service directly for assistance.
Keep your proof of purchase for warranty claims.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00GMV5HDG**

More documents and user manuals: **https://manuals.plus/**