Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ARREGUI 2006/W

ARREGUI 2006/W Wall-Mount Letter Box Instruction Manual

Model: **2006/W**
Brand: **ARREGUI**

1. Product Overview

The ARREGUI 2006/W is a compact, single letter box constructed from galvanized steel, designed for outdoor installation. It features a protective flap that shields the mail slot from adverse weather conditions such as rain. The lock mechanism is conveniently located on the front panel for easy access. The door opens from left to right, facilitating user-friendly mail retrieval.



Figure 1: Front view of the ARREGUI 2006/W Letter Box.

2. Package Contents

Verify that all components are present in the package before proceeding with installation.

- ARREGUI 2006/W Letter Box
- Mounting Material (dowels and screws)
- 2 Keys for the cylinder lock




Figure 2: Included components: Letter box, keys, and mounting hardware.

3. Specifications

Feature	Detail
Model Number	2006/W

Feature	Detail
Material	Galvanized Steel, Epoxy-Polyester Powder Thermoset Paintwork
Color	White
External Dimensions (H x W x D)	12.8" x 8.66" x 4.33" (32.5 x 22 x 11 cm)
Mail Slot Dimensions	18 x 2.5 cm
Mail Compatibility	DIN A5 sheets, folded A4 sheets, small envelopes (e.g., C5, DL)
Mounting Type	Wall Mount
Security Features	Cylinder lock with 2 keys
Item Weight	3.24 pounds



Figure 3: Dimensions of the ARREGUI 2006/W Letter Box.

4. Setup and Installation

The ARREGUI 2006/W letter box can be installed in two primary ways: wall-mounted or attached to a fence/gate (with an optional kit).

4.1 Wall Mounting

For wall mounting, the letter box features four pre-drilled holes on its back panel. Mounting hardware (dowels and screws) is included.





Figure 4: Rear view showing mounting holes.

Required Tools (Not Included):

- Drill
- Drill bit appropriate for wall material and dowel size
- Pencil
- Measuring tape
- Level

Installation Steps:

1. **Select Location:** Choose a suitable wall location for the letter box, ensuring it is at an accessible height and clear of obstructions.
2. **Mark Drilling Points:** Hold the letter box against the wall at the desired height. Use a pencil to mark the positions of the four pre-drilled holes on the wall. Use a level to ensure the marks are aligned horizontally and vertically.
3. **Drill Holes:** Using the appropriate drill bit, drill holes at the marked positions. Ensure the depth is sufficient for the provided dowels.
4. **Insert Dowels:** Insert the plastic dowels into the drilled holes. Tap them gently with a hammer if necessary until they are flush with the wall surface.
5. **Mount Letter Box:** Align the letter box's mounting holes with the inserted dowels. Insert the screws through the letter box holes and into the dowels. Tighten the screws securely, but do not overtighten to avoid damaging the wall or the letter box.

4.2 Fence or Gate Attachment

For attachment to a fence or gate, the ARREGUI C-015 mounting kit (sold separately) is required. Follow the instructions provided with the ARREGUI C-015 mounting kit for proper installation.

5. Operation

5.1 Inserting Mail

To insert mail, lift the protective flap located at the top of the letter box. The mail slot is positioned underneath this flap. Insert mail into the slot. The protective flap will automatically close, shielding the contents from weather.



Figure 5: Mail insertion slot with protective flap open.

5.2 Retrieving Mail

To retrieve mail, insert one of the provided keys into the cylinder lock on the front panel. Turn the key to unlock the door. The door opens from left to right. Once mail is retrieved, close the door and turn the key to lock it securely.



Figure 6: Letter box with door open for mail retrieval.

6. Maintenance

Regular maintenance helps ensure the longevity and proper function of your ARREGUI letter box.

- **Cleaning:** Clean the exterior surfaces periodically with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the paintwork.
- **Lock Mechanism:** If the lock mechanism becomes stiff, apply a small amount of graphite lubricant to the keyhole. Do not use oil-based lubricants, as they can attract dirt.
- **Protective Flap:** Ensure the protective flap and mail slot are kept clear of debris (e.g., leaves, dirt) to allow for smooth operation and proper weather protection.

7. Troubleshooting

This section addresses common issues you might encounter with your letter box.

- **Difficulty Locking/Unlocking:**
  - Ensure the door is fully closed and aligned before attempting to lock.
  - Check if the key is fully inserted and turn it firmly.
  - Apply graphite lubricant to the lock if it feels stiff (refer to Maintenance section).
- **Mail Getting Wet:**
  - Verify that the protective flap is closing completely over the mail slot. Clear any obstructions.
  - Inspect the letter box for any visible damage or gaps that could allow water ingress.
- **Door Not Closing Properly:**
  - Check for any foreign objects obstructing the door's closing path.
  - Ensure the hinges are not damaged or bent.

8. Warranty and Support

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase. ARREGUI products are designed for durability and performance.

If you require further assistance or have questions not covered in this manual, please contact your point of purchase or visit the official ARREGUI website for support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00H2JY62A

More documents and user manuals: **https://manuals.plus/**