Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Starbucks Decaf House Blend K-Cups

Starbucks Decaf House Blend Coffee K-Cups Instruction Manual

Product Overview

The Starbucks Decaf House Blend Coffee K-Cups offer a convenient way to enjoy a classic Starbucks coffee experience at home. This medium-roasted blend features balanced flavors with subtle notes of nut and cocoa, all without the caffeine. Each K-Cup is designed for single-serve brewing, providing a consistent and satisfying cup every time.

- **Medium Roast:** A balanced and approachable flavor profile.
- **Decaffeinated:** Enjoy the rich taste of coffee without the caffeine.
- **Flavor Notes:** Features hints of nut and cocoa.
- **Convenient:** Designed for single-serve Keurig brewing systems.
- **Quantity:** This package contains 96 K-Cups.

Product Image



Image of Starbucks Decaf House Blend Coffee K-Cups packaging, showing the green box with coffee beans and the Starbucks logo.

Setup

Before brewing, ensure your Keurig single-serve coffee maker is clean and filled with fresh water. Remove the K-Cup from its packaging. Do not remove the foil lid from the K-Cup pod.

Operating Instructions

1. **Power On:** Turn on your Keurig coffee maker and wait for it to heat up. The indicator light will typically stop flashing when ready.
2. **Insert K-Cup:** Lift the handle of your Keurig brewer. Place one Starbucks Decaf House Blend K-Cup into the K-Cup holder. Lower the handle completely to puncture the K-Cup.
3. **Select Brew Size:** Choose your desired brew size (e.g., 6 oz, 8 oz, 10 oz) on your coffee maker.
4. **Brew:** Press the brew button. The coffee maker will begin brewing your decaffeinated coffee.
5. **Enjoy:** Once brewing is complete, carefully remove the used K-Cup pod and dispose of it. Enjoy your fresh cup of Starbucks Decaf House Blend coffee.

Maintenance

To ensure the best taste and performance, regularly clean your Keurig coffee maker. Refer to your Keurig brewer's specific instruction manual for detailed cleaning and descaling procedures. Generally, this involves rinsing the water reservoir, cleaning the K-Cup holder, and descaling the machine every 3-6 months depending on water hardness and usage.

Troubleshooting

- **Coffee is too weak:** Try selecting a smaller brew size or ensure the K-Cup is properly seated.
- **Coffee maker not brewing:** Check if the water reservoir is filled, the K-Cup is inserted correctly, and the brewer is

powered on and ready. Descaling may be required if the machine has not been maintained.

- **Grounds in coffee:** Ensure the K-Cup is not damaged and is properly inserted. Clean the K-Cup needle if necessary.

Specifications

Feature	Detail
Brand	Starbucks
Item Form	Capsule
Flavor	Nut and Cocoa
Caffeine Content	Decaffeinated
Coffee Roast Level	Medium Roast
Container Type	Capsule, Coffee Cup
Unit Count	96.00 Count
Number of Items	4 (Packs of 24)
Specialty	Kosher Certified
Variety	Decaf House Blend
Package Dimensions	14.25 x 9.92 x 6.61 inches
Item Package Weight	1.75 Kilograms (3.85 Pounds)
UPC	099555095555
ASIN	B00I28Y3AU

Ingredients

100% Arabica coffee.

Safety Information

- May contain traces of allergens.
- Do not consume if you are sensitive to caffeine (even decaffeinated products contain trace amounts).
- Dispose of used K-Cups responsibly.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Official Product Video

▶ **Watch video online**
Starbucks K-Cup Coffee Evergreen

This video showcases the Starbucks K-Cup coffee experience, highlighting the quality and convenience of brewing Starbucks coffee at home.

Warranty and Support

For questions regarding Starbucks products, please visit the official Starbucks website or contact their customer support. For issues related to your Keurig brewing system, please refer to your Keurig machine's manufacturer warranty and support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00I28Y3AU

More documents and user manuals: **https://manuals.plus/**