Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun KPC1, 67000538

Braun KPC1 Bowl, Strainer, and Citrus Press User Manual

For Multiquick 7, Multisystem, and 3210 Food Processors

1. Product Overview

The Braun KPC1 is an original accessory designed to enhance the functionality of your compatible Braun food processor. This versatile attachment combines a bowl, a strainer, and a citrus press, allowing for efficient preparation of various ingredients.

Compatibility: This accessory is specifically designed for Braun Multiquick 7, Multisystem, and 3210 series food processors. Please verify your food processor model number to ensure compatibility before use. Compatible model codes include 0X63210765 (Multiquick 7, Multisystem - INT version) and 0X63210766 (Multiquick 7, Multisystem - CA, MX, US versions).



Image 1.1: The Braun KPC1 accessory, showing its transparent bowl design with integrated strainer and citrus press components. This image illustrates the complete unit ready for attachment to a compatible food processor base.

2. Safety Instructions

Always observe the following safety precautions when using the Braun KPC1 accessory:

- Ensure the food processor base unit is unplugged before attaching or detaching the KPC1 accessory.
- Do not operate the accessory if any part is damaged or broken.
- Keep hands and utensils away from moving parts during operation.
- This accessory is not suitable for hot liquids or ingredients.
- Always refer to your main food processor manual for additional safety guidelines.
- Keep out of reach of children.

3. Components

The Braun KPC1 accessory consists of the following main parts:

- **Main Bowl:** The transparent container that collects strained liquids or juice.

- **Strainer Insert:** A perforated disc that fits into the bowl for straining purposes.
- **Citrus Press Cone:** A conical attachment used for juicing citrus fruits, which fits over the strainer insert.

4. Setup

To set up the Braun KPC1 accessory for use:

1. Ensure your Braun food processor base unit is clean and unplugged.
2. Place the KPC1 main bowl onto the food processor's drive shaft, aligning the notches until it securely locks into place.
3. For straining, insert the strainer disc into the bowl.
4. For citrus pressing, place the strainer disc into the bowl, then firmly attach the citrus press cone onto the central spindle of the strainer.
5. Once assembled, you may plug in your food processor.

5. Operating Instructions

5.1. Using as a Strainer

1. Assemble the KPC1 with only the main bowl and strainer insert.
2. Pour the liquid or semi-liquid mixture you wish to strain into the bowl.
3. Turn on the food processor at a low speed. The rotation will help separate solids from liquids, with the liquid collecting in the bowl below the strainer.
4. Once straining is complete, turn off and unplug the food processor before carefully removing the accessory.

5.2. Using as a Citrus Press

1. Assemble the KPC1 with the main bowl, strainer insert, and citrus press cone.
2. Cut citrus fruits (oranges, lemons, limes, grapefruits) in half.
3. With the food processor running at a low to medium speed, firmly press a fruit half onto the rotating citrus press cone.
4. The juice will be extracted and flow through the strainer into the main bowl, while pulp and seeds are retained by the strainer.
5. Continue until all fruit halves are juiced.
6. Once juicing is complete, turn off and unplug the food processor before carefully removing the accessory.

6. Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your KPC1 accessory:

- Always unplug the food processor before cleaning.
- Disassemble all parts of the KPC1 accessory.
- Wash all removable parts (bowl, strainer, citrus press cone) immediately after use with warm, soapy water.
- Rinse thoroughly under running water.
- **Important:** This accessory is **not dishwasher safe**. Hand wash only.
- Dry all parts completely before reassembling or storing.
- Store in a clean, dry place.

7. Troubleshooting

If you encounter issues with your Braun KPC1 accessory, consider the following:

Problem	Possible Cause	Solution
Accessory does not fit or lock onto the food processor.	Incorrect model compatibility or improper alignment.	Verify your food processor model is listed as compatible (Multiquick 7, Multisystem, 3210). Ensure the accessory is aligned correctly with the drive shaft and rotated until it clicks into place.
Ineffective straining or juicing.	Too much material at once, or incorrect speed.	Process smaller batches. Ensure the food processor is running at the recommended low to medium speed for optimal performance.
Accessory is difficult to clean.	Dried-on food residue.	Clean immediately after use. Soak parts in warm, soapy water if food has dried. Use a small brush for strainer perforations.

8. Specifications

Feature	Detail
Brand	Braun
Model Number	67000538 (KPC1)
Dimensions (L x W x H)	20 x 7 x 22.5 cm (approximately 7.9 x 2.8 x 8.9 inches)
Weight	190 grams (approximately 0.42 lbs)
Material	As described (typically food-grade plastic)
Dishwasher Safe	No (Hand wash recommended)
Country of Origin	Italy

9. Warranty and Support

For information regarding warranty coverage or technical support for your Braun KPC1 accessory, please refer to the documentation provided with your main Braun food processor unit or visit the official Braun website. You may also contact Braun customer service directly for assistance.

For general inquiries or if your specific food processor model is not listed as compatible, it is recommended to contact the seller or Braun customer support before purchase to avoid compatibility issues.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00J0399LE

More documents and user manuals: **https://manuals.plus/**