Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz C206 GLS

CAMPINGAZ C206 GLS Pierceable Gas Cartridge

USER MANUAL

Product Overview

The Campingaz C206 GLS pierceable gas cartridge is engineered for reliable performance in various outdoor settings. It features a high-performance butane/propane blend (80%/20%) that provides additional power, allowing for effective use even in temperatures as low as -5°C. This cartridge is designed for single, continuous use with compatible Campingaz appliances, as it cannot be disconnected once pierced. It incorporates a new flow reduction system, compliant with the European standard EN 417:2012, which significantly reduces residual gas escape in case of accidental disconnection.



Image: The Campingaz C206 GLS pierceable gas cartridge, blue in color, showing its label and design.

Important Safety Information

WARNING: Failure to follow these instructions may result in fire, explosion, or serious injury.

- Keep away from heat sources and open flames.
- Do not modify or alter the cartridge.
- Use only with compatible Campingaz appliances (e.g., Bleuet 206 Plus stove, Lumogaz C206 lantern).
- For optimal safety, place the cartridge in a well-ventilated area during use.
- In case of accidental leakage, avoid contact with skin and eyes. Immediately seek fresh air.
- Dispose of responsibly in accordance with local regulations.

Installation and Setup

This cartridge is designed for a single, secure connection to your Campingaz appliance. Once pierced, the cartridge cannot be safely disconnected until it is empty.

1. Ensure your Campingaz appliance (such as the Bleuet 206 Plus or Lumogaz C206) is turned off and cool.
2. Read the specific instructions for your appliance regarding cartridge installation.
3. Align the cartridge with the piercing mechanism of your appliance.

4. Firmly and steadily push the cartridge into place until it is fully seated and pierced. You may hear a hiss of gas as it connects; this is normal.
5. Verify that the connection is secure and there are no audible or visible gas leaks.



Image: A person's hands demonstrating the attachment of a Campingaz stove to a gas cartridge, ensuring a secure connection.

Operation Guide

Once the C206 GLS cartridge is securely installed on a compatible Campingaz appliance, you can proceed with its operation according to your appliance's specific instructions.

- Ensure the appliance is on a stable, level surface, away from flammable materials.
- Follow the appliance's instructions for lighting and adjusting the flame or light output.
- Always operate in a well-ventilated area to prevent the accumulation of gas.
- Do not leave the appliance unattended while in operation.
- When finished, turn off the appliance's gas control completely.



Image: A man preparing food on a portable Campingaz grill, demonstrating typical outdoor use of the gas cartridge.

Care and Maintenance

The Campingaz C206 GLS cartridge requires minimal maintenance. Proper handling and storage are key to ensuring safety and longevity.

- Store cartridges in a cool, dry, well-ventilated area, away from direct sunlight and temperatures exceeding 50°C (122°F).
- Keep cartridges away from ignition sources, including pilot lights, open flames, and electrical equipment.
- Do not store near corrosive chemicals.
- Inspect cartridges for any signs of damage or corrosion before use. Do not use damaged cartridges.
- Once empty, dispose of the cartridge according to local regulations for hazardous waste. Do not puncture or incinerate empty cartridges.

Troubleshooting

If you encounter issues with your Campingaz C206 GLS cartridge, consider the following:

- **No Gas Flow:** Ensure the cartridge is fully and correctly pierced and seated in the appliance. Check that the appliance's gas control knob is open.
- **Weak Flame/Light:** The cartridge may be running low on gas, or the ambient temperature might be too low for optimal performance (though the butane/propane mix helps in colder conditions).
- **Gas Leakage (Hissing Sound/Smell):** Immediately turn off the appliance. Move to a well-ventilated area. If the leak persists, carefully remove the cartridge (if safe to do so, remembering it cannot be re-sealed once pierced) and contact Campingaz customer support or emergency services. Never attempt to find a leak with an open flame.
- **Cartridge Not Fitting:** Ensure you are using a Campingaz appliance specifically designed for C206 pierceable cartridges.

Technical Specifications

Feature	Specification
Model Number	C206 GLS
Gas Type	Butane/Propane Mix (80%/20%)
Gas Weight	190 g (approx. 194 g as per description)
Total Weight	280 g
Dimensions (approx.)	9 x 9.5 cm (Diameter x Height)
Material	Metal
Standard Compliance	EN 417:2012 (Flow Reduction System)
Recommended Use	Camping, Garden, Balcony, Terrace



Image: A detailed view of the Campingaz gas cartridge label, highlighting product information and safety warnings.

Warranty and Support

For information regarding warranty, product support, or to find authorized service centers, please refer to the official Campingaz website or contact their customer service directly. Always ensure you are using genuine Campingaz accessories and parts for optimal performance and safety.
For further assistance, please visit the Campingaz Brand Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00KYVC3MI

More documents and user manuals: **https://manuals.plus/**