Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AXON F16

AXON F-16 Pocket Model Hearing Aid User Manual

Model: F-16

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your AXON F-16 Pocket Model Hearing Aid. Designed for individuals with hearing impairment, this device offers a convenient and effective solution for improved auditory perception. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

Package Contents:

- AXON F-16 Pocket Model Hearing Aid (Black)
- 1 AA Battery (included)
- Earbud



Figure 1.1: Front view of the AXON F-16 Pocket Model Hearing Aid.

2. Product Features

The AXON F-16 Pocket Model Hearing Aid is engineered for user convenience and effective sound amplification. Key features include:

- **Sleek Design:** Compact and discreet for comfortable wear.
- **Easy to Operate:** Simple controls for straightforward use.
- **Superior Quality:** Constructed for reliable performance.
- **Convenient Size:** Easily fits into a pocket or clips onto clothing.
- **Battery Operated:** Uses standard AA batteries for power.
- **Pocket Model:** Designed for portability and ease of handling.



Figure 2.1: The AXON F-16 Pocket Model Hearing Aid in use, showing its compact design and earbud connection.

3. Setup Guide

3.1 Battery Installation

1. Locate the battery compartment on the side of the hearing aid.
2. Gently slide open the battery compartment cover.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

3.2 Connecting the Earbud

1. Identify the earbud cable and the corresponding port on the hearing aid unit.
2. Carefully insert the earbud connector into the port until it is firmly seated.
3. Select an earbud tip size that fits comfortably and securely in your ear canal.



Figure 3.1: Side view of the AXON F-16, illustrating the battery compartment and control switches.



Figure 3.2: The AXON F-16 with the earbud properly connected.

4. Operating Instructions

4.1 Power On/Off

To turn the hearing aid **ON**, slide the power switch (labeled 'O' for Off and 'I' for On) to the 'I' position. To turn it **OFF**, slide the switch to the 'O' position. Always turn off the device when not in use to conserve battery life.

4.2 Volume Adjustment

The hearing aid features a rotary volume control. Rotate the wheel upwards to increase the volume and downwards to decrease it. Start with a low volume setting and gradually increase it to a comfortable level.

4.3 Frequency Adjustment (N/H/PC Switch)

The device includes a switch for multiple frequency adjustments to suit different listening environments:

- **N (Normal):** Standard listening mode for general environments.
- **H (High):** Enhances high-frequency sounds, useful in situations where clarity of speech is important.
- **PC (Power Control):** Provides maximum amplification for severe hearing loss. Use with caution and adjust volume carefully.

Experiment with these settings to find the most suitable mode for your specific needs and environment.

5. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your hearing aid.

5.1 Cleaning

- Regularly clean the earbud with a soft, dry cloth to remove earwax and debris.
- Do not use water or cleaning solutions directly on the hearing aid unit. Use a dry, soft cloth for cleaning the main unit.
- Ensure the earbud is completely dry before reattaching it to the unit.

5.2 Battery Replacement

Replace the AA battery when the sound becomes weak or distorted, or if the device stops functioning. Refer to Section 3.1 for battery installation instructions.

5.3 Storage

- When not in use, turn off the hearing aid and store it in a cool, dry place.
- Remove the battery if the device will not be used for an extended period to prevent battery leakage.
- Keep the device away from direct sunlight, high temperatures, and moisture.

6. Troubleshooting

If you encounter issues with your AXON F-16 Hearing Aid, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
No sound or very weak sound	• Battery is dead or incorrectly inserted. • Volume is set too low. • Earbud is blocked by earwax or debris. • Earbud connection is loose.	• Replace battery or reinsert correctly. • Increase volume gradually. • Clean the earbud thoroughly. • Ensure earbud is securely connected.
Sound is distorted or unclear	• Low battery. • Earbud is dirty. • Incorrect frequency setting.	• Replace battery. • Clean the earbud. • Adjust the N/H/PC switch to a different setting.
Whistling or feedback sound	• Earbud not properly seated in the ear. • Volume is too high.	• Re-insert the earbud to ensure a snug fit. • Reduce the volume.

7. Specifications

- **Model Number:** F16
- **Dimensions (LxWxH):** 4 x 1 x 6 cm
- **Item Weight:** 27 g
- **Battery Type:** 1 x AA battery (included)
- **Manufacturer:** OCTUS LIFECARE PRIVATE LIMITED

8. Warranty and Support Information

Please note the following important information regarding your AXON F-16 Pocket Model Hearing Aid:

- This product is manufactured in China.
- **There is NO WARRANTY and NO GUARANTEE provided with this product.**
- **This product is NOT RETURNABLE and NOT EXCHANGABLE.**
- The seller commits to providing a new unit as received from the company in case of initial defect.

For any inquiries or assistance, please refer to the seller's contact information provided at the point of purchase.

© 2024 AXON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00LQCO3WW

More documents and user manuals: **https://manuals.plus/**