Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Port Authority TW51

Port Authority Grommeted Golf Towel User Manual

Model: TW51

Brand: Port Authority

Introduction

The Port Authority Grommeted Golf Towel (Model TW51) is designed to provide golfers with a luxurious and functional accessory for maintaining clean clubs and dry hands on the course. Crafted from 100% cotton terry velour, this towel offers superior absorbency and a soft feel. Its integrated silver grommet and hook allow for convenient attachment to your golf bag.

Product Features

- **Material:** 100% cotton terry velour for luxurious feel and performance.
- **Design:** Fully hemmed edges for a clean and durable finish.
- **Attachment:** Features a silver grommet and hook for easy hanging on a golf bag.
- **Dimensions:** Measures 16 inches by 26 inches.
- **Weight:** Approximately 3.5 lbs per dozen (for bulk reference).



Image: The Port Authority Grommeted Golf Towel in white, featuring the silver grommet and hook for attachment.

Setup and Attachment

The Port Authority Golf Towel is ready for immediate use. To attach it to your golf bag:

1. Locate the silver grommet on one corner of the towel.
2. Use the attached hook to clip the towel securely to a D-ring, loop, or handle on your golf bag.
3. Ensure the towel hangs freely and does not obstruct access to your clubs or pockets.

Operating Instructions

This golf towel is designed for effective cleaning and drying during your golf round.

- **Club Cleaning:** Use the towel to wipe dirt, grass, and debris from your golf club faces and grooves after each shot. For stubborn dirt, slightly dampen a portion of the towel.
- **Ball Cleaning:** Dampen a small section of the towel to clean your golf ball before putting or after retrieving it from a dirty lie.
- **Hand Drying:** Use a dry section of the towel to keep your hands dry, especially in humid conditions or after handling wet equipment.

Maintenance and Care

Proper care will extend the life and performance of your golf towel.

- **Washing:** Machine wash the towel with like colors. Use cold or warm water.
- **Detergent:** Use a mild detergent. Avoid harsh chemicals or bleach, which can damage the fabric.
- **Drying:** Tumble dry on low heat or hang to air dry. Avoid high heat, which can cause shrinkage or damage to the terry velour.
- **Ironing:** Do not iron.

Troubleshooting

Issue	Possible Cause / Solution
Towel not cleaning effectively.	Ensure the towel is clean before use. For stubborn dirt, slightly dampen a section of the towel.
Towel feels stiff after washing.	Avoid using too much detergent or fabric softener. Ensure thorough rinsing. Tumble drying with dryer balls can help maintain softness.
Grommet or hook appears loose.	Inspect the grommet and hook regularly for wear. If significantly damaged, consider replacing the towel to prevent loss.

Specifications

Attribute	Detail
Model Number	TW51
Brand	Port Authority
Material	100% Cotton Terry Velour
Color	White
Dimensions (L x W)	26 inches x 16 inches
Item Weight	5.28 Ounces (approx. 0.33 lbs)
Care Instructions	Machine Wash
Special Feature	Silver Grommet and Hook
UPC	191265012416, 643617068324



Image: Diagram illustrating the dimensions of the golf towel: 26 inches in length and 16 inches in width.

Warranty and Support

This product is designed for durability and performance. While specific warranty details are not provided in this manual, please refer to the retailer's return policy or contact Port Authority directly for any product-related inquiries or support needs.
For general product information, you may visit the official Port Authority brand store:Port Authority Store.

© 2024 Port Authority. All rights reserved.
Manual Version: 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00MFQJLDE

More documents and user manuals: **https://manuals.plus/**