Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EZ-FIT FIREPLACE DOORS 42

EZ-FIT FIREPLACE DOORS Superior-Lennox Prefab Fireplace Door (42" Models) Instruction Manual

Brand: EZ-FIT FIREPLACE DOORS | Model: 42"

1. Introduction

This manual provides essential information for the safe and effective installation, operation, and maintenance of your EZ-FIT FIREPLACE DOORS Superior-Lennox Prefab Fireplace Door. This product is specifically designed for certain Superior brand fireplace models to enhance safety, efficiency, and the aesthetic appeal of your living space.



Image: Superior-Lennox Prefab Fireplace Door with a sleek black frame and clear glass panels.

2. Important Safety Information

- **Fireplace doors must be fully opened while fire is burning.**Closing the glass doors during active burning can cause heat buildup, potentially leading to glass shattering.
- The doors feature tempered 3/16" clear glass with safe finished edges, providing a barrier against sparks and embers.
- Ensure proper ventilation as per your fireplace manufacturer's guidelines.

3. Product Overview and Features

The EZ Door is a custom-built fireplace door system designed for prefab/zero-clearance fireplaces. It offers a premium look and functionality at a competitive cost. Key features include:

- Smooth-operating tracked bi-fold doors that open a full 90 degrees.

- Sleek 1 1/8" matte black anodized-aluminum frame.
- Tempered 3/16" clear glass for safety and visibility.
- Designed to prevent cold drafts and improve fireplace efficiency.




Image: Detailed view of the fireplace door components, highlighting the 1 1/8" frame width, 3/16" tempered safety glass, and bifold track doors.

4. Measuring and Ordering

IMPORTANT: Order by the fireplace's make and model number, not by general dimensions.
This door is specifically made for "Superior" Model Numbers: BCF4385, BRF4375, B943, B1043, B1243, CF4360, CHD43, HC4320, HC4320A, HCE4550A, KC43, KC43-2, KR43, RD4300, RD4300A, SHC43, 1043. It will not fit any other fireplace models.
Locate the metal tag displaying the make and model number inside your firebox. This is crucial for ensuring a correct fit.



Image: A warning emphasizing to order by make and model, not by size, as these doors are not universal.



Image: Diagram illustrating that the fireplace door is designed for a specific model number.

Video: How to Order Fireplace Doors

Your browser does not support the video tag.

Video Description: This video provides detailed instructions on how to correctly identify your fireplace model and order the appropriate doors, emphasizing the importance of using the metal tag for accurate information.

5. Setup and Installation

The EZ Door is designed for easy installation, typically requiring only a screwdriver and drill. It is an inside-fit only system.

Video: How to Install Prefab Fireplace Doors

Your browser does not support the video tag.

Video Description: This video demonstrates the step-by-step process of installing the prefab fireplace doors, including preparing the opening and securing the frame.

Video: The EZ Door: Exact Fit, Easy Install, Clean Look for Any Prefab Fireplace

Your browser does not support the video tag.

Video Description: A short overview highlighting the exact fit, ease of installation, and clean aesthetic of the EZ Door for prefab fireplaces.

6. Operating Instructions

Your fireplace door features bi-fold glass doors and internal mesh screens for versatile operation.

- **Opening Glass Doors:** Gently pull the handles on the glass panels to open them outwards. The bi-fold design allows them to open up to 90 degrees.
- **Closing Glass Doors:** Push the glass panels back into place until they meet in the center. Ensure they are fully closed when the fireplace is not in use to prevent drafts.
- **Using Mesh Screens:** The internal mesh screens can be opened or closed independently of the glass doors. These provide an additional layer of protection against sparks when the glass doors are open.
- **During Fire Operation:** Always ensure glass doors are fully open when a fire is burning. The mesh screens can remain closed for spark protection.



Image: A fireplace with its bi-fold glass doors fully open, revealing the interior with a fire burning and mesh screens closed.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your fireplace doors.

- **Cleaning Glass:** Use a non-abrasive glass cleaner specifically designed for fireplace glass to remove soot and grime. Avoid harsh chemicals that could damage the glass or frame.

- **Cleaning Frame:** Wipe the matte black anodized-aluminum frame with a soft, damp cloth. Avoid abrasive cleaners.
- **Checking Mechanisms:** Periodically inspect the bi-fold tracks and hinges for any debris or signs of wear. Ensure smooth operation of both the glass doors and mesh screens.

8. Troubleshooting

If you encounter issues with your fireplace doors, consider the following:

- **Door Alignment:** If doors do not align perfectly, minor adjustments may be needed. Refer to the video below for guidance.
- **Fit Notes:** The listed dimensions (42 5/8" x 21") correspond to the fireplace opening size. The actual product dimensions you receive may be slightly smaller (up to 1/4") to accommodate installation adjustments. Evenly spaced gaps on either side of the doors are intentionally designed to ensure optimal functionality and reduce heat loss. These size adjustments are tailored to your specific model and are not defects.

Video: How to Adjust a Prefab Fireplace Door (Door Alignment)

Your browser does not support the video tag.

Video Description: This video provides instructions on how to adjust the alignment of your prefab fireplace doors to ensure a proper fit and smooth operation.




Image: Important buying tips for fireplace doors, including factors to consider like fascia interference, existing tracks, damper handles, and verifying the correct make and model number.

9. Specifications

Attribute	Detail
Brand	EZ-FIT FIREPLACE DOORS
Material	Aluminum
Color	Black
Product Dimensions (Fireplace Opening)	42.63"L x 21"W
Finish Type	Powder Coated

Style	Contemporary

10. Warranty and Support

The EZ Fireplace Door comes with a 2-year warranty against defects in materials, workmanship, and glass. For any questions or measurement assistance, please contact our support team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NMF05LY

More documents and user manuals: **https://manuals.plus/**