Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 1103666

Coleman 16 oz. Propane Cylinder Instruction Manual

Model: 1103666

1. Introduction

This manual provides essential information for the safe and effective use of your Coleman 16 oz. Propane Cylinder. Please read all instructions and safety warnings carefully before use. This product is designed for use with portable propane appliances such as camping stoves, lanterns, and grills.





Figure 1: Coleman 16 oz. Propane Cylinder. This image shows a green 16 oz. propane cylinder with a black cap. The label features the Coleman logo, 'PROPANE CAMPING GAS', and important safety warnings regarding flammability, explosion, and carbon monoxide hazards. The net weight is indicated as 16 oz. / 453 g (1 lb.).

2. Important Safety Information

DANGER: EXTREMELY FLAMMABLE. FIRE/EXPLOSION HAZARD. CONTENTS UNDER PRESSURE. CARBON MONOXIDE HAZARD.

- Use only with appliances designed for propane gas.
- Read and follow all safety warnings on the cylinder label and appliance manual.
- Ensure adequate ventilation when using this product.
- Never drop or throw cylinders.
- Store in a cool, dry, well-ventilated area, away from direct sunlight and heat sources.
- Keep out of reach of children.
- Do not puncture, incinerate, or expose to temperatures above 120°F (49°C).
- Check for leaks before and during use. Apply soapy water to connections; bubbles indicate a leak.

3. Setup

1. **Prepare Appliance:** Ensure your propane appliance (e.g., stove, lantern, grill) is in the 'OFF' position and cool to the touch.
2. **Remove Cap:** Unscrew and remove the black protective cap from the top of the propane cylinder.
3. **Attach Cylinder:** Hold the cylinder upright. Carefully screw the cylinder into the appliance's regulator or connection point. Turn clockwise until hand-tight. Do not overtighten.
4. **Check for Leaks:** After attaching, perform a leak test. Apply a small amount of soapy water to the connection point. If bubbles appear, there is a leak. Tighten the connection slightly and retest. If the leak persists, do not use the appliance and contact customer support.

4. Operating Instructions

1. **Ignition:** Follow the specific ignition instructions provided in your appliance's user manual. Generally, this involves turning the appliance control knob to a low setting and then activating the igniter (if present) or using a long-stemmed lighter to light the burner.
2. **Adjust Flame:** Once lit, adjust the flame to your desired intensity using the appliance's control knob.
3. **Outdoor Use:** This propane cylinder is ideal for outdoor use with compatible appliances for cooking, grilling, heating, and lighting.

5. Maintenance

- **Inspection:** Regularly inspect the cylinder for any signs of damage, dents, rust, or corrosion. Do not use a damaged cylinder.
- **Storage:** Store cylinders in a cool, dry, well-ventilated outdoor area, away from heat sources, open flames, and direct sunlight. Keep the protective cap on when not in use.
- **Disposal:** Dispose of empty cylinders according to local regulations. Do not refill these cylinders.

6. Troubleshooting

- **No Gas Flow:** Ensure the cylinder is properly attached and hand-tightened. Check if the appliance's control knob is fully open.
- **Weak Flame:** Verify the cylinder is not empty. Ensure there are no obstructions in the appliance's gas line or burner.
- **Gas Leak:** If you detect a gas leak (smell of gas, hissing sound, or bubbles during a soapy water test), immediately turn off the appliance, disconnect the cylinder in a well-ventilated area, and move away from any ignition sources. Do not use the cylinder or appliance until the leak is resolved by a qualified professional.

7. Specifications

Feature	Detail
Brand	Coleman
Model Number	1103666
Fuel Type	Liquefied Petroleum Gas
Material	Alloy Steel
Net Weight (per cylinder)	16 oz. / 453 g (1 lb.)
Product Dimensions (Case of 6)	12.25"L x 8.25"W x 8.25"H
UPC	066511039687

8. Product Videos

No official seller-created videos are available for this product in the provided data.

9. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your Coleman appliance or visit the official Coleman website. Specific warranty details for fuel cylinders may vary.

© 2026 Coleman. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NVUUPEM

More documents and user manuals: **https://manuals.plus/**