Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Synology DS215j

Synology Disk Station DS215j User Manual

Model: DS215j

1. Product Overview

The Synology Disk Station DS215j is a 2-bay Network Attached Storage (NAS) server engineered for home and personal users. It provides a centralized solution for data storage, effortless file sharing, and multimedia streaming across your network. The DS215j is powered by a dual-core CPU, enhancing its performance for various tasks, including multimedia processing with its floating-point unit.
Key features include:

- Personal Cloud Server powered by Dual-Core CPU
- Floating Point Unit Enabled for Multimedia Processing
- DLNA-Certified Media Server for seamless streaming
- Features USB 3.0 for high-speed data transfer
- Runs on Synology Disk Station Manager (DSM) operating system



Figure 1: Front-left view of the Synology DS215j, showing the status, LAN, and disk indicator lights, along with the power button.

2. Setup Guide

2.1 Hardware Installation

1. **Prepare Hard Drives:** Ensure you have compatible 3.5-inch or 2.5-inch SATA hard drives. For optimal performance and data redundancy, it is recommended to use NAS-specific drives.
2. **Install Hard Drives:** Carefully slide the hard drives into the drive bays until they click into place. Secure them with screws if required by your drive caddy.
3. **Connect Network Cable:** Connect one end of an Ethernet cable to the LAN port on the back of the DS215j and the other end to your router or switch.
4. **Connect Power Adapter:** Plug the power adapter into the DC In port on the back of the DS215j, then plug the other end into a power outlet.
5. **Power On:** Press the power button on the front panel to turn on the DS215j. The STATUS LED will blink green when booting up.



Figure 2: Rear view of the Synology DS215j, highlighting the USB 3.0, USB 2.0, LAN, and power input ports, along with the cooling fan.

2.2 Software Installation (Synology Disk Station Manager - DSM)

After hardware installation, you will need to install the Synology Disk Station Manager (DSM) operating system.

1. **Launch Web Browser:** Open a web browser on a computer connected to the same network as your DS215j.
2. **Access Web Assistant:** In the address bar, type http://find.synology.com or http://diskstation:5000. The Synology Web Assistant will automatically detect your DS215j.
3. **Install DSM:** Follow the on-screen instructions to install DSM. This process will download the latest DSM version from Synology's website and install it on your NAS. Ensure your internet connection is stable during this step.
4. **Create Administrator Account:** After DSM installation, you will be prompted to create an administrator account. Set a strong password for security.
5. **Configure Storage:** Once logged into DSM, navigate to *Storage Manager* to create storage pools and volumes. This is where you configure RAID types (e.g., Basic, RAID 1, SHR) and allocate storage space.

3. Operating the DS215j

3.1 Basic Functions

- **File Station:** Manage and access your files from any web browser. You can upload, download, move, copy, and share files and folders.
- **Shared Folders:** Create shared folders to organize your data and set user permissions for access control.
- **User Accounts:** Create individual user accounts and groups to manage access rights to shared folders and applications.

3.2 Multimedia Streaming

The DS215j functions as a DLNA-certified media server, allowing you to stream photos, music, and videos to compatible devices on your network, such as smart TVs, media players, and game consoles.

- **Video Station:** Organize your video collection and stream them to various devices.
- **Audio Station:** Manage your music library and stream audio to DLNA renderers, AirPlay devices, or USB speakers.
- **Photo Station:** Create photo albums, share them with others, and view them on your devices.

3.3 Cloud Synchronization and Backup

Utilize the DS215j for personal cloud synchronization and data backup.

- **Cloud Station Server:** Synchronize files between your DS215j and multiple client devices (computers, mobile devices).
- **Hyper Backup:** Back up data from your DS215j to various destinations, including external USB drives (via USB 3.0 port), remote Synology NAS, rsync servers, or public cloud services.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Synology DS215j.

- **DSM Updates:** Periodically check for and install DSM updates via *Control Panel > Update & Restore*. Updates often include security patches, bug fixes, and new features.
- **Drive Health Check:** Monitor the health of your hard drives in *Storage Manager > HDD/SSD*. Run S.M.A.R.T. tests regularly to detect potential drive issues early.
- **System Logs:** Review system logs in *Log Center* for any warnings or errors that may indicate underlying issues.
- **Physical Cleaning:** Ensure the device is kept in a well-ventilated area. Periodically clean dust from the fan vents using compressed air to prevent overheating.
- **Data Backup:** Always maintain regular backups of your critical data to an external destination, even with RAID configured.

5. Troubleshooting

This section addresses common issues you might encounter with your DS215j.

- **Cannot Find DS215j on Network:**
    - Ensure the Ethernet cable is securely connected to both the NAS and your router/switch.
    - Verify that the LAN LED on the front panel is lit.

- Try restarting your router and the DS215j.
- Temporarily disable any firewall software on your computer.

- **STATUS LED Blinking Orange:**
  - This usually indicates a system warning, such as a degraded volume or a fan error.
  - Log into DSM and check *Storage Manager* for disk status or *Log Center* for system messages to identify the specific issue.
- **Slow Performance:**
  - Check network cable and ensure it's a Gigabit Ethernet connection.
  - Monitor resource utilization (CPU, RAM, Disk I/O) in *Resource Monitor* within DSM.
  - Ensure hard drives are healthy and not experiencing errors.
- **Forgotten Administrator Password:**
  - Use the RESET button on the back of the unit (pinhole) to reset the administrator password and network settings without erasing data. Refer to the Synology website for detailed instructions on the reset procedure.

For more detailed troubleshooting steps and solutions, please refer to the official Synology Knowledge Base online.

6. Specifications

Feature	Specification
Model Number	DS215j
Product Dimensions	8.88 x 3.94 x 6.5 inches
Item Weight	5 pounds
Brand	Synology
Color	Gray; white
Material	Metal
Compatible Devices	PC; Mac
Manufacturer	Synology America Corp

7. Warranty and Support

7.1 Warranty Information

The Synology DS215j comes with a limited warranty. For detailed information regarding the warranty period, terms, and conditions, please refer to the warranty card included with your product or visit the official Synology website.

7.2 Technical Support

For technical assistance, product inquiries, or support resources, please visit the official Synology support website. You can find FAQs, knowledge base articles, and contact information for their support team.
Official Synology Support: https://www.synology.com/support

© 2024 Synology Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00OZ0CTAU

More documents and user manuals: **https://manuals.plus/**