Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BR64195614

Braun BR64195614 Worm Screw for Meat Grinders - Instruction Manual

1. Product Overview

This document provides instructions for the Braun BR64195614 worm screw, a replacement component for various Braun meat grinder models. This part is essential for the proper functioning of your meat grinder, facilitating the feeding of meat towards the cutting blade.



Image 1: The Braun BR64195614 worm screw, a metallic helical component designed to propel food through the meat grinder mechanism.

2. Safety Information

- Always ensure the meat grinder is unplugged from the power source before attempting any installation, removal, or cleaning of parts.
- Handle all components with care to avoid injury. The worm screw may have sharp edges.

- Keep replacement parts out of reach of children.
- Use only genuine Braun replacement parts to ensure compatibility and maintain appliance safety standards.

3. Compatibility

The Braun BR64195614 worm screw is compatible with the following Braun meat grinder models:

- KGZ3
- KGZ4
- KGZ31
- G1100
- G1300
- G1500
- G3000
- Multiquick 3
- Multiquick 5
- Multiquick 7
- PowerPlus 1100
- PowerPlus 1300

Verify your meat grinder's model number before installation to ensure correct fit.

4. Installation Instructions

Follow these steps to install the worm screw:

1. **Preparation:** Ensure the meat grinder is unplugged and completely disassembled according to your appliance's main instruction manual.
2. **Remove Old Part:** Carefully remove the existing worm screw from the grinder housing.
3. **Insert New Part:** Place the Braun BR64195614 worm screw into the grinder housing, ensuring it aligns correctly with the motor shaft and the internal components. The ribbed end should connect to the motor drive.
4. **Reassemble:** Reassemble the remaining parts of your meat grinder (blade, grinding plate, locking ring, etc.) as per your appliance's original manual.
5. **Test:** Once fully reassembled, plug in the appliance and perform a brief test run without food to confirm proper operation.

5. Maintenance and Cleaning

To ensure longevity and hygienic operation of your worm screw and meat grinder:

- **Immediate Cleaning:** After each use, disassemble the meat grinder and remove the worm screw. Wash it immediately to prevent food residue from drying on the surface.
- **Washing:** Wash the worm screw by hand using warm, soapy water and a brush to remove all food particles. Rinse thoroughly under running water.
- **Drying:** Dry the worm screw completely with a soft cloth before storing to prevent corrosion.
- **Storage:** Store the worm screw in a dry place, preferably with other meat grinder components.

6. Troubleshooting

If you experience issues after installing the new worm screw, consider the following:

Appliance Not Operating:

- Ensure the worm screw is correctly seated and aligned with the motor shaft.
- Verify all other meat grinder components are correctly assembled and the locking mechanism is engaged.
- Check if the appliance is properly plugged into a functional power outlet.

Poor Grinding Performance:

- Confirm the cutting blade is sharp and correctly installed against the grinding plate.
- Ensure the grinding plate is clean and free of obstructions.
- Verify the worm screw is not damaged or bent.

If problems persist, consult the main instruction manual for your specific Braun meat grinder model or contact Braun customer support.

7. Specifications

Feature	Detail
Part Name	Worm Screw
Model Number	BR64195614
Brand	Braun
Material	Metal (typically stainless steel or aluminum alloy)
Compatibility	Braun Meat Grinder Models: KGZ3, KGZ4, KGZ31, G1100, G1300, G1500, G3000, Multiquick 3/5/7, PowerPlus 1100/1300

8. Warranty and Support

This replacement part is subject to the warranty terms and conditions provided by Braun or the retailer at the time of purchase. Please refer to your purchase documentation for specific warranty details.

For further assistance, technical support, or to inquire about other replacement parts, please visit the official Braun website or contact their customer service department. Contact information can typically be found in your original appliance manual or on the Braun website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00OZLMFRQ

More documents and user manuals: **https://manuals.plus/**