Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire B00P84EW5M

FRIGIDAIRE 4.5 Cubic Feet Compact Fridge User Manual

Model: B00P84EW5M

1. Important Safety Information

Read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the appliance is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2. Product Overview

The FRIGIDAIRE 4.5 Cubic Feet Compact Fridge is designed for efficient cooling in a compact form factor. It features a stainless steel finish, an internal freezer, and adjustable components for versatile storage.



Figure 2.1: Front view of the Frigidaire Compact Fridge. This image shows the sleek stainless steel door with the Frigidaire logo on the upper right, and the black top and bottom trim.

Key Features:

- 4.5 Cu Ft Capacity
- Stainless Steel Finish
- Compressor Cooled with Space Saving Flush Back Design
- Built-in Can Dispenser and Freezer with Ice Tray
- Tempered Glass Shelves
- Adjustable Thermostat
- Reversible Door (Allows for Right or Left Opening)
- Adjustable Leveling Feet



Figure 2.2: Interior view of the Frigidaire Compact Fridge. This image displays the internal layout, including the tempered glass shelves, door storage for bottles and cans, and the small freezer compartment at the top.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials, including the foam base and adhesive tape. Keep packaging materials until you are sure the appliance is working correctly. Dispose of packaging materials responsibly.

3.2 Placement

Choose a location with a strong, level floor that can support the weight of the refrigerator when fully loaded. Ensure there is adequate ventilation around the unit. Avoid direct sunlight or heat sources.

- Allow at least 4 inches (10 cm) of space at the back and sides for proper air circulation.
- The appliance dimensions are approximately 22.24"D x 20.31"W x 32.06"H.



Figure 3.1: Dimensional view of the Frigidaire Compact Fridge. This image provides key measurements for depth, width, and height, essential for proper placement and installation.

3.3 Leveling the Appliance

The refrigerator has adjustable leveling feet. Turn the feet clockwise to raise the unit and counter-clockwise to lower it. Ensure the appliance is level to prevent vibrations and ensure proper door sealing.

3.4 Electrical Connection

Plug the refrigerator into a dedicated, grounded 115V, 60Hz AC outlet. Do not use extension cords or adapter plugs. Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

4. Operating Instructions

4.1 Initial Start-up

After plugging in the unit, allow it to cool for approximately 2-3 hours before placing food inside. This ensures the

interior reaches the desired temperature.

4.2 Temperature Control

The refrigerator is equipped with an adjustable thermostat. The thermostat dial is typically located inside the fresh food compartment. Turn the dial to adjust the cooling intensity. Higher numbers usually indicate colder temperatures.

- Start with a medium setting (e.g., '3' or '4') and adjust as needed based on ambient temperature and food load.
- Allow several hours for the temperature to stabilize after each adjustment.

4.3 Door Reversal

The door of this refrigerator is reversible, allowing it to open from either the right or left side. Refer to the detailed diagram and instructions in the full manual for the door reversal procedure. This typically involves removing hinges and reattaching them on the opposite side.



Figure 4.1: Left side view of the Frigidaire Compact Fridge. This image shows the side panel and the hinge mechanism at the top and bottom, which can be reversed for left-hand opening.



Figure 4.2: Right side view of the Frigidaire Compact Fridge. This image shows the side panel and the hinge mechanism at the top and bottom, which can be reversed for right-hand opening.

5. Maintenance and Care

5.1 Cleaning

Regular cleaning helps maintain the efficiency and appearance of your refrigerator.

- **Interior:** Unplug the unit. Wash interior surfaces with a solution of two tablespoons of baking soda to one quart of warm water. Rinse and dry thoroughly.
- **Exterior:** Clean the exterior with a mild detergent and warm water. Wipe dry with a soft cloth.
- **Door Gasket:** Clean the door gasket regularly to ensure a proper seal.

5.2 Defrosting

This refrigerator features an automatic defrost system. However, if ice buildup occurs in the freezer compartment, manual defrosting may be necessary. To manually defrost:

1. Unplug the refrigerator.

2. Remove all food items and place them in a cooler.
3. Leave the door open to allow ice to melt naturally. Place towels at the bottom to absorb water.
4. Once defrosted, clean and dry the interior before plugging the unit back in.

5.3 Power Outage

In case of a power outage, keep the refrigerator door closed to maintain temperature for as long as possible. Avoid opening the door unnecessarily.

6. Troubleshooting

Before contacting customer service, review this section for common issues and their solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "OFF".	Ensure plug is secure; reset circuit breaker; adjust thermostat to a colder setting.
Temperature is too warm.	Door opened too frequently; large amount of warm food added; poor ventilation; thermostat setting too high.	Minimize door openings; allow warm food to cool before placing in fridge; ensure proper clearance around unit; lower thermostat setting.
Excessive frost buildup.	Door not sealed properly; high humidity; frequent door openings.	Check door gasket for proper seal; avoid leaving door open for extended periods.
Noisy operation.	Unit not level; objects vibrating against the unit; normal compressor sounds.	Adjust leveling feet; ensure nothing is touching the back or sides; some sounds are normal.




Figure 6.1: Rear view of the Frigidaire Compact Fridge. This image shows the compressor unit at the bottom rear, along with warning labels for R600a refrigerant and C-PENTANE, indicating the type of refrigerant and insulation used.

7. Specifications

Feature	Detail
Product Dimensions	22.24"D x 20.31"W x 32.06"H
Brand	Frigidaire
Capacity	4.5 Cubic Feet
Configuration	Compact Internal Freezer
BEE Star Rating	5 Star
Color	Stainless Steel
Special Feature	Compact

Feature	Detail
Installation Type	Freestanding
Number of Doors	1
Defrost System	Automatic

8. Warranty and Customer Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Frigidaire website. Keep your purchase receipt for warranty claims.

For further assistance, you may contact Frigidaire customer service through their official channels. Please have your model number (B00P84EW5M) and purchase date ready when contacting support.

Online Resources: Frigidaire Brand Store on Amazon

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00P84EW5M

More documents and user manuals: **https://manuals.plus/**