Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 241778307

Kenmore 241778307 Refrigerator Door Gasket Instruction Manual

Model: 241778307 | Brand: Frigidaire

Introduction

This manual provides essential information for the installation, maintenance, and troubleshooting of the Kenmore 241778307 Refrigerator Door Gasket. This manufacturer-approved part is designed for refrigerators to create a seal around the inner door panel, preventing warm air from entering the refrigerator compartment. Proper functioning of the door gasket is crucial for maintaining optimal refrigerator temperature and energy efficiency.




Figure 1: Illustrative diagram of the Kenmore 241778307 Refrigerator Door Gasket, showing its rectangular shape and sealing profile.

Installation

Before beginning the installation process, ensure the refrigerator is unplugged from the power source to prevent accidental activation. It is also recommended to safely store any food items that could deteriorate while the refrigerator door is open during this repair.

Required Tools:

- No special tools are typically required as the gasket is designed for channel insertion.

Installation Steps:

1. **Preparation:** Unplug the refrigerator. Open the refrigerator door fully to access the old gasket.

2. **Old Gasket Removal:** Locate the channel holding the old gasket. Starting from one corner of the door, gently pull the old gasket away from the channel. The gasket is typically held in place by friction within this channel, without screws or clamps. Continue pulling around the entire perimeter of the door until the old gasket is completely removed.
3. **New Gasket Installation:** Align the new Kenmore 241778307 door gasket with the channel on the inner door panel. Begin by pressing one section of the gasket firmly into the channel, ensuring it is fully seated. Work your way around the entire door, pushing the gasket into the channel until it is securely in place.
4. **Sealing Check:** Once the new gasket is installed, close the refrigerator door and check for any gaps or areas where the gasket is not fully sealed against the refrigerator frame. If gaps are present, gently press and "massage" the gasket into the channel to ensure a complete and tight seal. This may involve applying gentle pressure along the gasket's length to help it conform to the door frame.
5. **Final Step:** Plug the refrigerator back into the power source.



Figure 2: The Kenmore 241778307 Refrigerator Door Gasket, ready for installation.

Maintenance

Regular maintenance of your refrigerator door gasket helps ensure its longevity and optimal performance.

- **Cleaning:** Periodically clean the gasket with a mild soap and warm water solution. Use a soft cloth to wipe away any food spills or debris. Rinse thoroughly with clean water and dry completely to prevent mold or mildew growth.
- **Inspection:** Regularly inspect the gasket for signs of wear, cracks, tears, or hardening. A damaged gasket can compromise the refrigerator's seal and lead to energy inefficiency.
- **Flexibility:** If the gasket feels stiff, you can gently warm it with a hairdryer on a low setting (from a safe distance) to help restore some flexibility, which can improve its sealing capability.

Troubleshooting

If you experience issues after installing the new door gasket, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Door does not seal completely / Gaps visible	Gasket not fully seated in the channel; Gasket needs to conform to the door frame; Gasket is not magnetic enough (less common for new gaskets).	Ensure the gasket is pushed completely into its retaining channel around the entire door. Gently "massage" or press the gasket along its length to help it relax and conform to the door frame, especially after initial installation. If the issue persists, verify the gasket part number matches your refrigerator model exactly.
Condensation forming on the outside of the door	Poor seal allowing warm, humid air to enter and condense on cooler surfaces.	Check the gasket for proper seating and ensure there are no gaps. Clean the gasket and door frame thoroughly to remove any debris that might prevent a tight seal. Perform the "paper test": Close the door on a piece of paper. If the paper slides out easily, the seal is weak in that area. Adjust the gasket or consider if the door hinges need adjustment (though less common for gasket issues).

Specifications

Attribute	Detail
Brand Name	Frigidaire
Model Number	241778307
Item Weight	1.45 pounds
Product Dimensions	14.4 x 6.7 x 6.4 inches
Part Number	241778307
Date First Available	June 6, 2013

Warranty Information

Specific warranty details for the Kenmore 241778307 Refrigerator Door Gasket are typically provided by the manufacturer, Frigidaire, or the retailer at the time of purchase. Please refer to your purchase documentation or contact Frigidaire directly for comprehensive warranty coverage information.

Customer Support

For further assistance, technical support, or to inquire about replacement parts, please contact Frigidaire customer service. You can typically find their contact information on their official website or through the documentation that came with your refrigerator appliance.

Note: Always ensure you have your appliance model number and the part number (241778307) ready when contacting support.

© 2025 Frigidaire. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00TRJLSVA

More documents and user manuals: **https://manuals.plus/**