Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Remington TF70CDN

Remington TF70CDN Battery-Operated Foil Travel Shaver User Manual

Model: TF70CDN

Introduction

The Remington TF70CDN Battery-Operated Foil Travel Shaver is designed for convenient and effective shaving. This compact shaver features Dual Foil Technology and surgical steel blades for a smooth shave. It includes an integrated head guard and a built-in cleaning brush for consistent performance and easy maintenance. The Travel Lock feature prevents accidental activation during transport.



Image: Front view of the Remington TF70CDN Battery-Operated Foil Travel Shaver.

Important Safety Information

- Always keep the shaver dry and avoid contact with water. This device is not designed for wet shaving.
- Use the travel lock when the shaver is not in use to prevent accidental activation and conserve battery life.
- Follow the cleaning instructions provided in this manual to prevent bacterial growth and maintain optimal performance.
- Do not attempt to disassemble or repair the shaver yourself. Contact customer support for assistance.
- Keep out of reach of children.

Product Features

- **Dual Foil Technology:** Two durable foils designed for maximum skin contact and a close, comfortable shave.
- **Surgical Steel Blades:** Precision-engineered for an even, smooth shave.
- **Travel Lock:** A secure switch that prevents the shaver from accidentally turning on and draining batteries during travel or

storage.

- **Built-In Cleaning Brush:** Integrated brush for convenient maintenance and cleaning of the shaver head.
- **Integrated Head Guard:** A plastic guard that slides securely over the foils to protect the shaver head during travel.
- **Battery-Operated:** Powered by two AA batteries, with an easily accessible compartment at the bottom of the shaver.



Image: Close-up view highlighting the Dual Foil Technology of the shaver head.

Setup

Battery Installation

1. Locate the battery compartment at the bottom of the shaver.
2. Slide the battery compartment cover open.
3. Insert two AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Illustration showing the battery compartment of the shaver.

Operating Instructions

Turning the Shaver On/Off and Travel Lock

The shaver features an integrated travel lock mechanism. To turn the shaver on, slide the integrated head guard completely open. The shaver will activate automatically. To turn the shaver off, slide the head guard back into its closed position. This action also engages the travel lock, preventing accidental power-on.

▶ **Watch video online**
How to turn on the Remington Travel Shaver?

Video: Demonstration on how to turn on the Remington Travel Shaver by sliding the head guard.



Image: View of the shaver with the integrated head guard, illustrating the travel lock mechanism.

Shaving Technique

- Hold the shaver at a right angle (90 degrees) to your skin.
- For stubborn areas, use slow, circular motions.
- Avoid pressing too hard on the skin, as this can cause irritation and reduce shaving effectiveness.
- Stretch the skin in tough spots to help the foils capture hairs more effectively.

Maintenance and Cleaning

Cleaning the Shaver

To maintain optimal performance and hygiene, clean your shaver after each use.

1. Ensure the shaver is turned off and the travel lock is engaged.
2. Carefully remove the head assembly (foils and cutters).
3. Use the built-in cleaning brush to remove any accumulated hair clippings from the cutters and inside the shaver body.
4. Do not rinse the shaver head or body under water. This shaver is designed for dry use only.
5. Replace the head assembly securely before the next use.



Image: Close-up view of the shaver showing the built-in cleaning brush.

Foil and Cutter Replacement

The shaver foils and cutters are precision components that can wear over time. For best shaving results, it is recommended to replace the screens (foils) approximately every 12 months with daily use. Replacement parts can be purchased from authorized Remington retailers or the official Remington website.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Travel lock engaged. Dead or incorrectly inserted batteries.	Slide the head guard completely open to disengage the travel lock. Check battery polarity and replace with fresh AA batteries if needed.
Poor shaving performance or pulling.	Foil or cutters are dirty. Foil or cutters are worn. Hair is too long.	Clean the shaver head assembly thoroughly using the built-in brush. Replace the foils and cutters if they are worn or damaged. For longer hair, trim it shorter before using the shaver for best results.
Batteries are difficult to remove.	Tight battery compartment design.	Carefully pry out the batteries. This is a known characteristic of the design.

Specifications

- **Model Number:** TF70CDN
- **Power Source:** 2 x AA Batteries (included)
- **Battery Average Life:** Approximately 40 minutes
- **Head Type:** Foil
- **Number of Blades:** 2
- **Blade Material:** Stainless Steel
- **Product Dimensions:** 2.48 x 3.23 x 4.33 inches
- **Item Weight:** 6.4 ounces
- **Color:** Black
- **Manufacturer:** Remington Products

Warranty and Support

For warranty information, product registration, or customer support, please visit the official Remington website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.
You can find more information and products from Remington at their official store:Remington Store.

© 2026 Remington. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00U0X2T1U

More documents and user manuals: **https://manuals.plus/**