TimeMist 1047809

TimeMist 1047809 White Settings Metered Dispenser

Instruction Manual

Introduction

This manual provides comprehensive instructions for the proper installation, operation, and maintenance of your TimeMist 1047809 White Settings Metered Dispenser. Please read this manual thoroughly before using the device to ensure safe and efficient operation.

Safety Information

- Keep the dispenser out of reach of children and pets.
- Do not spray directly onto food, fabrics, or surfaces that may be damaged by fragrance.
- Use only TimeMist brand refills designed for this dispenser.
- Do not expose batteries to extreme heat or dispose of them in fire.
- If the dispenser is damaged, do not attempt to repair it. Contact customer support.
- Ensure proper ventilation when using the dispenser in enclosed spaces.

Product Overview

The TimeMist 1047809 Metered Dispenser is designed to automatically release fragrance at set intervals, maintaining a consistent fresh environment. Key components include:

- **Spray Nozzle:** Where the fragrance is dispensed.
- **Light Sensor:** Detects ambient light to enable day/night operation modes.
- **Control Panel:** Located inside the dispenser for setting spray intervals and light sensor modes.
- **Battery Compartment:** Holds four AA batteries (not included).
- **Refill Canister Slot:** Area for inserting the fragrance refill.

Image 1: Front view of the TimeMist 1047809 White Settings Metered Dispenser. This image displays the front of the dispenser, showing the spray nozzle and the light sensor located above it. The TimeMist brand name is visible at the bottom.

Setup

1. Opening the Dispenser

To access the internal components, gently flip up the front cover of the dispenser. This will reveal the battery compartment and the refill canister slot.

2. Battery Installation

1. Locate the battery compartment inside the dispenser.
2. Insert four (4) AA batteries (not included), ensuring correct polarity (+/-) as indicated in the compartment.
3. The dispenser is designed to operate efficiently for up to two years on a fresh set of batteries.

3. Refill Canister Installation

1. Ensure the dispenser is turned off or in a paused state before inserting a refill.
2. Align the nozzle of the TimeMist 6.6oz aerosol fragrance refill (sold separately) with the dispenser's spray mechanism.

3. Gently push the refill canister into the slot until it is securely seated.

4. Mounting the Dispenser

Mount the dispenser securely on a wall or flat surface using appropriate hardware (not included). Ensure it is placed in an area where the fragrance can disperse effectively and away from direct airflow that might interfere with the light sensor.

Operating Instructions

After installing batteries and a fragrance refill, configure the dispenser settings using the internal controls.

1. Setting Spray Interval

Locate the interval setting switch or dial inside the dispenser. You can choose from the following spray frequencies:

- **7.5 minutes:** For high-traffic areas or stronger fragrance needs.
- **15 minutes:** Standard setting for most environments.
- **30 minutes:** For lighter fragrance needs or smaller spaces.

2. Configuring Light Sensor Mode

The light sensor allows the dispenser to operate only when needed, conserving fragrance and battery life. Select one of the following modes:

- **Light:** Dispenses only when ambient light is detected (daytime operation).
- **Dark:** Dispenses only when ambient light is low or absent (nighttime operation).
- **24 Hours:** Dispenses continuously regardless of light conditions.

3. Battery Level Indicator

The dispenser features indicator lights to show the remaining power level of your batteries. Refer to the internal markings for specific light patterns and their meaning (e.g., green for good, red for low).

4. Closing the Dispenser

Once settings are configured, close the front cover of the dispenser securely. The dispenser will begin operation according to your selected settings.

Maintenance

1. Cleaning

To maintain optimal performance and appearance, periodically wipe the exterior of the dispenser with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.

2. Refill Replacement

When the fragrance level is low or depleted, replace the refill canister. Follow the "Refill Canister Installation" steps in the Setup section. Always use TimeMist 6.6oz refill sprays for proper fit and function.

3. Battery Replacement

Replace all four AA batteries when the low battery indicator illuminates or when the dispenser ceases to operate. Refer to the "Battery Installation" steps in the Setup section.

Troubleshooting

Problem	Possible Cause	Solution
Dispenser not spraying	Batteries are dead or incorrectly installed. Fragrance refill is empty. Dispenser is in "Dark" mode during daylight, or "Light" mode at night. Spray nozzle is blocked.	Replace batteries, ensuring correct polarity. Replace the fragrance refill. Adjust the light sensor mode to "24 Hours" or the appropriate setting for current light conditions. Check and clear any obstruction from the spray nozzle.
Weak or inconsistent spray	Low battery power. Refill canister is nearly empty.	Replace batteries. Replace the fragrance refill.
Dispenser operates continuously (24 hours) but is set to Light/Dark mode	Light sensor is obstructed or malfunctioning.	Ensure the light sensor is clean and unobstructed. If the issue persists, contact customer support.

Specifications

Model Number	1047809
Brand	TimeMist
Color	White
Power Source	4 x AA Batteries (not included)
Product Dimensions	7.75 x 3.25 x 3.25 inches (L x W x H)
Item Weight	15.2 ounces
Spray Intervals	7.5, 15, or 30 minutes
Light Sensor Modes	Light, Dark, or 24 Hours

Warranty Information

For detailed warranty information, please refer to the documentation included with your purchase or visit the official TimeMist website. Warranty terms and conditions may vary.

Customer Support

If you have any questions, require assistance, or need to report an issue with your TimeMist dispenser, please contact TimeMist customer support through their official website or the contact information provided on the product packaging.
Website: www.timemist.com (*Note: This is a placeholder URL, please verify the actual manufacturer's website.*)