Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KraftKids WIC123-4

KraftKids Children's Bench WIC123-4 Instruction Manual

Model: WIC123-4

1. Introduction

Thank you for choosing the KraftKids Children's Bench. This manual provides essential information for the safe assembly, operation, and maintenance of your new children's furniture. Please read these instructions carefully before assembly and retain them for future reference.

Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assembly should be performed by an adult.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- After assembly, ensure all screws and fasteners are securely tightened. Periodically check and re-tighten as necessary.
- The bench is designed for seating and storage. Do not allow children to climb on the backrest or stand on the bench.
- Place the bench on a flat, stable surface to prevent tipping.
- The product features rounded edges for child safety.

2. Package Contents

Verify that all components listed below are included in your package. If any parts are missing, please contact KraftKids customer support.

- Bench components (pre-cut wood panels)
- Assembly hardware (screws, dowels, etc.)
- Seat cushion (if ordered with cushion)



Figure 2.1: Assembly diagram illustrating the individual components (A: Left Side Panel, B: Right Side Panel, C: Base Panel, D: Seat Panel, E: Backrest) and their respective dimensions and screw placement for the KraftKids Children's Bench.

3. Assembly Instructions (Setup)

Follow these steps carefully for proper assembly. Refer to Figure 2.1 for component identification and placement.

1. **Prepare Components:** Unpack all wooden panels and hardware. Identify parts A, B, C, D, and E as shown in the assembly diagram.
2. **Attach Side Panels to Base:** Connect the left side panel (A) and the right side panel (B) to the base panel (C) using the provided screws and dowels. Ensure the pre-drilled holes align correctly.
3. **Install Seat Panel:** Secure the seat panel (D) between the side panels (A and B), above the base panel (C). Use the appropriate screws to fasten it firmly.
4. **Attach Backrest:** Position the backrest (E) at the rear of the bench, aligning it with the side panels (A and B) and the seat panel (D). Fasten it securely with screws. The curved design of the backrest should face upwards.
5. **Final Tightening:** Once all components are assembled, carefully check and tighten all screws to ensure the bench is stable and secure. Do not overtighten.
6. **Place Seat Cushion:** If your bench includes a seat cushion, place it on the seat panel (D).



Figure 3.1: The assembled KraftKids Children's Bench, ready for use, shown without the seat cushion.



Figure 3.2: The assembled KraftKids Children's Bench with the soft seat cushion installed, providing a comfortable seating surface.

4. Usage (Operating)

The KraftKids Children's Bench is designed for versatile use in a child's room or play area.

- **Seating:** Provides a comfortable seating area for children. The included seat cushion enhances comfort.
- **Storage:** The open compartment beneath the seat offers additional space for toys, books, or other items. Decorative baskets (not included) can be used to organize contents.
- **Shoe Rack:** Can be utilized as a shoe rack in an entryway or child's room.



Figure 4.1: The KraftKids Children's Bench integrated into a room, demonstrating its function as both seating and a storage solution for items like shoes.

5. Care and Maintenance

Proper care will ensure the longevity and appearance of your KraftKids Children's Bench.

- **Cleaning the Bench:** Wipe the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish. Dry immediately with a clean cloth.
- **Cleaning the Seat Cushion:** Refer to the care label on the seat cushion for specific cleaning instructions. Typically, spot cleaning with a mild detergent is recommended.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** Do not expose the bench to excessive moisture or direct sunlight for prolonged periods, as this can cause warping or discoloration.

6. Troubleshooting

This section addresses common issues you might encounter.

- **Bench feels wobbly after assembly:**

Ensure all screws are fully tightened. Check that the bench is placed on a level surface. If the issue persists, disassemble and reassemble, paying close attention to alignment.

- **Missing parts:**

  Carefully check all packaging materials. If parts are genuinely missing, contact KraftKids customer support with your model number and a description of the missing components.

7. Specifications

Model:	WIC123-4
Brand:	KraftKids
Material:	16 mm thick Chipboard (Wood)
Color:	White
Overall Dimensions (W x D x H):	80 cm x 28 cm x 50 cm
Seat Height:	26 cm
Seat Depth:	28 cm
Backrest Height (from seat):	24 cm (50 cm total height - 26 cm seat height)
Features:	Rounded edges, curved backrest, integrated storage compartment.

8. Warranty and Support

KraftKids products are manufactured with quality and care. For any questions regarding assembly, missing parts, or product issues, please contact KraftKids customer support. Please have your model number (WIC123-4) available when contacting support.

Specific warranty details may vary. Please refer to your purchase documentation or the KraftKids official website for the most current warranty information.

© 2023 KraftKids. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00WFD9CLS

More documents and user manuals: **https://manuals.plus/**