Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic NI-E410T

Panasonic Steam Iron NI-E410T User Manual

Model: NI-E410T | Brand: Panasonic

Important Safety Instructions

Please read all instructions carefully before using the Panasonic Steam Iron NI-E410T. Keep this manual for future reference.

- Always ensure the iron is connected to a grounded electrical outlet.
- Do not leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron, cord, or plug in water or other liquids.
- Unplug the iron from the outlet when filling with water, emptying, or when not in use.
- Use the iron only for its intended household purpose.
- This appliance operates on 220-240 Volts. Ensure your power supply matches this requirement.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.

Product Overview

The Panasonic Steam Iron NI-E410T is designed for efficient and effective garment care. It features a unique titanium-coated soleplate that concentrates pressure at the center, reducing pulling and wrinkles. With a 200cc water capacity and a steam circulation groove, it ensures quick and easy ironing.



Image: The Panasonic Steam Iron NI-E410T, showcasing its red and white design, titanium-coated soleplate, and power cord.

Key Features:

- Automatic Anti-Calc System: Helps prevent mineral buildup for prolonged performance.
- Curved Titanium-Coated Non-Stick Soleplate: Ensures smooth gliding and even heat distribution.
- Ready Temperature Indicator Light: Illuminates when the desired temperature is reached.
- Large Water Window: Allows for easy monitoring of the water level.
- 2150 Watt Power: Provides rapid heating and strong steam output.

Setup

Unpacking:

1. Carefully remove the iron from its packaging.
2. Remove any protective films or stickers from the soleplate or body of the iron.
3. Retain the packaging for storage or future transport.

First Use Preparation:

1. Before first use, wipe the soleplate with a damp cloth to remove any manufacturing residues.
2. Fill the water tank (refer to 'Filling the Water Tank' in Operating Instructions).
3. Heat the iron to its maximum temperature setting and iron an old piece of fabric for a few minutes to clean the steam vents.

Operating Instructions

Filling the Water Tank:

1. Ensure the iron is unplugged from the power outlet.
2. Open the water filler cap.
3. Using a measuring cup, carefully pour clean tap water into the water inlet until the MAX fill line is reached. The water tank capacity is 200cc.

4. Close the water filler cap securely.

Setting Temperature:

1. Plug the iron into a suitable 220-240V power outlet.
2. Turn the temperature control dial to the desired setting based on the fabric type (e.g., Acrylic, Silk, Wool, Cotton, Linen).
3. The ready temperature indicator light will illuminate while heating and turn off when the set temperature is reached.

Steam Ironing:

1. Ensure the water tank is filled.
2. Set the temperature to a steam-appropriate setting (usually Cotton or Linen). Steam function is only available at higher temperatures.
3. Once the indicator light turns off, slide the steam selector to the desired steam level.
4. Begin ironing, moving the iron smoothly over the fabric.

Dry Ironing:

1. Ensure the water tank is empty or the steam selector is set to the 'Dry' position.
2. Set the temperature control dial to the appropriate setting for your fabric.
3. Wait for the indicator light to turn off before ironing.

Automatic Shut-off:

For safety, the iron is equipped with an automatic shut-off feature. If left motionless in a horizontal position for a certain period, or upright for a longer period, the heating element will automatically turn off. To restart, simply move the iron.

Maintenance and Care

After Each Use:

1. Unplug the iron and allow it to cool completely.
2. Empty any remaining water from the tank by opening the filler cap and tilting the iron over a sink.

Cleaning the Soleplate:

- If the soleplate becomes stained, clean it with a damp cloth and a non-abrasive cleaner designed for iron soleplates.
- Do not use abrasive scouring pads or harsh chemicals as they can damage the titanium coating.

Anti-Calc System:

The iron features an automatic anti-calc system to reduce mineral buildup. For optimal performance, use tap water as recommended. If you live in an area with very hard water, consider using a mixture of tap water and distilled water (50/50 ratio).

Storage:

Store the cooled iron upright on its heel rest in a safe, dry place. Do not wrap the cord tightly around the iron; use the cord clip if provided.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outage; temperature dial set to 'Min'; automatic shut-off activated.	Check power connection; ensure power supply; turn temperature dial to desired setting; move the iron to reactivate.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam vents clogged; steam selector set to 'Dry'.	Fill water tank; set temperature to a higher, steam-appropriate setting; clean soleplate vents; set steam selector to desired steam level.

Problem	Possible Cause	Solution
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; steam selector left on 'Steam' while iron is cooling.	Increase temperature to steam setting; do not overfill water tank; ensure steam selector is set to 'Dry' when cooling or storing.
Soleplate is dirty or sticky.	Starch buildup; ironing over synthetic materials at high heat.	Clean soleplate with a damp cloth and non-abrasive cleaner; always check fabric care labels and adjust temperature accordingly.

Specifications




Image: A diagram illustrating the physical dimensions of the Panasonic Steam Iron NI-E410T, indicating its height.

Specification	Value
Brand	Panasonic
Model Number	NI-E410T
Color	Blue (Product image shows red/white, but spec says blue. Sticking to spec.)
Product Dimensions	27.94 x 11.43 x 13.97 cm
Power / Wattage	2150 Watts
Voltage	220-240 Volts
Material	Iron (body), Titanium (soleplate)
Special Features	Automatic Shut-off, Ready Temperature Indicator Light
Item Weight	590 grams
Recommended Product Uses	Water (for steam ironing)
Style	Modern

Specification	Value
Base Material	Titanium
Manufacturer	Panasonic

Warranty and Support

This Panasonic product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Panasonic website for your region.
For technical support, service, or inquiries regarding your Panasonic Steam Iron NI-E410T, please contact Panasonic customer service through their official website or the contact information provided in your product documentation. When contacting support, please have your model number (NI-E410T) and purchase details ready.
You can find more information and support resources by visiting the Panasonic Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B010AKYRHQ

More documents and user manuals: **https://manuals.plus/**