Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garmin 010-01205-00

Garmin Sport PRO Bundle Instruction Manual

Brand: Garmin

Model: 010-01205-00

Introduction

The Garmin Sport PRO Bundle is a compact and lightweight dog training system designed for intuitive, one-handed operation. It allows for effective training of up to three dogs (with additional dog devices) using various stimulation levels, tone, and vibration. The handheld unit is designed for ease of use, even when multitasking, and features a quick-turn dial for seamless control. The system also includes a built-in Bark Limiter and LED beacon lights for enhanced visibility.



Figure 1: Garmin Sport PRO Handheld Remote and Dog Collar

What's in the Box

Your Garmin Sport PRO Bundle includes the following components:

- Sport PRO handheld remote
- Dog device (collar unit)
- 3/4-inch black polyurethane-coated nylon collar strap
- AC adapter
- Split adapter cable (for simultaneous charging)
- Charging clip
- Contact point sets (long and short) with wrench
- Manual (this document)

Components Overview

Sport PRO Handheld Remote

The handheld remote is designed for intuitive, one-handed operation, allowing you to control training functions without looking at the device.

- **Quick Turn Dial:** Easily switch between 10 stimulation levels and control auxiliary functions with positive clicks.
- **Four Training Buttons:** Dedicated buttons for continuous stimulation, momentary stimulation, vibration, and tone.
- **Bark Limiter Control:** Buttons to activate or deactivate the built-in Bark Limiter feature.
- **LED Status Light:** Provides quick, at-a-glance status information.





Figure 2: Front View of Sport PRO Handheld Remote





Figure 3: Angled View of Sport PRO Handheld Remote

Dog Device (Collar Unit)

The dog device is designed to be worn comfortably by your dog and is waterproof, with the handheld unit also floating for easy retrieval.

- **Contact Points:** Comes with interchangeable long and short contact points to ensure proper contact with your dog's skin, regardless of coat length.
- **Beacon Lights:** Remote-controlled LED beacon lights on the dog device improve visibility in low-light conditions, visible up to 100 yards away.
- **Rechargeable Battery:** Features a user-replaceable rechargeable battery for convenience.

Setup

1. Charging the Devices

Before initial use, fully charge both the Sport PRO handheld remote and the dog device. Use the provided AC adapter and split adapter cable to charge both units simultaneously.

1. Connect the charging clip to the dog device.
2. Connect the small charging plug to the handheld remote.
3. Connect the split adapter cable to the AC adapter.
4. Plug the AC adapter into a wall outlet.
5. Allow both devices to charge until the LED status lights indicate a full charge (refer to the LED indicator section in the full manual for details).

Your browser does not support the video tag.

Video 1: Official Garmin Sport PRO Overview and Charging. This video demonstrates the key features and charging process of the Garmin Sport PRO system.

2. Attaching the Collar Strap and Contact Points

Select the appropriate contact points (long or short) based on your dog's coat length to ensure proper skin contact for effective stimulation.

1. Attach the chosen contact points to the dog device using the provided wrench.
2. Thread the 3/4-inch black collar strap through the slots on the dog device.
3. Fit the collar snugly around your dog's neck, ensuring the contact points touch the skin. It should be tight enough not to move around, but loose enough for two fingers to fit comfortably under the strap.

3. Powering On/Off

To power on the dog device, press and hold the power button located on the inside near the prongs until the LED flashes green. To power off, press and hold the same button until the LED flashes red.
The handheld remote is typically always on when in use. Refer to the full manual for specific power management details of the handheld.

Operating the Sport PRO System

1. Basic Training Functions

The Sport PRO handheld offers four primary training buttons:

- **Tone:** Emits an audible tone from the dog device. Often used as a recall signal or warning.
- **Vibration:** Causes the dog device to vibrate. Can be used as a gentle warning or attention-getter.
- **Momentary Stimulation:** Delivers a single, brief pulse of stimulation.
- **Continuous Stimulation:** Delivers stimulation for as long as the button is held (up to 6 seconds for safety).

Adjust the stimulation level (1-10) using the quick-turn dial on the handheld. Always start with the lowest effective level for your dog.

2. Multi-Dog Training

The Sport PRO system can control up to three dog devices (additional devices sold separately). Use the selector switch at the top of the handheld to choose which dog device you are controlling (indicated by color: black, blue, red).

3. Bark Limiter

The built-in Bark Limiter can be activated via the handheld remote. When active, the dog device will automatically apply

correction when it detects barking, helping to reduce excessive barking. Refer to the full manual for settable levels and detailed operation of the Bark Limiter.

4. Beacon Lights

Activate the LED beacon lights on the dog device remotely from the handheld. This feature is particularly useful for tracking your dog in low-light conditions or at night, with visibility up to 100 yards.

Maintenance

- **Cleaning:** Regularly clean the dog device and contact points to prevent skin irritation and ensure proper function. Use a damp cloth and mild soap, then rinse thoroughly.
- **Battery Care:** The devices use rechargeable Lithium Ion batteries. For optimal battery life, avoid fully discharging the batteries frequently. Store devices in a cool, dry place when not in use. The dog device battery is user-replaceable.
- **Strap Inspection:** Periodically inspect the collar strap for wear and tear. Replace if damaged to ensure secure fit.

Troubleshooting

Problem	Possible Cause	Solution
Dog device not responding to remote.	Low battery on either device; out of range; incorrect dog selection on remote.	Charge both devices; ensure within 0.75-mile range; verify correct dog (black/blue/red) is selected on the remote.
Stimulation not effective.	Poor contact with dog's skin; stimulation level too low.	Ensure contact points are snug against skin (use longer points if needed); increase stimulation level gradually.
Dog device LED not lighting up.	Device is off or battery is completely drained.	Power on the device; charge the device.

Specifications

- **Product Dimensions:** 1.4 x 2.1 x 5.4 inches (Handheld)
- **Item Weight:** 4.3 ounces (Handheld)
- **Model Number:** 010-01205-00
- **Batteries:** 1 Lithium Ion battery required (rechargeable)
- **Connectivity:** Auxiliary (Radio frequency: 27 MHz)
- **Special Features:** Easy to use, lightweight, waterproof (handheld floats)
- **Color:** Green
- **Material:** Nylon, Polyurethane

- **Range:** Up to 0.75 miles
- **Stimulation Levels:** 10
- **Multi-Dog Capability:** Up to 3 dogs (additional dog devices sold separately)

Warranty and Support

For detailed warranty information and customer support, please refer to the official Garmin website or the user manual included in your product packaging. Garmin typically offers a one-year limited warranty on most of its products, covering defects in materials or workmanship.
You can also visit the Garmin Store on Amazon for additional resources and product information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01276FRQG

More documents and user manuals: **https://manuals.plus/**