Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Truper SOPLA-960

TRUPER SOPLA-960 Electric Blower User Manual

Model: SOPLA-960 | Brand: Truper

1. Product Overview

The TRUPER SOPLA-960 is a powerful 960W electric blower designed for efficient clearing of leaves, dust, and light debris. Its compact and handheld design ensures ease of use and maneuverability for various cleaning tasks around your home or workshop.



Image of the Truper SOPLA-960 Electric Blower, showcasing its compact design and orange and black color scheme.

2. Important Safety Instructions

Always read and understand all safety warnings and instructions before operating this electric blower. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

2.1 General Safety

- **Read the Manual:** Familiarize yourself with the controls and proper use of the blower.
- **Wear Eye Protection:** Always wear safety glasses or goggles when operating the blower.
- **Keep Area Clear:** Ensure the work area is free of bystanders, children, and pets.

- **Avoid Wet Conditions:** Do not operate the blower in rain or wet conditions.
- **Proper Attire:** Wear long pants, long sleeves, and sturdy footwear. Avoid loose clothing or jewelry that could get caught in moving parts.
- **Inspect Before Use:** Check the blower for any damaged parts, loose connections, or frayed cords before each use.

2.2 Electrical Safety

- **Voltage Compatibility:** Ensure the power supply voltage matches the voltage specified on the blower's rating label (127 Volts).
- **Use Proper Extension Cords:** If an extension cord is necessary, ensure it is rated for outdoor use and has a sufficient gauge for the blower's power requirements.
- **Avoid Damaged Cords:** Never use the blower with a damaged power cord or plug.
- **Unplug When Not in Use:** Always unplug the blower from the power outlet before cleaning, servicing, or storing.
- **Do Not Abuse Cord:** Never carry the blower by the cord or yank it to disconnect from an outlet.

3. Product Components

Familiarize yourself with the different parts of your TRUPER SOPLA-960 Electric Blower to ensure proper assembly and operation.



Diagram illustrating the main components of the Truper SOPLA-960 Electric Blower, including the switch, blower tube lock, blower tube, cable holder, and air intake.

Key Components

Component	Description

Component	Description
Interrupter (Switch)	Activates and deactivates the blower.
Blower Tube Lock	Secures the blower tube to the main unit.
Blower Tube	Directs the airflow for blowing debris.
Cable Holder	Provides a secure point for the power cord.
Air Intake	Area where air is drawn into the blower. Keep clear of obstructions.

4. Assembly and Setup

4.1 Attaching the Blower Tube

1. Align the grooves on the blower tube with the corresponding slots on the main blower unit.
2. Push the blower tube firmly into place until it clicks or locks securely. Ensure the blower tube lock engages.
3. Verify that the tube is securely attached and does not wobble.

4.2 Power Connection

1. Ensure the blower's switch is in the 'OFF' position.
2. Connect the blower's power cord to a suitable 127 Volt power outlet or a properly rated extension cord.
3. Use the cable holder to secure the connection and prevent accidental unplugging during operation.

5. Operating Instructions

5.1 Starting the Blower

1. With the blower properly assembled and connected to power, hold the handle firmly.
2. Press the 'Interrupter' (switch) to turn the blower ON. The motor will start instantly.

5.2 Using the Blower

- Direct the blower tube towards the debris you wish to clear.
- Use a sweeping motion to gather leaves and debris into piles.
- Maintain a safe distance from the nozzle to avoid blowing debris into your face or towards others.
- For optimal performance and motor longevity, operate the blower for periods of 30 minutes followed by 15 minutes of rest, with a maximum of 3 hours per day.

5.3 Shutting Down

1. Release the 'Interrupter' (switch) to turn the blower OFF.
2. Once the motor has completely stopped, unplug the blower from the power outlet.

6. Maintenance and Care

6.1 Cleaning

- Always unplug the blower before cleaning.
- Wipe the exterior of the blower with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Regularly check and clear any debris from the air intake vents to ensure proper airflow and prevent overheating.
- Ensure the blower tube is free of obstructions.

6.2 Storage

- Store the blower in a dry, clean, and well-ventilated area, away from direct sunlight and moisture.
- Keep the blower out of reach of children.
- Coil the power cord neatly to prevent tangling or damage.

7. Troubleshooting Guide

This section provides solutions to common issues you might encounter with your TRUPER SOPLA-960 Electric Blower.

Common Issues and Solutions

Problem	Possible Cause	Solution
Blower does not start.	No power supply. Switch is off. Damaged power cord/plug.	Check power outlet and circuit breaker. Ensure switch is in 'ON' position. Inspect cord and plug for damage; replace if necessary.
Low airflow/power.	Air intake blocked. Blower tube obstructed.	Unplug and clear any debris from air intake vents. Unplug and clear any obstructions from the blower tube.
Unusual noise or vibration.	Loose components. Debris inside housing.	Unplug and check all connections, especially the blower tube. If noise persists, discontinue use and contact customer support.
Blower overheats.	Blocked air vents. Prolonged continuous use.	Unplug and clear air intake vents. Allow the blower to cool down. Adhere to recommended operating times (30 min on, 15 min off).

8. Technical Specifications

Below are the detailed specifications for the TRUPER SOPLA-960 Electric Blower.



Image showing the approximate dimensions of the Truper SOPLA-960 Electric Blower: 77 cm in length and 25 cm in height.

TRUPER SOPLA-960 Specifications

Feature	Specification
Brand	Truper
Model Number	SOPLA-960
Power Source	Corded Electric
Voltage	127 Volts
Power	960 W
Form Factor	Handheld
Special Feature	Instant Start
Noise Level	69 dB
Included Components	Extension Nozzle
Item Weight	2.4 Kilograms (approx. 5.27 pounds)
Package Dimensions	17.83 x 10.04 x 6.97 inches

9. Warranty Information

Truper products are manufactured to high-quality standards and are warranted against defects in materials and workmanship. Please refer to your purchase receipt or the product packaging for specific warranty duration and terms. Keep your proof of purchase for any warranty claims.

10. Customer Support

For technical assistance, replacement parts, or any questions regarding your TRUPER SOPLA-960 Electric Blower, please contact Truper customer support. Contact information can typically be found on the product packaging or the official Truper website.

Website: www.truper.com (Please check for your regional website)

© 2023 Truper. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B013R1R7YK

More documents and user manuals: **https://manuals.plus/**