Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 5103062YP

Official logo of Briggs & Stratton, featuring the company name in a metallic, shield-like design.

Briggs & Stratton 5103062YP Instruction Manual

Model: 5103062YP

1. Introduction

This manual provides essential information for the proper installation, function, and maintenance of your Briggs & Stratton 5103062YP 3/16" TEE, B fitting. This genuine OEM part is designed for specific applications within Briggs & Stratton outdoor power equipment, ensuring optimal performance and compatibility.

Please read this manual thoroughly before attempting any installation or maintenance procedures to ensure safety and correct operation.

2. Safety Information

WARNING: Cancer and Reproductive Harm -www.P65Warnings.ca.gov

Always observe general safety precautions when working with machinery and replacement parts. Failure to do so may result in injury or damage to equipment.

- Ensure the equipment is turned off and cooled down before attempting any installation or maintenance.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection.
- Keep children and bystanders away from the work area.
- Use only genuine Briggs & Stratton replacement parts to ensure proper fit and function.
- If you are unsure about any procedure, consult a qualified service technician.

3. Setup and Installation

The 5103062YP is a 3/16" TEE fitting, typically used in fuel lines or vacuum lines. Installation requires careful attention to ensure a secure and leak-free connection.

1. **Identify the Connection Points:** Locate the existing lines where the TEE fitting needs to be installed. Ensure they are clean and free of debris.
2. **Prepare the Lines:** If cutting existing lines, ensure clean, straight cuts. For 3/16" lines, a sharp utility knife or hose

cutter is recommended.

3. **Install the Fitting:** Carefully push the ends of the lines onto the barbed connections of the TEE fitting. Ensure the lines are fully seated over the barbs to prevent leaks.
4. **Secure Connections (if applicable):** Depending on the application, hose clamps may be required to secure the lines to the fitting. Tighten clamps just enough to prevent leaks without over-tightening, which can damage the lines or fitting.
5. **Check for Leaks:** After installation, operate the equipment briefly and visually inspect all connections for any signs of leaks. Address any leaks immediately.

Note: Specific installation steps may vary based on the equipment model and the exact location of the fitting. Refer to your equipment's service manual for detailed diagrams and instructions.

4. Operation

As a passive component, the 3/16" TEE fitting facilitates the branching or merging of fluid or vacuum lines within your equipment's system. Once correctly installed, it operates continuously as part of the system's normal function, ensuring proper flow distribution.

No direct user interaction is required for the operation of the fitting itself after installation.

5. Maintenance

Regular inspection of the 3/16" TEE fitting and its connections is recommended as part of your equipment's routine maintenance schedule.

- **Visual Inspection:** Periodically check the fitting and connected lines for signs of wear, cracks, hardening, or leaks.
- **Connection Integrity:** Ensure that all connections remain tight and secure. Re-tighten hose clamps if necessary, but avoid over-tightening.
- **Cleaning:** Keep the area around the fitting clean and free of dirt, debris, or fluid buildup.

Replace the fitting if any damage or significant wear is observed to prevent system malfunctions or leaks.

6. Troubleshooting

Most issues related to a TEE fitting involve leaks or blockages. If you experience problems with your equipment that you suspect are related to the fitting, consider the following:

- **Leaks:**
  - Check if lines are fully seated on the barbs.
  - Ensure hose clamps (if used) are properly tightened.
  - Inspect the fitting and lines for cracks or damage. Replace if damaged.
- **Restricted Flow/Blockage:**
  - Verify that the lines connected to the fitting are not kinked or pinched.
  - Check for debris inside the lines or the fitting itself.

If troubleshooting steps do not resolve the issue, it may indicate a problem with another component of the system or require professional assistance.

7. Specifications

Attribute	Detail
Part Number	5103062YP
Description	FITTING, 3/16" TEE, B
Manufacturer	Briggs and Stratton
Item Package Quantity	1
Batteries Required?	No
ASIN	B01AFAQSKU
Date First Available	June 27, 2017

8. Warranty and Support

For information regarding warranty coverage for your Briggs & Stratton 5103062YP part, please refer to the warranty documentation provided with your original equipment or visit the official Briggs & Stratton website.

If you require technical assistance or have questions about this product, please contact Briggs & Stratton customer support or an authorized service dealer. You can find contact information and support resources on the official Briggs & Stratton website: www.briggsandstratton.com

© 2025 Briggs & Stratton. All rights reserved.
This manual is for informational purposes only. Briggs & Stratton reserves the right to make changes without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01AFAQSKU

More documents and user manuals: **https://manuals.plus/**