Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Denali Pure FA-W10311524-2PK-DL532

Denali Pure Refrigerator Air Filter Instruction Manual

Model: FA-W10311524-2PK-DL532

1. Introduction

This manual provides instructions for the installation and maintenance of your Denali Pure Refrigerator Air Filter. This product is designed as a replacement for Whirlpool W10311524 AIR1 refrigerator air filters, compatible with models such as Whirlpool WRF757SDEM00. Please read these instructions carefully before installation to ensure proper function and safety.

2. Safety Information

- Always disconnect power to the refrigerator before attempting any maintenance or installation.
- Keep the filter out of reach of children.
- Do not attempt to modify the filter or use it for purposes other than its intended use.
- Dispose of old filters responsibly according to local regulations.

3. Product Overview

The Denali Pure Refrigerator Air Filter is designed to help reduce odors in your refrigerator, contributing to a fresher internal environment. It features a compact design for easy installation.



Figure 3.1: Top-down view of the Denali Pure refrigerator air filter.



Figure 3.2: Angled view of the Denali Pure refrigerator air filter.

4. Compatibility

This Denali Pure air filter is a compatible replacement for the following:

- Whirlpool W10311524 AIR1 Refrigerator Air Filter
- Whirlpool Refrigerator models including WRF757SDEM00

Please verify your refrigerator's current filter model number to ensure compatibility.

5. Installation

Follow these steps to install your new Denali Pure Refrigerator Air Filter:

1. **Locate the Air Filter Compartment:** The air filter is typically located on the upper back wall inside the fresh food compartment of your refrigerator. Refer to your refrigerator's owner's manual for the exact location if needed.
2. **Open the Filter Cover:** Gently push in the tabs on the filter cover to release it, then pull the cover down or out.
3. **Remove the Old Filter:** Pull the old air filter straight out from its housing.
4. **Install the New Filter:** Insert the new Denali Pure air filter into the housing, ensuring it clicks securely into place. The filter can be inserted in either direction.
5. **Close the Filter Cover:** Reattach the filter cover by aligning it and pushing it firmly until it snaps into place.
6. **Reset the Filter Indicator (if applicable):** Many refrigerators have a filter indicator light. To reset it, press and hold the 'Filter Reset' button (or similar, refer to your refrigerator manual) for approximately 3 seconds until the light turns off.

6. Maintenance

For optimal performance and odor reduction, it is recommended to replace your Denali Pure Refrigerator Air Filter every 6 months. Regular replacement ensures continuous fresh air circulation within your refrigerator.

7. Troubleshooting

- **Filter does not fit:** Double-check the model number of your refrigerator and the filter. Ensure you are inserting the filter correctly into the housing.
- **Odor persists after replacement:** Ensure the filter is properly seated. If odors persist, check for expired food items or spills within the refrigerator that may be contributing to the smell.
- **Filter indicator light remains on:** Ensure you have correctly performed the filter reset procedure as outlined in your refrigerator's owner's manual.

8. Specifications

- **Brand:** Denali Pure
- **Model Number:** FA-W10311524-2PK-DL532
- **UPC:** 754672941122
- **Product Grade:** Replacement Part
- **Compatible with:** Whirlpool W10311524, Whirlpool WRF757SDEM00

9. Warranty and Support

Any warranties for this Denali Pure Refrigerator Air Filter are offered solely by Denali Pure. For support or warranty inquiries, please refer to the contact information provided with your purchase or visit the official Denali Pure website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01CCFL2AC

More documents and user manuals: **https://manuals.plus/**