Braun 81481301

Braun Clean & Renew System for Series 9 Shavers (Model 81481301) Instruction Manual

Your guide to optimal shaver maintenance and performance.

Introduction

This instruction manual provides essential information for the proper use and maintenance of your Braun Clean & Renew System, model 81481301. This system is designed to clean, lubricate, dry, and charge your Braun Series 9 electric shaver, ensuring hygienic operation and peak performance. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Information

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. This includes:

- Do not immerse the appliance in water or other liquids.
- Do not use the appliance if it is damaged.
- Keep the appliance out of reach of children.
- Only use the appliance for its intended purpose as described in this manual.
- Disconnect the appliance from the power supply before cleaning or maintenance.
- Ensure the power cord is not damaged or pinched.

Product Overview

The Braun Clean & Renew System (Model 81481301) is a dedicated cleaning and charging station for compatible Braun Series 9 electric shavers. It provides a convenient way to maintain your shaver's hygiene and performance.

Image 1: Front view of the Braun Clean & Renew System. This image displays the main unit, which is black and features a power button on the front. The top section is designed to dock a Braun Series 9 shaver for cleaning and charging.

Package Contents

- Braun Clean & Renew System (Model 81481301)

- Power Cord (typically included with the system, though not explicitly listed as a separate component in the provided data)
- *Note: Cleaning cartridges are sold separately and are required for the cleaning function.*

Setup Instructions

1. **Unpack the System:** Carefully remove the Clean & Renew System from its packaging.
2. **Choose a Location:** Place the system on a flat, stable surface in your bathroom or desired location. Ensure it is away from direct water spray.
3. **Insert Cleaning Cartridge:**
    - Press the release button on the side of the Clean & Renew System to open the housing.
    - Remove the cap from a new Braun Clean & Renew cleaning cartridge.
    - Slide the cartridge into the system until it clicks into place.
    - Close the housing until it locks securely.
4. **Connect Power:** Plug the power cord into the Clean & Renew System and then into an electrical outlet.
5. **Initial Charge:** Place your Braun Series 9 shaver head-down into the system. Ensure it clicks into place. The shaver will begin charging.

Operating the Clean & Renew System

The Clean & Renew System offers both charging and cleaning functionalities for your Braun Series 9 shaver.

Charging Your Shaver

- Ensure the Clean & Renew System is plugged into a power outlet.
- Place your Braun Series 9 shaver, with the shaving head facing downwards, into the system. The shaver will automatically begin charging.
- The charging indicator on your shaver will illuminate to confirm charging is in progress.

Initiating a Cleaning Cycle

- After shaving, ensure your shaver is turned off.
- Place the shaver head-down into the Clean & Renew System.
- Press the start button on the Clean & Renew System (typically a circular button on the front).
- The system will automatically select the appropriate cleaning program based on the shaver's cleanliness level.
- The cleaning cycle involves cleaning, lubricating, and drying the shaver. This process can take several minutes.
- Once the cycle is complete, the shaver will be clean, lubricated, and ready for its next use.

Maintenance

Replacing the Cleaning Cartridge

The cleaning cartridge should be replaced approximately every 3 months, or when the cleaning fluid indicator on the system illuminates (if applicable to your model).

1. Unplug the Clean & Renew System from the power outlet.

2. Press the release button to open the system housing.
3. Carefully remove the used cleaning cartridge. Dispose of it according to local regulations.
4. Insert a new Braun Clean & Renew cleaning cartridge as described in the "Setup Instructions" section.
5. Close the housing and reconnect the power.

Cleaning the System

- Periodically wipe the exterior of the Clean & Renew System with a damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure no water enters the electrical components.

Troubleshooting

Problem	Possible Cause	Solution
System does not power on or charge shaver.	Power cord not properly connected. No power from outlet. System malfunction.	Ensure power cord is securely plugged into both the system and the wall outlet. Test the outlet with another appliance. Contact Braun customer support.
Cleaning cycle does not start.	Shaver not correctly seated. Cleaning cartridge empty or not inserted correctly. System malfunction.	Re-seat the shaver firmly into the system. Check the cleaning cartridge level and ensure it is properly installed. Replace if empty. Contact Braun customer support.
Shaver is not cleaned effectively.	Cleaning cartridge fluid is old or low. Shaver head is excessively dirty.	Replace the cleaning cartridge. Rinse the shaver head under running water before placing it in the Clean & Renew System for a deeper clean.
System is noisy during operation.	Normal operation.	Some noise during the cleaning and drying cycles is normal. If the noise is excessive or unusual, contact support.
Compatibility issues with shaver.	Incorrect shaver model.	This Clean & Renew System (Model 81481301) is specifically designed for Braun Series 9 shavers. Ensure your shaver is a compatible Series 9 model. Refer to your shaver's manual for compatibility.

Specifications

Image 2: Side view of the Braun Clean & Renew System illustrating its approximate height of 6.0 inches (15 cm).

Model Number:	81481301
Brand:	Braun
Compatibility:	Braun Series 9 Electric Shavers
Material:	Plastic
Color:	Black
Approximate Dimensions (H x W x D):	15 cm (6.0 inches) Height (Width and Depth are proportional to the main image)
Item Weight:	352 g
Usage Environment:	Bathroom
Special Feature:	Lightweight design

Warranty and Support

For warranty information, product registration, or technical support, please refer to the documentation included with your original Braun Series 9 shaver or visit the official Braun website. You may also contact Braun customer service directly for assistance with your Clean & Renew System.
Online Support: www.braun.com