Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic SR-G06FGL

Panasonic SR-G06FGL Rice Cooker & Multi-Cooker Instruction Manual

Model: SR-G06FGL | Brand: Panasonic

1. Introduction

Thank you for purchasing the Panasonic SR-G06FGL Rice Cooker, Steamer & Multi-Cooker. This appliance is designed for convenient and efficient cooking of rice, steaming vegetables, and preparing various other dishes. With its one-step automatic cooking function, it simplifies meal preparation for individuals and small families. This model has a capacity of 3 cups of uncooked rice, yielding up to 6 cups of cooked rice. It features a durable non-stick aluminum-coated inner pan, a tempered see-through glass lid, and an automatic shut-off function for ease of use.

Included Accessories:

- Rice Cooker Unit
- Non-stick Inner Pan
- Glass Lid
- Measuring Cup
- Rice Scoop
- Operating Manual (this document)

2. Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, please read and understand all instructions before operating this appliance.

- Always ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Keep out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.

- Do not use outdoors.
- Always place the rice cooker on a stable, heat-resistant surface.
- Avoid contact with hot surfaces. Use handles or knobs.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Product Overview

The Panasonic SR-G06FGL is a compact and efficient rice cooker designed for ease of use. Below are the main components and their functions.



Image: Panasonic SR-G06FGL Rice Cooker with glass lid and white handles. The cooker is silver with a white 'COOK' switch on the front.

Components:

- **Main Unit:** The outer housing that contains the heating element and control panel.

- **Inner Pot:** Removable, non-stick aluminum pot where rice and other ingredients are cooked.
- **Glass Lid:** Tempered glass lid with a plastic knob, allowing you to monitor cooking progress.
- **COOK Switch:** A simple one-touch switch to start the cooking cycle. It automatically switches off when cooking is complete.
- **Handles:** Integrated handles on the main unit for easy portability.



Image: Diagram showing the dimensions of the Panasonic SR-G06FGL Rice Cooker. The dimensions are approximately 8.1 inches (depth) x 10.2 inches (width) x 8.5 inches (height).

4. Setup

Before first use, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Wash Components:** Wash the inner pot, glass lid, measuring cup, and rice scoop with warm, soapy water. Rinse thoroughly and dry completely. Do NOT immerse the main unit in water.
3. **Placement:** Place the rice cooker on a dry, level, and heat-resistant surface, away from direct sunlight or heat sources. Ensure there is adequate ventilation around the unit.
4. **Insert Inner Pot:** Place the clean inner pot into the main unit, ensuring it sits properly on the heating plate.

5. Operating Instructions

5.1. Cooking Rice

This rice cooker is designed for simple, one-step automatic cooking.

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of uncooked rice. For this 3-cup uncooked capacity model, you can cook up to 3 cups of uncooked rice.
2. **Rinse Rice (Optional but Recommended):** Rinse the rice under cold water until the water runs clear. This helps remove excess starch.
3. **Add Water:** Place the rinsed rice into the inner pot. Add the appropriate amount of water. A common ratio for many types of white rice is 1:1 (e.g., 1 cup rice to 1 cup water). For other rice types like brown rice, more water may be needed. Refer to your rice packaging for specific water ratios.
4. **Place Inner Pot:** Ensure the exterior of the inner pot is dry, then place it firmly into the main unit.
5. **Close Lid:** Place the glass lid securely on the rice cooker.
6. **Start Cooking:** Plug the power cord into an electrical outlet. Press the 'COOK' switch down. The indicator light will illuminate, signifying that cooking has begun.
7. **Automatic Shut-off:** The rice cooker will automatically switch to 'WARM' mode (or turn off, depending on the specific model's indicator) once the rice is cooked.
8. **Resting Period:** For best results, allow the rice to rest for 10-15 minutes with the lid on after the cooking cycle is complete. This allows the steam to distribute evenly.
9. **Serve:** Use the provided rice scoop to fluff and serve the rice.

▶ **Watch video online**
Panasonic 3 Cup Rice Cooker, Multi-Cooker And Steamer

Video: A demonstration of the Panasonic 3-Cup Rice Cooker, showing its components and basic operation for cooking rice. This video highlights the simplicity of use and the non-stick inner pot.

5.2. Steaming

The rice cooker can also be used for steaming various foods using a compatible steaming basket (sold separately or included with some models).

1. **Add Water:** Pour water into the inner pot, ensuring it does not exceed the steaming line (if marked) or about 1-2 inches from the bottom.
2. **Prepare Food:** Place vegetables, fish, eggs, or other items into the steaming basket.
3. **Steam:** Place the steaming basket over the inner pot. Close the glass lid. Press the 'COOK' switch down.
4. **Monitor:** Steam until food is tender or cooked to your preference. Cooking times will vary based on the food type and quantity.
5. **Serve:** Carefully remove the lid and steaming basket (use oven mitts as steam will be hot). Serve immediately.

▶ **Watch video online**
Panasonic SR-3NAL 1.5-Cup Automatic Rice Cooker, Silver

Video: This video demonstrates the multi-cooking capabilities of Panasonic rice cookers, including steaming vegetables, eggs, and fish, highlighting the versatility of the appliance.

6. Maintenance and Cleaning

Proper care ensures the longevity and performance of your rice cooker.

- **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Inner Pot:** The non-stick inner pan should be hand washed with warm, soapy water and a soft sponge. Do not use abrasive cleaners, metal scouring pads, or sharp utensils, as these can damage the non-stick coating.
- **Glass Lid:** Hand wash the glass lid with warm, soapy water.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
- **Heating Plate:** Gently wipe the heating plate inside the main unit with a damp cloth to remove any food residue. Ensure it is completely dry before next use.
- **Storage:** Store the clean and dry rice cooker in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your rice cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; lid not sealed properly; cooking cycle interrupted.	Add slightly more water next time; ensure lid is secure; do not open lid during cooking.
Rice is too soft/mushy	Too much water.	Reduce water slightly next time.
Rice sticks to the bottom of the pot	Not enough water; rice not rinsed; pot not properly cleaned.	Ensure correct water ratio; rinse rice thoroughly; clean inner pot properly. Soaking rice for 30 minutes before cooking can also help.
Cooker does not turn on	Not plugged in; power outage; faulty unit.	Check power connection; verify power supply; contact customer support if issue persists.

8. Specifications

Feature	Detail
Brand	Panasonic
Model Name	SR-G06FGL
Capacity	3 Cups (Uncooked) / 6 Cups (Cooked)
Product Dimensions (D x W x H)	8.1" x 10.2" x 8.5"
Power Source	Corded Electric
Product Care Instructions	Hand Wash
Included Components	Rice cooker, measuring cup, rice scooper, operating manual
Wattage	310 watts
Voltage	120 Volts

Feature	Detail
Material	Aluminum (Inner Pot)
Lid Material	Glass
Item Weight	2.6 Pounds
Color	Silver

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Panasonic website. You may also contact Panasonic customer service directly for assistance with your SR-G06FGL Rice Cooker, Steamer & Multi-Cooker.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01DGQVX46

More documents and user manuals: **https://manuals.plus/**