Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SUNPOLLO USB Mini Desk Fan

SUNPOLLO 4-inch USB Mini Desk Fan User Manual

Model: USB Mini Desk Fan

Introduction

Thank you for choosing the SUNPOLLO 4-inch USB Mini Desk Fan. This compact and powerful fan is designed to provide personal cooling in various settings, powered conveniently via USB. Its durable metal construction and quiet operation make it suitable for office desks, bedrooms, or travel. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting.

Safety Instructions

- Always ensure the fan is placed on a stable, flat surface to prevent tipping.
- Do not insert fingers or any objects into the fan grille while it is operating.
- Keep the fan away from water or other liquids. Do not operate in wet environments.
- Do not block the air intake or outlet. Ensure adequate space around the fan for proper airflow.
- Unplug the fan from the USB power source before cleaning or when not in use for extended periods.
- This fan is designed for indoor use only.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support for assistance.
- Keep out of reach of children and pets.

Package Contents

Please check the package for the following items:

- SUNPOLLO 4-inch USB Mini Desk Fan
- USB Power Cable (attached)
- User Manual



Image: The SUNPOLLO 4-inch USB Mini Desk Fan shown alongside its retail packaging and included USB cable.

Setup

1. **Placement:** Place the fan on a flat, stable surface where you desire cooling. Ensure the rubber feet are securely positioned to prevent movement.
2. **Connect Power:** Insert the USB plug of the fan's power cable into a compatible USB power source. This can be a computer's USB port, a USB wall adapter (not included), or a power bank.



Image: The USB Mini Desk Fan demonstrating connection to a laptop, a power bank, and a USB wall adapter.

Operating Instructions

1. **Power On/Off:** Locate the rocker-style power switch on the back of the fan. Press the 'I' side to turn the fan ON, and the 'O' side to turn it OFF.
2. **Adjust Angle:** The fan features a 360-degree rotation design. Gently tilt the fan head up or down to direct the airflow to your desired angle.



Image: A detailed view of the fan's rear, highlighting the rocker switch for power control and the anti-slip rubber feet.



Image: A circular diagram demonstrating the fan's ability to rotate 360 degrees on its stand, allowing for flexible airflow direction.

Maintenance

Regular cleaning helps maintain optimal performance and extends the life of your fan.

- **Cleaning:** Ensure the fan is unplugged from its power source before cleaning. Use a soft, dry cloth to wipe the exterior surfaces. For dust accumulation on the fan blades or grille, use a soft brush or compressed air. Do not use abrasive cleaners or immerse the fan in water.
- **Storage:** When not in use, store the fan in a cool, dry place, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Ensure the USB cable is securely connected to both the fan and a working USB power source. Check if the power switch is in the 'ON' position.
Weak airflow.	Blocked air intake/outlet or dust accumulation.	Ensure nothing is obstructing the front or back of the fan. Clean any dust from the grille and blades as per maintenance instructions.
Unusual noise during operation.	Fan not on a stable surface or foreign object.	Place the fan on a flat, stable surface. Check for any loose debris or objects near the fan blades (with power off).

Specifications




Image: The SUNPOLLO 4-inch USB Mini Desk Fan with key dimensions labeled: 5.7 inches width, 5.6 inches height, and 3.3 inches base depth.



Image: A diagram highlighting key features of the fan, including its high-quality metal net, four aluminum blades for stronger winds, and a triangular chassis for stability.

Feature	Detail
Brand	SUNPOLLO
Color	Red
Electric fan design	Table Fan
Power Source	USB Powered
Style	Modern
Room Type	Bedroom
Recommended Uses For Product	Travel
Wattage	2.5 watts

Feature	Detail
Finish Type	Metal
Voltage	5 Volts
Switch Type	Push Button
Included Components	Cord
Control Method	Button Control
UPC	601209206080
Item Weight	10.4 ounces
ASIN	B01DK4IHE8
Diameter	4 Inches
Batteries required	No
Mounting Type	Desk Fan
Material	Metal

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official SUNPOLLO website. Please retain your proof of purchase for any warranty claims.

© 2023 SUNPOLLO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01DK4IHE8

More documents and user manuals: **https://manuals.plus/**