Utilitech sfdc2 – 600T

Utilitech Pro 24-inch 2-Speed High Velocity Fan User Manual

Brand: Utilitech | **Model:** SFDC2-600T

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before using this fan. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the fan from the power outlet before cleaning, servicing, or moving.

- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area where it will not be tripped over.

- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.

- Do not use outdoors or on wet surfaces. This fan is designed for indoor use only.

- Place the fan on a stable, flat surface to prevent it from tipping over.

- Keep children and pets away from the fan during operation.

PACKAGE CONTENTS

Carefully unpack your fan and ensure all items are present and in good condition. If any items are missing or damaged, contact customer support.

- Utilitech Pro 24-inch High Velocity Fan Unit

- Sturdy Floor Stand with Wheels

- Assembly Hardware (bolts, nuts, washers)

- User Manual (this document)

SETUP

Assembly Instructions

Follow these steps to assemble your Utilitech Pro High Velocity Fan:

1. Carefully remove all packaging materials from the fan unit and the stand components.

2. Attach the fan head to the U-shaped floor stand using the provided bolts, nuts, and washers. Ensure the fan head is securely fastened and can pivot smoothly within the stand.

3. Attach the wheels to the designated points on the base of the floor stand. These wheels allow for easy portability of the fan.

4. Ensure all connections are tight and secure before plugging in the fan.

An image of the fully assembled Utilitech Pro 24-inch 2-Speed High Velocity Fan, showcasing its black metal frame, large circular fan head with a protective grille, and a sturdy base with wheels for portability.

OPERATING INSTRUCTIONS

Controls

The fan features a simple control knob located on the rear of the fan motor housing. This knob allows you to select between two speed settings.

Operation

1. Place the fan on a firm, level surface.

2. Plug the power cord into a standard 120V AC electrical outlet.

3. Turn the control knob on the back of the fan to select your desired speed setting: '1' for low speed or '2' for high speed.

4. To turn off the fan, turn the control knob to the 'OFF' position.

5. Adjust the angle of the fan head by tilting it up or down to direct airflow as needed.

MAINTENANCE

Cleaning

Regular cleaning will help maintain the fan's performance and extend its lifespan.

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- To clean the fan blades, carefully remove the front grille (refer to assembly instructions for reverse steps if necessary). Wipe the blades with a soft cloth. Ensure the blades are dry before reattaching the grille.
- Do not immerse the fan in water or allow water to drip into the motor housing.

Storage

When not in use, store the fan in a cool, dry place, away from direct sunlight and moisture. It is recommended to cover the fan to protect it from dust.

TROUBLESHOOTING

If you experience issues with your fan, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	No power to the outlet.	Check the power cord connection and the circuit breaker. Try another outlet.
Fan does not turn on.	Control knob is in the 'OFF' position.	Turn the control knob to '1' or '2'.
Weak or no airflow.	Fan blades are dirty or obstructed.	Unplug the fan and clean the blades and grille. Ensure no obstructions are present.

Problem	Possible Cause	Solution
Unusual noise during operation.	Loose parts or debris inside the fan.	Unplug the fan and inspect for any loose components or foreign objects. Tighten any loose screws.

SPECIFICATIONS

Feature	Detail
Brand	Utilitech
Electric fan design	Floor Fan
Power Source	Corded Electric
Style	Modern
Room Type	Bedroom
Special Feature	High Velocity
Recommended Uses For Product	Air Circulation, Cooling
Indoor/Outdoor Usage	Indoor
Control Method	Touch
Blade Material	Plastic
Is Cordless?	No
Manufacturer	Utilitech
Item Weight	30.5 pounds
Item model number	sfdc2 – 600T
Diameter	24 Inches
Batteries required	No

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase

or visit the official Utilitech website. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - sfdc2 – 600T

	[Utilitech 60-Inch High-Velocity Belt-Drive Drum Fan Manual](#) This manual provides safety instructions, operating procedures, maintenance guidelines, troubleshooting steps, warranty information, and a list of replacement parts for the Utilitech 60-inch High-Velocity Belt-Drive Drum Fan, Model SFDC-1500FB.
	[Utilitech 36-Inch Industrial High-Velocity Drum Fan Assembly and Operation Manual](#) This manual provides assembly instructions, operating guidelines, care and maintenance tips, and troubleshooting advice for the Utilitech 36-Inch Industrial High-Velocity Drum Fan (Model #SFDC-900F). It includes safety information, a parts list, and warranty details.
	[Utilitech 48-Inch High-Velocity Belt-Drive Drum Fan SFDC-1200FB Manual](#) This manual provides assembly instructions, operating procedures, care and maintenance guidelines, and troubleshooting tips for the Utilitech 48-inch High-Velocity Belt-Drive Drum Fan, model SFDC-1200FB. It also includes warranty information and a parts list.
	[Utilitech 42-Inch High-Velocity Belt-Drive Drum Fan - Assembly, Operation, and Maintenance Manual](#) This document provides assembly instructions, operating procedures, care and maintenance guidelines, and troubleshooting tips for the Utilitech 42-inch High-Velocity Belt-Drive Drum Fan (Model #SFDC-1050FB). It includes safety information and a replacement parts list.
	[Utilitech 20-Inch High-Velocity Fan SFC1-500B User Manual](#) Comprehensive user manual for the Utilitech 20-inch High-Velocity Fan, Model SFC1-500B. Includes safety information, assembly, operating instructions, care, maintenance, troubleshooting, and warranty details.

[Utilitech 20-Inch High-Velocity Shroud Fan SFD1-500B User Manual](#)

This manual provides instructions for the assembly, operation, care, and troubleshooting of the Utilitech 20-Inch High-Velocity Shroud Fan, model SFD1-500B. It includes safety information, a parts list, and warranty details.