Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun Series 7 7898cc

Braun Series 7 7898cc Electric Shaver User Manual

Model: 7898cc

Introduction

This user manual provides comprehensive instructions for the Braun Series 7 7898cc electric shaver, including its Clean & Charge Station. Please read this manual carefully before using the product to ensure safe and optimal performance. The Braun Series 7 is designed for both wet and dry shaving, offering a close and comfortable shave.



Image: The Braun Series 7 7898cc electric shaver, its Clean & Charge Station, and a protective travel case.

Safety Information

Always hold the shaver gently and avoid applying excessive pressure to prevent cuts. Do not use the shaver while charging or near water sources to avoid electrical hazards. Clean the shaver regularly to prevent bacterial growth and maintain optimal performance.

Legal Disclaimer: Actual product packaging and materials may contain more and different information than what is shown on our website. We recommend that you do not rely solely on the information presented and that you always read labels, warnings, and directions before using or consuming a product.

Package Contents

Upon unboxing your Braun Series 7 7898cc, please ensure all the following components are present:

- Braun Series 7 7898cc Electric Shaver
- Clean & Charge Station
- Cleaning Brush

- SmartPlug Charger
- Travel Case
- Cleaning Cartridge (for Clean & Charge Station)



Image: A complete overview of all items included in the Braun Series 7 7898cc package.

Setup

Charging the Shaver

1. Ensure the shaver is dry before charging.
2. Connect the SmartPlug charger to the shaver and then to a power outlet.
3. A full charge takes approximately 1 hour and provides up to 50 minutes of cordless shaving. The battery indicator will show charging progress.

Setting up the Clean & Charge Station

1. Open the Clean & Charge Station by pressing the release button.
2. Insert a cleaning cartridge into the station until it clicks into place.
3. Close the station.
4. Connect the SmartPlug charger to the Clean & Charge Station and then to a power outlet.



Image: The Braun Series 7 shaver positioned beside its Clean & Charge Station, illustrating the setup.

Operating Instructions

Shaving

- **Dry Shaving:** Ensure your face is dry before shaving.
- **Wet Shaving:** The shaver is waterproof and can be used with foam, gel, or in the shower.
- Press the On/Off button to start the shaver.
- Stretch your skin and shave against the direction of hair growth.
- Use short, circular strokes for best results.

Precision Trimmer

The integrated precision trimmer can be extended by sliding the trimmer switch upwards. It is ideal for shaping sideburns, mustaches, or trimming longer hairs before shaving.



Image: A detailed view of the shaver head, highlighting the precision foil and trimmer components.

Maintenance and Cleaning

Manual Cleaning

1. After each use, switch off the shaver and rinse the shaver head under hot running water until all residue is removed.
2. For a more thorough cleaning, remove the shaver head and tap out any trapped hairs. Use the provided cleaning brush to remove stubborn debris.
3. Allow the shaver head to air dry completely before reattaching or storing.

Using the Clean & Charge Station

1. Place the shaver head-down into the Clean & Charge Station. Ensure it clicks into place.
2. The station will automatically detect the shaver's cleanliness level and initiate the appropriate cleaning program.
3. After cleaning, the station will dry the shaver using an inductive heating system.
4. The cleaning cartridge should be replaced when the indicator light on the station signals it is empty (approximately every 3 weeks with daily use).

Replacing Shaver Parts

To maintain 100% shaving performance, replace the shaver foil and cutter block every 18 months, or when they show signs of wear. Replacement parts are available from authorized Braun retailers.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes.
Poor shaving performance.	Foil/cutter block worn out or dirty.	Clean the shaver head thoroughly or replace the foil and cutter block.
Clean & Charge Station not working.	Cleaning cartridge empty or station not powered.	Replace cleaning cartridge or ensure power connection.

Specifications

Brand: Braun

Model Name: Series 7

Item Model Number: 7898cc

Power Source: Battery Powered

Battery Type: 1 Lithium Polymer battery (included)

Battery Life: Up to 50 minutes

Special Feature: Waterproof

Recommended Uses: Beard, Face

Blade Material: Stainless Steel

Color: Silver

Item Weight: 0.93 Grams

Product Dimensions: 25.2 x 15.7 x 15.7 cm

Included Components: Shaver, Clean & Charge Station, Charger, Cleaning Brush, Travel Case, Cleaning Cartridge

Manufacturer: Braun

Date First Available: Sept. 9 2016

Warranty and Support

Braun products are manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Braun website. For customer support, replacement parts, or service inquiries, please contact Braun customer service or an authorized service center.
You can find more information and support on the official Braun website:www.braun.com

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01IN8LBOY

More documents and user manuals: **https://manuals.plus/**