Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCS SENTINEL HCN0018

SCS Sentinel ControlPower 2300W Remote Controlled Sockets

Model: HCN0018 | Brand: SCS SENTINEL

Introduction

The SCS Sentinel ControlPower 2300W remote-controlled socket set provides a convenient solution for wirelessly controlling your electrical appliances. This kit includes five remote-controlled sockets and one remote control, allowing you to switch devices on and off from a distance. Designed for indoor use, it is ideal for controlling hard-to-reach appliances or for creating a smart home environment without complex installations.

Product Overview

The ControlPower 2300W system consists of individual remote-controlled sockets and a central remote control unit. Each socket is designed to be plugged into a standard wall outlet, and your appliance then plugs into the socket. The remote control allows for independent operation of each connected socket.



Figure 1: Overview of the five remote-controlled sockets included in the set.



Figure 2: Close-up view of a single remote-controlled socket, highlighting its design and numbering.



Figure 3: The remote control unit, featuring individual ON/OFF buttons for each of the five sockets.

Safety Information

- This product is designed for **indoor use only**. Do not expose to moisture or extreme temperatures.
- Do not exceed the maximum load capacity of **2300W or 10A**. Overloading can cause damage to the device and pose a fire hazard.
- Ensure the socket is fully inserted into the wall outlet before connecting any appliance.
- Do not disassemble or attempt to repair the device. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Disconnect the socket from the power supply before cleaning. Clean only with a dry, soft cloth.

Package Contents

Please verify that all components are present in the package:

- 5 x SCS Sentinel Remote-Controlled Sockets
- 1 x SCS Sentinel Remote Control
- 1 x LR23-A-12V Battery (for remote control)
- 1 x User Manual (original language may vary)




scs sentinel
ControlPower
Prises télécommandées
+ télécommande
Control sockets
+ remote
Prese telecomandate
+ telecomando
Enchufes con mando a distancia
+ control remoto
Funksteckdosen
+ Fernbedienung
Aan/uit stekker
+ afstands bediening
Toutes les infos sur
www.scs-sentinel.com

Figure 4: The complete product set as packaged, including sockets and remote.

Setup

1. **Insert Battery into Remote Control:**

   Locate the battery compartment on the back of the remote control. Insert the supplied LR23-A-12V battery, ensuring correct polarity (+/-). Close the battery compartment securely.



Figure 5: The LR23-A-12V battery required for the remote control.

2. **Plug in the Remote-Controlled Socket:**

Plug one of the remote-controlled sockets into a standard wall outlet. Ensure it is firmly seated.

3. **Connect Your Appliance:**

   Plug the electrical appliance you wish to control into the remote-controlled socket. The product is designed for immediate use without complex pairing or configuration.

Repeat steps 2 and 3 for each of the five sockets you intend to use.

Operating Instructions

Each remote-controlled socket is pre-paired with its corresponding button on the remote control (e.g., socket 1 with button 1, socket 2 with button 2, etc.).

- To turn an appliance **ON**, press the "ON" button corresponding to the socket's number on the remote control.
- To turn an appliance **OFF**, press the "OFF" button corresponding to the socket's number on the remote control.
- The remote control has an effective range of up to **30 meters (approximately 98 feet) in an open field**. Obstacles such as walls and furniture may reduce this range.

Maintenance

- **Cleaning:** Disconnect the sockets from the power supply before cleaning. Use a soft, dry cloth to wipe the surfaces. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** If the remote control's range decreases or it stops responding, the battery may need replacement. Replace it with a new LR23-A-12V alkaline battery, ensuring correct polarity. Dispose of old batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, store the sockets and remote control in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn ON/OFF.	◦ Remote control battery is low or dead. ◦ Appliance is not properly plugged into the socket. ◦ Socket is not properly plugged into the wall outlet. ◦ Appliance power switch is OFF. ◦ Socket is overloaded.	◦ Replace the LR23-A-12V battery in the remote control. ◦ Ensure the appliance is fully plugged into the remote socket. ◦ Ensure the remote socket is fully plugged into the wall outlet. ◦ Turn the appliance's power switch to the ON position. ◦ Check the appliance's power consumption; ensure it is below 2300W/10A.
Remote control range is reduced.	◦ Low battery in remote control. ◦ Obstacles (walls, furniture) between remote and socket. ◦ Interference from other wireless devices.	◦ Replace the remote control battery. ◦ Reduce obstacles or move closer to the socket. ◦ Move the socket or remote away from other interfering devices.

Problem	Possible Cause	Solution
Socket indicator light is off.	◦ No power to the wall outlet. ◦ Socket is faulty.	◦ Check the wall outlet with another device. ◦ Contact customer support if the outlet has power but the socket does not.

SPECIFICATIONS

Model Number:	HCN0018
Manufacturer:	SCS SENTINEL
Power Supply:	230V ~ 50Hz (AC)
Max Load:	2300W / 10A
Wireless Frequency:	433.92 MHz
Remote Control Battery:	1 x LR23-A-12V (included)
Range (Open Field):	Up to 30 meters (approx. 98 feet)
Product Dimensions:	10 x 7 x 13 cm (approx. 3.9 x 2.8 x 5.1 inches)
Weight:	660 g (approx. 1.46 lbs)
Color:	White
Intended Use:	Indoor use only



Figure 6: Technical specifications label on the back of a socket.

Warranty and Support

SCS Sentinel guarantees the reliability of its innovative technical products, which are designed for easy installation and use, combining comfort and safety. Our technical support team, based in France, is available to assist you with product installation and provide thorough, personalized advice. Your satisfaction is our priority.
For further information or support, please visit the official SCS Sentinel website or contact their technical support:

- **Website:** www.scs-sentinel.com
- **Address:** SCS Sentinel - Route de St Symphorien - 85130 Les Landes Génusson, France
- **EAN/UPC:** 3760074130696





Figure 7: Product packaging displaying the official website for support.

© 2024 SCS Sentinel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LWSSZAO

More documents and user manuals: **https://manuals.plus/**