Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC108-BLUE

Frigidaire ICE102 ICE108 Compact Ice Maker User Manual

Model: EFIC108-BLUE

1. Product Overview

The Frigidaire ICE102 ICE108 is a compact and portable ice maker designed for convenience and efficiency. Its sleek blue finish complements any kitchen or compact space, such as RVs and boats. This unit is capable of producing up to 11.8 kg (26 lbs) of ice per day, with a fresh batch ready in as little as 6 minutes. It features a 2.3-liter water reservoir and stores up to 0.7 kg (1.5 lbs) of ice at a time. Electronic controls with LED indicators provide easy operation, and the compressor cooling system ensures quiet performance. The ice maker offers a choice of two ice cube sizes to suit your needs.



Figure 1: Front angle view of the Frigidaire ICE102 ICE108 Compact Ice Maker, showcasing its blue exterior, clear lid, and control panel.

2. Safety Information

Please read all safety instructions carefully before operating the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the appliance is connected to a grounded power outlet with the correct voltage (120 Volts).
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep hands and foreign objects out of the ice maker while it is operating.
- Do not operate the appliance with a damaged cord or plug.
- Place the ice maker on a stable, level surface away from direct sunlight or heat sources.
- Allow at least 15 cm (6 inches) of clearance around the appliance for proper ventilation.
- Unplug the ice maker before cleaning or when not in use for extended periods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Setup and Installation

The Frigidaire ICE102 ICE108 ice maker is designed for easy setup and requires no complex installation. Follow these steps to prepare your unit for first use:

1. **Unpack the Unit:** Carefully remove the ice maker from its packaging. Remove all packing materials, tape, and labels.
2. **Position the Ice Maker:** Place the unit on a flat, stable, and level surface. Ensure there is adequate ventilation around the appliance, at least 15 cm (6 inches) of space from walls or other objects. Avoid placing it near heat sources or in direct sunlight.
3. **Clean Before First Use:** Before making ice for consumption, it is recommended to clean the interior of the ice maker. Refer to the "Maintenance and Cleaning" section for detailed instructions.
4. **Connect to Power:** Plug the power cord into a grounded 120-Volt AC electrical outlet.

Figure 2: Rear view of the Frigidaire ICE102 ICE108, highlighting the ventilation area and power input.

4. Operating Instructions

Follow these steps to operate your Frigidaire ICE102 ICE108 ice maker:

1. **Add Water:** Open the lid and fill the water reservoir with clean, potable water up to the MAX fill line. Do not overfill.
2. **Power On:** Press the "POWER" button on the control panel. The "ICE" indicator light will illuminate.
3. **Select Ice Size:** Press the "SELECT" button to choose your desired ice cube size: Small or Large. The corresponding LED indicator will light up.
4. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice will be ready in approximately 6-10 minutes, depending on the selected size and ambient temperature.
5. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will illuminate, and the ice production will automatically pause. Remove ice from the basket to resume production.
6. **Add Water Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will illuminate, and the ice production will stop. Add more water to the reservoir to resume operation.
7. **Power Off:** To turn off the ice maker, press the "POWER" button again.

Figure 3: The Frigidaire ICE102 ICE108 with its lid open, revealing the ice basket containing freshly made ice.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ice maker. Always unplug the unit before cleaning.

5.1 Daily Cleaning

- Empty any remaining water from the reservoir and ice from the basket.
- Wipe the interior with a soft cloth dampened with warm water and a mild detergent.
- Rinse thoroughly with clean water and dry with a clean cloth.
- Wipe the exterior with a soft, damp cloth.

5.2 Deep Cleaning (Monthly or as Needed)

- Prepare a cleaning solution of water and white vinegar (10:1 ratio) or a dedicated ice maker cleaning solution.
- Pour the solution into the water reservoir.
- Run the ice maker for a few cycles (without consuming the ice) to circulate the cleaning solution.
- Drain the solution completely and rinse the reservoir and internal components thoroughly with clean water several times.
- Make a few batches of ice with clean water and discard them to ensure all cleaning residue is removed.

5.3 Storage

If storing the ice maker for an extended period, ensure it is completely drained and dry. Store it in a cool, dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Refer to the following table for common issues and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Ice maker not turning on.	No power; unit not plugged in; power outlet malfunction.	Ensure unit is securely plugged into a working, grounded outlet. Check circuit breaker.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Fill the water reservoir with clean, potable water up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket. The unit will resume ice production automatically.
Ice production is slow or ice cubes are small/misshapen.	High ambient temperature; poor ventilation; dirty condenser; water temperature too high.	Ensure proper ventilation. Clean the condenser (refer to maintenance). Use colder water. Operate in a cooler environment.
Unit is making unusual noises.	Normal operation sounds (compressor, water pump, ice dropping); loose component.	Some noise is normal. If noise is excessive or unusual, unplug the unit and contact customer support.

7. Specifications

Feature	Detail
Model Number	EFIC108-BLUE
Dimensions (L x W x H)	36.68 cm x 24.38 cm x 37.8 cm (14.44 in x 9.6 in x 14.88 in)
Weight	7.12 kg (15.7 lbs)
Ice Production Capacity	Up to 11.8 kg (26 lbs) per day
Ice Storage Capacity	0.7 kg (1.5 lbs)
Water Reservoir Capacity	2.3 Liters
Voltage	120 Volts
Refrigerant	R600a
Material	Plastic
UPC	058465801960, 058465809676

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Frigidaire website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Igloo

ASIN: B01M2ZWKSN

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M2ZWKSN

More documents and user manuals: **https://manuals.plus/**